



# Service Manual

**8013**

**8015**

**8017**

**8018**

**801** *Gravemaster*

Published by the  
TECHNICAL PUBLICATIONS DEPARTMENT  
of JCB COMPACT PRODUCTS LTD;  
Harewood Estate  
Leek Road, Cheadle  
Stoke-on-Trent  
Staffordshire, England  
ST10 2JU  
Tel: 01538 757500, Fax: 01538 757590

Publication No. 9803/3105 Issue 3

<b>General Information</b>	<b>1</b>
<b>Care &amp; Safety</b>	<b>2</b>
<b>Routine Maintenance</b>	<b>3</b>
<b>Attachments</b>	<b>A</b>
<b>Body &amp; Framework</b>	<b>B</b>
<b>Electrics</b>	<b>C</b>
<b>Controls</b>	<b>D</b>
<b>Hydraulics</b>	<b>E</b>
<b>Gearboxes</b>	<b>F</b>
<b>Track &amp; Running Gear</b>	<b>J</b>
<b>Engine</b>	<b>L</b>



## Introduction

This publication is designed for the benefit of JCB Distributor Service Engineers who are receiving, or have received, training by JCB Technical Training Department.

It is assumed that these personnel have a sound knowledge of workshop practice, safety procedures and general techniques associated with the maintenance and repair of hydraulic earthmoving equipment. Therefore, these basic subjects generally are omitted from this manual, the intention being to convey only more specialised information concerning particular aspects of a machine or component.

For example, renewal of oil seals, gaskets etc., and any component showing obvious signs of wear or damage is expected as a matter of course and, therefore, information of this nature is included only in the context of specialised procedures or where a range of wear tolerances is required. Similarly, it is expected that components will be cleaned and lubricated where appropriate, also that any opened hose or pipe connections will be blanked to prevent excessive loss of hydraulic fluid and ingress of dirt. Finally, please remember above all **SAFETY MUST COME FIRST!**

The manual is compiled in sections, the first three are numbered and contain information as follows:

- 1** = **General Information** - includes torque settings and service tools
- 2** = **Care & Safety** - includes warnings and cautions pertinent to aspects of workshop procedures etc.
- 3** = **Routine Maintenance** - includes service schedules and recommended lubricants for the machine.

The remaining sections are alphabetically coded and deal with Dismantling, Overhaul etc. of specific components, for example:

- A** = **Attachments**
- B** = **Body & Framework** ... etc.

The page numbering in each alphabetically coded section may not be continuous. This allows for the insertion of new items in later issues of the manual.

Section contents, technical data, circuit descriptions, operation descriptions etc. are inserted at the beginning of each alphabetically coded section.

All sections are listed on the front cover; tabbed divider cards align directly with individual sections on the front cover for rapid reference.

Illustrations which show a dismantled component are numbered as a guide to the dismantling sequence, which generally can be reversed for assembly.

Torque settings are given as a 'mean' figure which may be varied by plus or minus 3%. Torque figures indicated are for dry threads, hence for lubricated threads may be reduced by one third.

'Left Hand' and 'Right Hand' are as viewed from the rear of the machine.

References to alternative servicing intervals are to be treated on a 'whichever occurs first' basis.



<b>Contents</b>	<b>Page No.</b>
Identification	1 - 1
Preparation for Storage	1 - 2
Preparation after Storage	1 - 2
TOPS and FOGS	1 - 3
<b>Operation</b>	
Introduction	2 - 1
Before entering cab	2 - 2
Entering/exiting the cab	2 - 3
Cab	2 - 4
Opening the windscreen	2 - 5
Opening the side window	2 - 5
Heater controls	2 - 6
Seat control	2 - 7
Seat belt	2 - 8
Engine and track controls, switches and instruments	3 - 1
Track Controls	3 - 2
Engine Controls	3 - 3
Switches	3 - 3
Dozer controls	4 - 1
Undercarriage extension/retraction controls	4 - 2
Control Pattern - ISO/SAE	4 - 3
Excavator controls	4 - 3
Before starting the engine	5 - 2
Starting the engine	5 - 3
Jump starting the engine	5 - 4
Cold climate warm up	5 - 5
Operating in low temperatures	5 - 6
Operating in high temperatures	5 - 6
Stopping and parking the machine	6 - 1
Preparing for site travel	6 - 2
Getting the machine moving	6 - 3
Working with the dozer	7 - 1
* Working with the excavator	7 - 6
Lifting Regulations and Safe Working Loads	8 - 1
Using the Attachments and Site Safety	8 - 1
* Moving a disabled machine	10 - 1
Transporting the machine	10 - 2
Before using the trailer	10 - 2
Securing the machine	10 - 3
* Machine masses (to ISO 6016)	10 - 4
* Service Tools Numerical List	11 - 1
* Service Tools	
- Body and Framework	12 - 1
- Electrics	12 - 3
- Hydraulics	12 - 4
- Engine	12 - 5
* Sealing and Retaining Compounds	13 - 1

**Please Click Here To Download The Complete Manual**  
**Download Other Manuals**  
**If Having Any Questions Feel Free To Contact us**

**[admin@servicemanualbit.com](mailto:admin@servicemanualbit.com)**