Service Manual



JS290 - Tier III Auto

Section 1 - General Information

Section 2 - Care and Safety

Section 3 - Routine Maintenance

Section B - Body & Framework

Section C - Electrics

Section E - Hydraulics

Section F - Transmission

Section J - Track and Running Gear

Section K - Engine



Publication No. **9803/9800-4**



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

World Class Customer Support



Section 0 - Service Manual

Notes:	

0-0 9803/9800-4 **0-0**

Section 1



General Information

Service Manual - JS290 - Tier III Auto

Section 1 - General Information

Section 2 - Care and Safety

Section 3 - Routine Maintenance

Section B - Body & Framework

Section C - Electrics

Section E - Hydraulics

Section F - Transmission

Section J - Track and Running Gear

Section K - Engine



Publication No. **9803/9800-3**



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

World Class



Section 1 - General Information

Notes:	

1-0 9803/9800-3 **1-0**



Section 1 - General Information

Contents	Page No.
Introduction	
About this Manual	
Identifying Your Machine	1-3
Torque Settings	
Zinc Plated Fasteners and Dacromet Fasteners	
Hydraulic Connections	1-11
Service Tools	
Numerical List	1-15
Tool Detail Reference	1-18
Service Consumables	
Sealing and Retaining Compounds	1-39
Terms and Definitions	
Colour Coding	1-41

1-i 1-i



Section 1 - General Information

Contents Page No.

1-ii 1-ii



Introduction

About this Manual

Machine Model and Serial Number

This manual provides information for the following model(s) in the JCB machine range:

JCB JS290 from serial number 01421200 to 01421599.

Using the Service Manual

T11-00

This publication is designed for the benefit of JCB Distributor Service Engineers who are receiving, or have received, training by JCB Technical Training Department.

These personnel should have a sound knowledge of workshop practice, safety procedures, and general techniques associated with the maintenance and repair of hydraulic earthmoving equipment.

The illustrations in this publication are for guidance only. Where the machines differ, the text and/or the illustration will specify.

General warnings in Section 2 are repeated throughout the manual, as well as specific warnings. Read all safety statements regularly, so you do not forget them.

Renewal of oil seals, gaskets, etc., and any component showing obvious signs of wear or damage is expected as a matter of course. It is expected that components will be cleaned and lubricated where appropriate, and that any opened hose or pipe connections will be blanked to prevent excessive loss of hydraulic fluid and ingress of dirt.

Where a torque setting is given as a single figure it may be varied by plus or minus 3%. Torque figures indicated are for dry threads, hence for lubricated threads may be reduced by one third.

The manufacturer's policy is one of continuous improvement. The right to change the specification of the machine without notice is reserved. No responsibility will be accepted for discrepancies which may occur between specifications of the machine and the descriptions contained in this publication.

Finally, please remember above all else safety must come first!

Section Numbering

T11-005

The manual is compiled in sections, the first three are numbered and contain information as follows:

- 1 General Information includes torque settings and service tools.
- 2 Care and Safety includes warnings and cautions pertinent to aspects of workshop procedures etc.
- 3 Maintenance includes service schedules and recommended lubricants for all the machine.

The remaining sections are alphabetically coded and deal with Dismantling, Overhaul etc. of specific components, for example:

- **A** Attachments
- **B** Body and Framework, etc.

Section contents, technical data, circuit descriptions, operation descriptions etc. are inserted at the beginning of each alphabetically coded section.

Please Click Here To Download The Complete Manual Download Other Manuals If Having Any Questions Feel Free To Contact us

admin@servicemanualbit.com