

HYDRAULIC EXCAVATOR

**SHOP
MANUAL** model

**SK230(LC)-6E
SK250(LC)-6E
SK250NLC-6E**

INDEX

1	SPECIFICATIONS SECTION
2	MAINTENANCE SECTION
3	SYSTEM SECTION
4	DISASSEMBLY SECTION
5	TROUBLESHOOTING
6	ENGINE SECTION
7	INSTALLATION PROCEDURES FOR OPTIONAL ATTACHMENT

MAINTENANCE SPECIFICATIONS

SYSTEM

DISASSEMBLING

TROUBLESHOOTING

E/G

OPT.

KOBELCO

Book Code No. **S5LQ0012E②**



WARNING



SAFETY



WARNING



The proper and safe lubrication and maintenance for this machine, recommended by KOBELCO are outlined in the OPERATION & MAINTENANCE GUIDE for this machine.

Improper performance of lubrication or maintenance procedures is dangerous and could result in injury or death. Read and understand the OPERATION & MAINTENANCE GUIDE before performing any lubrication or maintenance.

The serviceman or mechanic may be unfamiliar with many of the systems on this machine. This makes it important to use caution when performing service work. A knowledge of the system and or components is important before the removal or disassembly of any component.

Because of the size of some of the machine components, the serviceman or mechanic should check the weights noted in this Manual. Use proper lifting procedures when removing any components.

Following is a list of basic precautions that should always be observed.

1. Read and understand all Warning plates and decals on the machine before operating, lubricating or repairing this product.
2. Always wear protective glasses and protective shoes when working around machines. In particular, wear protective glasses when pounding on any part of the machine or its attachments with a hammer or sledge. Use welders gloves, hood / goggles, apron and other protective clothing appropriate to the welding job being performed. Do not wear loose-fitting or torn clothing. Remove all rings from fingers when working on machinery.
3. Disconnect battery and discharge any capacitors before starting to work on machine. Hang "Do Not Operate" tag in the Operator's Cab.
4. If possible, make all repairs with the machine parked on a level, hard surface. Block machine so it does not roll while working on or under machine.
5. Do not work on any machine that is supported only by lift jacks or a hoist. Always use blocks or jack stands to support the machine before performing any disassembly.



WARNING



Do not operate this machine unless you have read and understand the instructions in the OPERATORS MANUAL. Improper machine operation is dangerous and could result in injury or death.

6. Relieve all pressure in air, oil or water systems before any lines, fittings or related items are disconnected or removed. Always make sure all raised components are blocked correctly and be alert for possible pressure when disconnecting any device from a system that utilizes pressure.
7. Lower the bucket, blade, ripper or other attachment to the ground before performing any work on the machine. If this cannot be done, make sure the bucket, blade, ripper or other attachment is blocked correctly to prevent it from dropping unexpectedly.
8. Use steps and grab handles when mounting or dismounting a machine. Clean any mud or debris from steps, walkways or work platforms before using. Always face machine when using steps, ladders and walkways. When it is not possible to use the designed access system, provide ladders, scaffolds, or work platforms to perform safe repair operations.
9. To avoid back injury, use a hoist when lifting components which weigh 23 kg (50 lbs) or more. Make sure all chains, hooks, slings, etc., are in good condition and are in the correct capacity. Be sure hooks are positioned correctly. Lifting eyes are not to be side loaded during a lifting operation.
10. To avoid burns, be alert for hot parts on machines which have just been stopped and hot fluids in lines, tubes and components.
11. Be careful when removing cover plates. Gradually back off the last two bolts or nuts located at opposite ends of the cover or device and pry cover loose to relieve any spring or other pressure, before removing the last two bolts or nuts completely.
12. Be careful when removing filler caps, breathers and plugs on the machine. Hold a rag over the cap or plug to prevent being sprayed or splashed by liquids under pressure. The danger is even greater if the machine has just been stopped because fluids can be hot.



WARNING



13. Always use tools that are in good condition and be sure you understand how to use them before performing any service work.
14. Reinstall all fasteners with same part number. Do not use a lesser quality fastener if replacements are necessary.
15. Repairs, which require welding, should be performed only with the benefit of the appropriate reference information and by personnel adequately trained and knowledgeable in welding procedures. Determine type of metal being welded and select correct welding procedure and electrodes, rods or wire to provide a weld metal strength equivalent at least to that of parent metal. Always disconnect battery during welding operations to protect sensitive electric equipment.
16. Do not damage wiring during removal operations. Reinstall the wiring so it is not damaged nor will it be damaged in operation by contacting sharp corners, or by rubbing against some object or hot surface. Do not connect wiring to a line containing fluid.
17. Be sure all protective devices including guards and shields are properly installed and functioning correctly before starting a repair. If a guard or shield must be removed to perform the repair work, use extra caution.
18. Loose or damaged fuel, lubricant and hydraulic lines, tubes and hoses can cause fires. Do not bend or strike high-pressure lines or install ones, which have been bent or damaged. Inspect lines, tubes and hoses carefully. Do not check for leaks with your hands. Pinhole (very small) leaks can result in a high velocity oil stream that will be invisible close to the hose. This oil can penetrate the skin and cause personal injury. Use cardboard or paper to locate pinhole leaks.
19. Tighten connections to the correct torque. Make sure that all heat shields, clamps and guards are installed correctly to avoid excessive heat, vibration or rubbing against other parts during operation. Shields that protect against oil spray onto hot exhaust components in event of a line, tube or seal failure must be installed correctly.
20. Do not operate a machine if any rotating part is damaged or contacts any other part during operation. Any high speed-rotating component that has been damaged or altered should be checked for balance before reusing.
21. On track-type machines, be careful when servicing or separating tracks. Chips can fly when removing or installing a track pin. Wear safety glasses and long sleeve shirts. Track can unroll very quickly when separated. Keep away from front and rear of machine. The machine can move unexpectedly when both tracks are disengaged from the sprockets. Block the machine to prevent it from moving.

SK230 (LC)-6E
SK250 (LC)-6E
SK250 (NLC)-6E

Index of shop Manual

Book Code No. Distribution Year-Month				Title	Index No.
LQ09-04801~ LL09-03501~	LQ09-04801~ LL09-03501~ LQ10-04915~ LL10-03666~			APPLICABLE MACHINES	
S5LQ0112E 2002-10	S5LQ0112E ① 2003-11		SPECIFICATIONS	OUTLINE	LQ01
S5LQ0212E 2002-10	S5LQ0212E ① 2003-11			SPECIFICATION	LQ02
S5LQ0312E 2002-10	S5LQ0312E ① 2003-11			ATTACHMENT DIMENSION	LQ03
S5LQ1112E 2002-10	S5LQ1112E ① 2003-11		MAINTENANCE	TOOLS	LQ11
S5LQ1212E 2002-10	S5LQ1212E ① 2003-11			STANDARD MAINTENANCE TIME SCHEDULE	LQ12
S5LQ1312E 2002-10	S5LQ1312E ① 2003-11			MAINTENANCE STANDARD AND TEST PROCEDURE	LQ13
S5LQ2112E 2002-10	S5LQ2112E ① 2003-11		SYSTEM	MECHATRO CONTROL SYSTEM	LQ21
S5LQ2212E 2002-10	S5LQ2212E ① 2003-11			HYDRAULIC SYSTEM	LQ22
S5LQ2312E 2002-10	S5LQ2312E ① 2003-11			ELECTRICAL SYSTEM	LQ23
S5LQ2412E 2002-10	S5LQ2412E ① 2003-11			COMPONENTS SYSTEM	LQ24
S5LQ2512E 2002-10	S5LQ2512E ① 2003-11			AIR-CONDITIONER SYSTEM	LQ25
—	—			—	
S5LQ3112E 2002-10	S5LQ3112E ① 2003-11		DISASSEMBLING	DISASSEMBLING AND ASSEMBLING	LQ31
S5LQ3212E 2002-10	S5LQ3212E ① 2003-11			ATTACHMENT	LQ32
S5LQ3312E 2002-10	S5LQ3312E ① 2003-11			UPPER STRUCTURE	LQ33
S5LQ3412E 2002-10	S5LQ3412E ① 2003-11			TRAVEL SYSTEM	LQ34
S5LQ4112E 2002-10	S5LQ4112E ① 2003-11		TROUBLESHOOTING	MECHATRO CONTROL	LQ41
S5LQ4212E 2002-10	S5LQ4212E ① 2003-11			HYDRAULIC	LQ42
S5LQ4312E 2002-10	S5LQ4312E ① 2003-11			ELECTRICAL	LQ43
S5LQ4412E 2002-10	S5LQ4412E ① 2003-11			ENGINE	LQ44
S5LQ5112E 2002-10	S5LQ5112E ① 2003-11		E/G	ENGINE	LQ51
			OPT.	MOUNTING THE BREAKER AND NIBBLER & BREAKER	LQ63
—	S5LQ6601E 2004-07			LIFTING MAGNET	LQ66

KOBELCO

Book Code No.

S5**LQ01** 12E ①

SHOP MANUAL

SK230(LC)-6E
SK250(LC)-6E
SK250NLC-6E

LQ01

— OUTLINE —

TABLE OF CONTENTS

- 1. GENERAL PRECAUTIONS FOR MAKING REPAIRS 1-1
- 2. INTERNATIONAL UNIT CONVERSION SYSTEM 1-4

KOBELCO CONSTRUCTION MACHINERY CO., LTD.

Applicable Machines

LQ09-04801~

LL09-03501~

LQ10-04915~

LL10-03666~

Revision	Date of Issue	Remarks	
First edition	October, 2002	S5LQ0112E	K·E
First revision	November, 2003	S5LQ0112E①	K·E

Please Click Here To Download The Complete Manual
Download Other Manuals
If Having Any Questions Feel Free To Contact us

admin@servicemanualbit.com