HYDRAULIC EXCAVATOR

SHOP MANUAL

model

SK330_{(LC)-6E}

INDEX

1	SPECIFICATION SECTION
2	MAINTENANCE SECTION
3	SYSTEM SECTION
4	DISASSEMBLY SECTION
5	TROUBLESHOOTING
6	ENGINE SECTION
7	INSTALLATION PROCEDURES FOR OPTIONAL ATTACHMENT





SAFETY

A WARNING

The proper and safe lubrication and maintenance for this machine, recommended by KOBELCO are outlined in the OPERATION & MAINTENANCE GUIDE for this machine.

Improper performance of lubrication or maintenance procedures is dangerous and could result in injury or death. Read and understand the OPERATION & MAINTENANCE GUIDE before performing any lubrication or maintenance.

The serviceman or mechanic may be unfamiliar with many of the systems on this machine. This makes it important to use caution when performing service work. A knowledge of the system and or components is important before the removal or disassembly of any component.

Because of the size of some of the machine components, the serviceman or mechanic should check the weights noted in this Manual. Use proper lifting procedures when removing any components.

Following is a list of basic precautions that should always be observed.

- 1. Read and understand all Warning plates and decals on the machine before operating, lubricating or repairing this product.
- 2. Always wear protective glasses and protective shoes when working around machines. In particular, wear protective glasses when pounding on any part of the machine or its attachments with a hammer or sledge. Use welders gloves, hood / goggles, apron and other protective clothing appropriate to the welding job being performed. Do not wear loose-fitting or torn clothing. Remove all rings from fingers when working on machinery.
- Disconnect battery and discharge any capacitors before starting to work on machine. Hang "Do Not Operate" tag in the Operator's Cab.
- If possible, make all repairs with the machine parked on a level, hard surface. Block machine so it does not roll while working on or under machine.
- 5. Do not work on any machine that is supported only by lift jacks or a hoist. Always use blocks or jack stands to support the machine before performing any disassembly.

A WARNING

Do not operate this machine unless you have read and understand the instructions in the OPERATORS MANUAL. Improper machine operation is dangerous and could result in injury or death.

- 6. Relieve all pressure in air, oil or water systems before any lines, fittings or related items are disconnected or removed. Always make sure all raised components are blocked correctly and be alert for possible pressure when disconnecting any device from a system that utilizes pressure.
- 7. Lower the bucket, blade, ripper or other attachment to the ground before performing any work on the machine. If this cannot be done, make sure the bucket, blade, ripper or other attachment is blocked correctly to prevent it from dropping unexpectedly.
- 8. Use steps and grab handles when mounting or dismounting a machine. Clean any mud or debris from steps, walkways or work platforms before using. Always face machine when using steps, ladders and walkways. When it is not possible to use the designed access system, provide ladders, scaffolds, or work platforms to perform safe repair operations.
- 9. To avoid back injury, use a hoist when lifting components which weigh 23 kg (50 lbs) or more. Make sure all chains, hooks, slings, etc., are in good condition and are in the correct capacity. Be sure hooks are positioned correctly. Lifting eyes are not to be side loaded during a lifting operation.
- 10. To avoid burns, be alert for hot parts on machines which have just been stopped and hot fluids in lines, tubes and components.
- 11. Be careful when removing cover plates. Gradually back off the last two bolts or nuts located at opposite ends of the cover or device and pry cover loose to relieve any spring or other pressure, before removing the last two bolts or nuts completely.
- 12. Be careful when removing filler caps, breathers and plugs on the machine. Hold a rag over the cap or plug to prevent being sprayed or splashed by liquids under pressure. The danger is even greater if the machine has just been stopped because fluids can be hot.

MARNING

- 13. Always use tools that are in good condition and be sure you understand how to use them before performing any service work.
- 14. Reinstall all fasteners with same part number. Do not use a lesser quality fastener if replacements are necessary.
- 15. Repairs, which require welding, should be performed only with the benefit of the appropriate reference information and by personnel adequately trained and knowledgeable in welding procedures. Determine type of metal being welded and select correct welding procedure and electrodes, rods or wire to provide a weld metal strength equivalent at least to that of parent metal. Always disconnect battery during welding operations to protect sensitive electric equipment.
- 16. Do not damage wiring during removal operations. Reinstall the wiring so it is not damaged nor will it be damaged in operation by contacting sharp corners, or by rubbing against some object or hot surface. Do not connect wiring to a line containing fluid.
- 17. Be sure all protective devices including guards and shields are properly installed and functioning correctly before starting a repair. If a guard or shield must be removed to perform the repair work, use extra caution.
- 18. Loose or damaged fuel, lubricant and hydraulic lines, tubes and hoses can cause fires. Do not bend or strike high-pressure lines or install ones, which have been bent or damaged. Inspect lines, tubes and hoses carefully. Do not check for leaks with your hands. Pinhole (very small) leaks can result in a high velocity oil stream that will be invisible close to the hose. This oil can penetrate the skin and cause personal injury. Use cardboard or paper to locate pinhole leaks.
- 19. Tighten connections to the correct torque. Make sure that all heat shields, clamps and guards are installed correctly to avoid excessive heat, vibration or rubbing against other parts during operation. Shields that protect against oil spray onto hot exhaust components in event of a line, tube or seal failure must be installed correctly.

- 20. Do not operate a machine if any rotating part is damaged or contacts any other part during operation. Any high speed-rotating component that has been damaged or altered should be checked for balance before reusing.
- 21. On track-type machines, be careful when servicing or separating tracks. Chips can fly when removing or installing a track pin. Wear safety glasses and long sleeve shirts. Track can unroll very quickly when separated. Keep away from front and rear of machine. The machine can move unexpectedly when both tracks are disengaged from the sprockets. Block the machine to prevent it from moving.

Book Code No.			Index	Title	
Distribution Year-Month			No	11016	
S5LC0109E 2003-03	S5LC0109E① 2003-11		TION	OUTLINE	LC01
S5LC0209E 2003-03	S5LC0209E① 2003-11		SPECIFICATION	SPECIFICATION	LC02
S5LC0309E 2003-03	S5LC0309E① 2003-11		SPEC	ATTACHMENT DIMENSION	LC03
S5LC1109E 2003-03	S5LC1109E① 2003-11		NCE	TOOLS	LC11
S5LC1209E 2003-03	S5LC1209E① 2003-11		MAINTENANCE	STANDARD MAINTENANCE TIME TABLE	LC12
S5LC1309E 2003-03	S5LC1309E① 2003-11		MAIN	MAINTENANCE STANDARD AND TEST PROCEDURE	LC13
S5LC2109E 2003-03	S5LC2109E① 2003-11			MECHATRO CONTROL SYSTEM	LC21
S5LC2209E 2003-03	S5LC2209E① 2003-11			HYDRAULIC SYSTEM	LC22
S5LC2309E 2003-03	S5LC2309E① 2003-11		SYSTEM	ELECTRICAL SYSTEM	LC23
S5LC2409E 2003-03	S5LC2409E① 2003-11		SYS	COMPONENTS SYSTEM	LC24
S5LC2509E 2003-03	S5LC2509E① 2003-11			AIR-CONDITIONER SYSTEM	LC25
S5LC3109E 2003-03	S5LC3109E① 2003-11		NG	DISASSEMBLING AND ASSEMBLING	LC31
S5LC3209E 2003-03	S5LC3209E① 2003-11		SSEMBLING	ATTACHMENT	LC32
S5LC3309E 2003-03	S5LC3309E① 2003-11			UPPER STRUCTURE	LC33
S5LC3409E 2003-03	S5LC3409E① 2003-11		DISA	TRAVEL SYSTEM	LC34
S5LC4109E 2003-03	S5LC4109E① 2003-11		TING	MECHATRO CONTROL	LC41
S5LC4209E 2003-03	S5LC4209E① 2003-11		TROUBLESHOOTING	HYDRAULIC	LC42
S5LC4309E 2003-03	S5LC4309E① 2003-11		JBLE	ELECTRICAL	LC43
S5LC4409E 2003-03	S5LC4409E① 2003-11		TRO	ENGINE	LC44
S5LC5109E 2003-03	S5LC5109E① 2003-11		E/G	ENGINE	LC51
★ S5LC6103E 2003-05	—		OPT.	LMN & BREAKER	LC61
	★ S5LC6303E 2003-11		Ö	MOUNTING THE BREAKER AND NIBBLER & BREAKER	LC63
LC08-06201~ YC08-03001~	LC08-06201~ YC08-03001~ LC09-06323~ YC09-03088~		;	APPLICABLE MACHINES	

KOBELCO

SK330(LC)-BE SHOP MANUAL SK330(LC)-BE LC01

OUTLINE

TABLE OF CONTENTS

1.	GENERAL PRECAUTIONS FOR MAKING REPAIRS	1
2.	INTERNATIONAL UNIT CONVERSION SYSTEM	4

KOBELCO CONSTRUCTION MACHINERY CO., LTD.

Applicable Machines LC08-06201~ YC08-03001~ LC09-06323~ YC09-03088~

Revision	Date of Issue	Remarks	
First edition	March, 2003	S5LC0109E	K
First revision	November, 2003	S5LC0109E①	К
·			

Please Click Here To Download The Complete Manual Download Other Manuals If Having Any Questions Feel Free To Contact us

admin@servicemanualbit.com