

SHOP  
MANUAL

**KOMATSU**

**6D105 SERIES**

**DIESEL ENGINE**

# CONTENTS

	No. of page
<b>01 GENERAL</b> .....	01-001
<b>11 STRUCTURE AND FUNCTION</b> .....	11-001
<b>12 TESTING AND ADJUSTING</b> .....	12-001
<b>13 DISASSEMBLY AND ASSEMBLY</b> .....	13-001
<b>14 MAINTENANCE STANDARD</b> .....	14-001

Not to be reproduced in whole or in part without the prior written permission of  
**KOMATSU**, Tokyo, Japan.

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
( )	Page to be deleted	Discard

Pages having no marks are those previously revised or made additions.

### LIST OF REVISED PAGES



Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
●	00-1	(9)		01-026			11-016			11-061			12-030	
	00-2	(8)		01-027		●	11-017	(9)		11-062			12-031	
●	00-2-1	(9)		01-028			11-018		●	11-063	(9)		12-032	
●	00-2-2	(9)		01-029			11-019			11-064			12-033	
	00-3			01-030		●	11-020	(9)	●	11-065	(9)		12-034	
	00-4			01-031			11-021			11-065-1	(7)		12-035	
	00-5			01-032			11-022			11-066			12-036	(8)
	00-6			01-033			11-023		●	11-067	(9)		12-037	(8)
	00-7			01-034			11-024		●	11-068	(9)		12-037-1	(7)
	00-8			01-035			11-025		○	11-068-1	(9)	●	12-038	(9)
	00-9			01-036			11-026			11-069			12-039	
	00-10			01-036-1	(7)		11-027		●	11-070	(9)		12-040	
	00-11			01-037			11-028		●	11-071	(9)		12-041	
	00-12			01-038			11-029		●	11-072	(9)		12-042	
	00-13			01-038-1	(8)		11-030			11-074			12-043	
	00-14			01-039		●	11-031	(9)		11-075			12-044	
	00-15			01-040			11-032					●	12-045	(9)
	00-16			01-041			11-033			12-001	(7)		12-046	
				01-042			11-035	(7)		12-002			12-047	
	01-001			01-043			11-036			12-003	(7)	●	12-048	(9)
	01-002			01-044			11-037			12-004			12-049	
	01-003			01-045			11-038			12-005			12-050	
	01-004			01-046			11-039			12-006			12-051	
	01-005			01-047	(7)		11-040			12-007			12-052	
	01-006			01-048	(7)		11-041	(7)		12-008			12-053	
●	01-007	(9)		01-049		●	11-042	(9)		12-009			12-054	
●	01-008	(9)	○	01-050	(9)		11-043			12-010			12-055	
●	01-009	(9)	○	01-051	(9)		11-044	(7)	●	12-011	(9)		12-056	
●	01-009-1	(9)	○	01-052	(9)		11-045		●	12-012	(9)		12-057	
●	01-010	(9)					11-046	(7)	●	12-013	(9)		12-058	
	01-011	(7)		11-001	(7)		11-047		●	12-014	(9)		12-058-1	(8)
○	01-011-1	(9)		11-002		●	11-048	(9)		12-015			12-058-2	(8)
	01-012			11-003			11-049			12-016		○	12-058-3	(9)
	01-013			11-004		●	11-050	(9)		12-017		○	12-058-4	(9)
	01-014			11-005		●	11-050-1	(9)		12-018		○	12-058-5	(9)
	01-015		●	11-006	(9)		11-050-2	(7)		12-019			12-059	
	01-016			11-007			11-051	(7)		12-020			12-060	
	01-017			11-008	(7)		11-052			12-021			12-061	
	01-018			11-008-1	(7)		11-053		●	12-022	(9)		12-062	
	01-019			11-009			11-054		●	12-023	(9)		12-063	
	01-020	(7)		11-010	(7)		11-055			12-024		●	12-064	(9)
	01-021			11-011			11-056			12-025			12-065	
	01-022	(7)		11-012			11-057			12-026			12-066	
	01-023			11-013	(7)		11-058			12-027			12-067	
●	01-024	(9)		11-014			11-059		●	12-028	(9)		12-068	
	01-025			11-015			11-060		●	12-029	(9)	●	12-069	(9)

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
●	12-070	(9)		13-012		●	14-012	(9)						
●	12-071	(9)		13-013			14-013							
●	12-072	(9)		13-014		●	14-014	(9)						
●	12-073	(9)		13-015		●	14-015	(9)						
	12-074	(7)		13-016			14-016							
	12-075	(8)		13-017		●	14-017	(9)						
	12-076	(8)		13-018			14-018							
○	12-077	(9)		13-019			14-019							
	12-078			13-020		●	14-020	(9)						
	12-079			13-021		●	14-021	(9)						
	12-080	(8)		13-022			14-022							
	12-081	(8)		13-023										
	12-082	(8)		13-024										
	12-083	(8)		13-025										
○	12-083-1	(9)		13-026										
○	12-083-2	(9)		13-027										
	12-084		●	13-028	(9)									
	12-085			13-029										
●	12-086	(9)	●	13-030	(9)									
●	12-087	(9)		13-031										
●	12-088	(9)		13-032										
●	12-088-1	(9)		13-033										
●	12-089	(9)		13-034										
●	12-090	(9)		13-035										
●	12-091	(9)		13-036										
●	12-092	(9)	●	13-037	(9)									
●	12-093	(9)		13-038										
	12-094			13-039										
	12-095	(7)		13-040										
●	12-096	(9)		13-041										
●	12-097	(9)		13-042										
●	12-098	(9)		13-043										
●	12-099	(9)		13-044										
●	12-100	(9)		13-045										
●	12-101	(9)		13-046	(7)									
●	12-102	(9)		13-047										
●	12-103	(9)		13-048										
●	12-104	(9)		13-049										
	12-105			13-050										
●	12-106	(9)		13-051										
●	12-107	(9)		13-052										
●	12-108	(9)		13-053										
●	12-109	(9)		13-054										
●	12-110	(9)		13-055										
●	12-111	(9)		13-056										
●	13-001	(9)		14-001										
	13-002		●	14-002	(9)									
	13-003		●	14-003	(9)									
	13-004		●	14-004	(9)									
	13-005			14-005										
	13-006		●	14-006	(9)									
	13-007			14-007										
	13-008			14-008										
	13-009		●	14-009	(9)									
	13-010			14-010	(7)									
	13-011			14-011										



## IMPORTANT SAFETY NOTICE

Proper service and repair is extremely important for the safe operation of your machine. The service and repair techniques recommended by Komatsu and described in this manual are both effective and safe methods of operation. Some of these operations require the use of tools specially designed by Komatsu for the purpose.

To prevent injury to workers, the symbols  and  are used to mark safety precautions in this manual. The cautions accompanying these symbols should always be followed carefully. If any dangerous situation arises or may possibly arise, first consider safety, and take the necessary actions to deal with the situation.



## SAFETY

### GENERAL PRECAUTIONS

Mistakes in operation are extremely dangerous. Read the Operation and Maintenance Manual carefully **BEFORE** operating the machine.

1. Before carrying out any greasing or repairs, read all the precautions given on the decals which are fixed to the machine.
2. When carrying out any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
  - Always wear safety glasses when hitting parts with a hammer.
  - Always wear safety glasses when grinding parts with a grinder, etc.
3. If welding repairs are needed, always have a trained, experienced welder carry out the work. When carrying out welding work, always wear welding gloves, apron, glasses, cap and other clothes suited for welding work.
4. When carrying out any operation with two or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the operation. Before starting work, hang **UNDER REPAIR** signs on the controls in the operator's compartment.
5. Keep all tools in good condition and learn the correct way to use them.

6. Decide a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt or oil on the floor. Smoke only in the areas provided for smoking. Never smoke while working.

### PREPARATIONS FOR WORK

7. Before adding oil or making any repairs, park the machine on hard, level ground, and block the wheels or tracks to prevent the machine from moving.
8. Before starting work, lower blade, ripper, bucket or any other work equipment to the ground. If this is not possible, insert the safety pin or use blocks to prevent the work equipment from falling. In addition, be sure to lock all the control levers and hang warning signs on them.
9. When disassembling or assembling, support the machine with blocks, jacks or stands before starting work.
10. Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine. Never jump on or off the machine. If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.

## PRECAUTIONS DURING WORK

11. When removing the oil filler cap, drain plug or hydraulic pressure measuring plugs, loosen them slowly to prevent the oil from spurting out.  
Before disconnecting or removing components of the oil, water or air circuits, first remove the pressure completely from the circuit.
12. The water and oil in the circuits are hot when the engine is stopped, so be careful not to get burned.  
Wait for the oil and water to cool before carrying out any work on the oil or water circuits.
13. Before starting work, remove the leads from the battery. Always remove the lead from the negative (–) terminal first.
14. When raising heavy components, use a hoist or crane.  
Check that the wire rope, chains and hooks are free from damage.  
Always use lifting equipment which has ample capacity.  
Install the lifting equipment at the correct places. Use a hoist or crane and operate slowly to prevent the component from hitting any other part. Do not work with any part still raised by the hoist or crane.
15. When removing covers which are under internal pressure or under pressure from a spring, always leave two bolts in position on opposite sides. Slowly release the pressure, then slowly loosen the bolts to remove.
16. When removing components, be careful not to break or damage the wiring. Damaged wiring may cause electrical fires.
17. When removing piping, stop the fuel or oil from spilling out. If any fuel or oil drips on to the floor, wipe it up immediately. Fuel or oil on the floor can cause you to slip, or can even start fires.
18. As a general rule, do not use gasoline to wash parts. In particular, use only the minimum of gasoline when washing electrical parts.
19. Be sure to assemble all parts again in their original places.  
Replace any damaged parts with new parts.
  - When installing hoses and wires, be sure that they will not be damaged by contact with other parts when the machine is being operated.
20. When installing high pressure hoses, make sure that they are not twisted. Damaged tubes are dangerous, so be extremely careful when installing tubes for high pressure circuits. Also, check that connecting parts are correctly installed.
21. When assembling or installing parts, always use the specified tightening torques. When installing protective parts such as guards, or parts which vibrate violently or rotate at high speed, be particularly careful to check that they are installed correctly.
22. When aligning two holes, never insert your fingers or hand. Be careful not to get your fingers caught in a hole.
23. When measuring hydraulic pressure, check that the measuring tool is correctly assembled before taking any measurements.
24. Take care when removing or installing the tracks of track-type machines.  
When removing the track, the track separates suddenly, so never let anyone stand at either end of the track.

---

## FOREWORD

---

This shop manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgements. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This shop manual mainly contains the necessary technical information for operations performed in a service workshop.

For ease of understanding, the manual is divided into chapters for each main group of components; these chapters are further divided into the following sections.

### **STRUCTURE AND FUNCTION**

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

### **TESTING AND ADJUSTING**

This section explains checks to be made before and after performing repairs, as well as adjustments to be made at completion of the checks and repairs.

Troubleshooting charts correlating "Problems" to "Causes" are also included in this section.

### **DISASSEMBLY AND ASSEMBLY**

This section explains the order to be followed when removing, installing, disassembling or assembling each component, as well as precautions to be taken for these operations.

### **MAINTENANCE STANDARD**

This section gives the judgement standards when inspecting disassembled parts.

### **NOTICE**

**The specifications contained in this shop manual are subject to change at any time and without any advance notice. Contact your KOMATSU distributor for the latest information.**

## HOW TO READ THE SHOP MANUAL

### VOLUMES

Shop manuals are issued as a guide to carrying out repairs. They are divided as follows:

- Chassis volume:** Issued for every machine model
- Engine volume:** Issued for each engine series
- Electrical volume** : } Each issued as one volume to cover all models
- Attachments volume** : }


These various volumes are designed to avoid duplicating the same information. Therefore to deal with all repairs for any model, it is necessary that chassis, engine, electrical and attachment volumes are ready.

### DISTRIBUTION AND UPDATING


Any additions, amendments or other changes will be sent to KOMATSU distributors. Get the most up-to-date information before you start any work.

### FILING METHOD

1. See the page number on the bottom of the page. File the pages in correct order.
2. Following examples shows how to read the page number.  
Example 1 (Chassis volume):



Example 2 (Engine volume):



3. Additional pages: Additional pages are indicated by a hyphen (-) and number after the page number. File as in the example.  
Example:



### REVISED EDITION MARK (①②③ ...)

When a manual is revised, an edition mark is recorded on the bottom outside corner of the pages.

### REVISIONS

Revised pages are shown at the LIST OF REVISED PAGES on the between the title page and SAFETY page.

### SYMBOLS


So that the shop manual can be of ample practical use, important places for safety and quality are marked with the following symbols.

Symbol	Item	Remarks
	Safety	Special safety precautions are necessary when performing the work.
		Extra special safety precautions are necessary when performing the work because it is under internal pressure.
	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing the work.
	Weight	Weight of parts or systems. Caution necessary when selecting hoisting wire, or when working posture is important, etc.
	Tightening torque	Places that require special attention for the tightening torque during assembly.
	Coat	Places to be coated with adhesives and lubricants etc.
	Oil, water	Places where oil, water or fuel must be added, and the capacity.
	Drain	Places where oil or water must be drained, and quantity to be drained.



# HOISTING INSTRUCTIONS



**⚠** Heavy parts (25 kg or more) must be lifted with a hoist etc. In the **Disassembly and Assembly** section, every part weighing 25 kg or more is indicated clearly with the symbol 

1. If a part cannot be smoothly removed from the machine by hoisting, the following checks should be made:
  - Check for removal of all bolts fastening the part to the relative parts.
  - Check for existence of another part causing interference with the part to be removed.

## 2. Wire ropes


- 1) Use adequate ropes depending on the weight of parts to be hoisted, referring to the table below:

Wire ropes (Standard "Z" or "S" twist ropes without galvanizing)	
Rope diameter (mm)	Allowable load (tons)
10	1.0
11.2	1.4
12.5	1.6
14	2.2
16	2.8
18	3.6
20	4.4
22.4	5.6
30	10.0
40	18.0
50	28.0
60	40.0

The allowable load value is estimated to be one-sixth or one-seventh of the breaking strength of the rope used.

- 2) Sling wire ropes from the middle portion of the hook.

Slings near the edge of the hook may cause the rope to slip off the hook during hoisting, and a serious accident can result. Hooks have maximum strength at the middle portion.



FS0064


- 3) Do not sling a heavy load with one rope alone, but sling with two or more ropes symmetrically wound on to the load.

**⚠** Slings with one rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can result in a dangerous accident.

- 4) Do not sling a heavy load with ropes forming a wide hanging angle from the hook.

When hoisting a load with two or more ropes, the force subjected to each rope will increase with the hanging angles. The table below shows the variation of allowable load (kg) when hoisting is made with two ropes, each of which is allowed to sling up to 1000 kg vertically, at various hanging angles.

When two ropes sling a load vertically, up to 2000 kg of total weight can be suspended. This weight becomes 1000 kg when two ropes make a 120° hanging angle. On the other hand, two ropes are subjected to an excessive force as large as 4000 kg if they sling a 2000 kg load at a lifting angle of 150°.



Lifting angle :  $\alpha$



FS0065



## STANDARD TIGHTENING TORQUE

### 1. STANDARD TIGHTENING TORQUE OF BOLTS AND NUTS

The following charts give the standard tightening torques of bolts and nuts. Exceptions are given in sections of "Disassembly and Assembly".

Thread diameter of bolt (mm)	Width across flat (mm)		
		kgm	Nm
6	10	1.35 ± 0.15	13.2 ± 1.4
8	13	3.2 ± 0.3	31.4 ± 2.9
10	17	6.7 ± 0.7	65.7 ± 6.8
12	19	11.5 ± 1.0	112 ± 9.8
14	22	18.0 ± 2.0	177 ± 19
16	24	28.5 ± 3	279 ± 29
18	27	39 ± 4	383 ± 39
20	30	56 ± 6	549 ± 58
22	32	76 ± 8	745 ± 78
24	36	94.5 ± 10	927 ± 98
27	41	135 ± 15	1320 ± 140
30	46	175 ± 20	1720 ± 190
33	50	225 ± 25	2210 ± 240
36	55	280 ± 30	2750 ± 290
39	60	335 ± 35	3280 ± 340

This torque table does not apply to the bolts with which nylon packings or other non-ferrous metal washers are to be used, or which require tightening to otherwise specified torque.

★ Nm (newton meter): 1Nm ≅ 0.1 kgm

### 2. TIGHTENING TORQUE OF SPLIT FLANGE BOLTS

Use these torques for split flange bolts.


Thread diameter of bolt (mm)	Width across flats (mm)	Tightening torque	
		kgm	Nm
10	14	6.7 ± 0.7	65.7 ± 6.8
12	17	11.5 ± 1	112 ± 9.8
16	22	28.5 ± 3	279 ± 29

## STANDARD TIGHTENING TORQUE



### 3. TIGHTENING TORQUE FOR NUTS OF FLARED

Use these torques for nut part of flared.



FS0068

Thread diameter of nut part (mm)	Width across flats of nut part (mm)	Tightening torque	
		kgm	Nm
14	19	2.5 ± 0.5	24.5 ± 4.9
18	24	5 ± 2	49 ± 19.6
22	27	8 ± 2	78.5 ± 19.6
24	32	14 ± 3	137.3 ± 29.4
30	36	18 ± 3	176.5 ± 29.4
33	41	20 ± 5	196.1 ± 49
36	46	25 ± 5	245.2 ± 49
42	55	30 ± 5	294.2 ± 49



## COATING MATERIALS

The recommended coating materials prescribed in Komatsu Shop Manuals are listed below.

Nomenclature	Komatsu code	Applications
Adhesives	LT-1A	Used to apply rubber pads, rubber gaskets, and cork plugs.
	LT-1B	Used to apply resin, rubber, metallic and non-metallic parts when a fast, strong seal is needed.
	LT-2*	Preventing bolts, nuts and plugs from loosening and leaking oil.
	LT-3	Provides an airtight, electrically insulating seal. Used for aluminum surfaces.
	LT-4	Used to coat plugs (plate shaped, bowl shaped) and holes, and mating portion of shaft.
Sealant gasket	LG-1	Used with gaskets and packings to increase sealing effect.
	LG-3	Heat-resistant gasket for precombustion chambers and exhaust piping.
	LG-4	Used by itself on mounting surfaces on the final drive and transmission cases. (Thickness after tightening: 0.07 – 0.08 mm)
	LG-5	Used by itself to seal grease fittings, tapered screw fittings and tapered screw fittings in hydraulic circuits of less than 50 mm in diameter.
	LG-6	Silicon base type used in combination with LG-1 and LG-4.
	LG-7	Has a shorter curing time than LG-6, and is easier to peel off.
Antifriction compound (Lubricant including molybdenum disulfide)	LM-P	Applied to bearings and taper shafts to facilitate press-fitting and to prevent sticking, burning or rusting.
Grease (Lithium grease)	G2-LI	Applied to bearings, sliding parts and oil seals for lubrication, rust prevention and facilitation of assembling work.
Vaseline	—	Used for protecting battery electrode terminals from corrosion.

\*LT-2 is also called LOCTITE in the shop manuals.



## ELECTRIC WIRE CODE

In the wiring diagrams, various colors and symbols are employed to indicate the thickness of wires. This wire code table will help you understand WIRING DIAGRAMS.  
 Example: 5WB indicates a cable having a nominal number 5 and white coating with black stripe.

### CLASSIFICATION BY THICKNESS

Nominal number	Copper wire			Cable O.D. (mm)	Current rating (A)	Applicable circuit
	Number strands	Dia. of strands (mm)	Cross section (mm <sup>2</sup> )			
0.85	11	0.32	0.88	2.4	12	Starting, lighting, signal etc.
2	26	0.32	2.09	3.1	20	Lighting, signal etc.
5	65	0.32	5.23	4.6	37	Charging and signal
15	84	0.45	13.36	7.0	59	Starting (Glow plug)
40	85	0.80	42.73	11.4	135	Starting
60	127	0.80	63.84	13.6	178	Starting
100	217	0.80	109.1	17.6	230	Starting

### CLASSIFICATION BY COLOR AND CODE

Priority	Circuits		Charging	Ground	Starting	Lighting	Instrument	Signal	Other
	Classification								
1	Primary	Code	W	B	B	R	Y	G	L
		Color	White	Black	Black	Red	Yellow	Green	Blue
2	Auxiliary	Code	WR	—	BW	RW	YR	GW	LW
		Color	White & Red	—	Black & White	Red & White	Yellow & Red	Green & White	Blue & White
Code		WB	—	BY	RB	YB	GR	LR	
Color		White & Black	—	Black & Yellow	Red & Black	Yellow & Black	Green & Red	Blue & Red	
Code		WL	—	BR	RY	YG	GY	LY	
Color		White & Blue	—	Black & Red	Red & Yellow	Yellow & Green	Green & Yellow	Blue & Yellow	
Code		WG	—	—	RG	YL	(GB)	(LB)	
Color		White & Green	—	—	Red & Green	Yellow & Blue	(Green & Black)	(Blue & Black)	
6	Code	—	—	—	RL	YW	(GL)	—	
	Color	—	—	—	Red & Blue	Yellow & White	(Green & Blue)	—	

## CONVERSION TABLE

### Method of using the Conversion Table

The Conversion Table in this section is provided to enable simple conversion of figures. For details of the method of using the Conversion Table, see the example given below.

### Example

- Method of using the Conversion Table to convert from millimeters to inches

1. Convert 55 mm into inches.

- Locate the number 50 in the vertical column at the left side, take this as (A), then draw a horizontal line from (A).
- Locate the number 5 in the row across the top, take this as (B), then draw a perpendicular line down from (B).
- Take the point where the two lines cross as (C). This point (C) gives the value when converting from millimeters to inches. Therefore, 55 mm = 2.165 inches.

2. Convert 550 mm into inches.

- The number 550 does not appear in the table, so divide by 10 (move the decimal point one place to the left) to convert it to 55 mm.
- Carry out the same procedure as above to convert 55 mm to 2.165 inches.
- The original value (550 mm) was divided by 10, so multiply 2.165 inches by 10 (move the decimal point one place to the right) to return to the original value. This gives 550 mm = 21.65 inches.

Millimeters to inches

(B)

1 mm = 0.03937 in

	0	1	2	3	4	5	6	7	8	9
0		0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
(A) 50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

**CONVERSION TABLE**

**Millimeters to Inches**

1 mm = 0.03937 in

	0	1	2	3	4	5	6	7	8	9
0		0.039	0.079	0.118	0.157	0.197	0.236	0.276	0.315	0.354
10	0.394	0.433	0.472	0.512	0.551	0.591	0.630	0.669	0.709	0.748
20	0.787	0.827	0.866	0.906	0.945	0.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.536
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.032	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

**Kilogram to Pound**

1 kg = 2.2046 lb

Kilogram	0	1	2	3	4	5	6	7	8	9
		2.20	4.41	6.61	8.82	11.02	13.23	15.43	17.64	19.84
10	22.05	24.25	26.46	28.66	30.86	33.07	35.27	37.48	39.68	41.89
20	44.09	46.30	48.50	50.71	51.91	55.12	57.32	59.53	61.73	63.93
30	66.14	68.34	70.55	72.75	74.96	77.16	79.37	81.57	83.78	85.98
40	88.18	90.39	92.59	94.80	97.00	99.21	101.41	103.62	105.82	108.03
50	110.23	112.44	114.64	116.85	119.05	121.25	123.46	125.66	127.87	130.07
60	132.28	134.48	136.69	138.89	141.10	143.30	145.51	147.71	149.91	152.12
70	154.32	156.53	158.73	160.94	163.14	165.35	167.55	169.76	171.96	174.17
80	176.37	178.57	180.78	182.98	185.19	187.39	189.60	191.80	194.01	196.21
90	198.42	200.62	202.83	205.03	207.24	209.44	211.64	213.85	216.05	218.26

**CONVERSION TABLE****Liter to U.S. Gallon**

1 ℓ = 0.2642 U.S. Gal

	0	1	2	3	4	5	6	7	8	9
		0.264	0.528	0.793	1.057	1.321	1.585	1.849	2.113	2.378
10	2.642	2.906	3.170	3.434	3.698	3.963	4.227	4.491	4.755	5.019
20	5.283	5.548	5.812	6.076	6.340	6.604	6.869	7.133	7.397	7.661
30	7.925	8.189	8.454	8.718	8.982	9.246	9.510	9.774	10.039	10.303
40	10.567	10.831	11.095	11.359	11.624	11.888	12.152	12.416	12.680	12.944
50	13.209	13.473	13.737	14.001	14.265	14.529	14.795	15.058	15.322	15.586
60	15.850	16.115	16.379	16.643	16.907	17.171	17.435	17.700	17.964	18.228
70	18.492	18.756	19.020	19.285	19.549	19.813	20.077	20.341	20.605	20.870
80	21.134	21.398	21.662	21.926	22.190	22.455	22.719	22.983	23.247	23.511
90	23.775	24.040	24.304	24.568	24.832	25.096	25.361	25.625	25.889	26.153

**Liter to U.K. Gallon**

1 ℓ = 0.21997 U.K. Gal

	0	1	2	3	4	5	6	7	8	9
		0.220	0.440	0.660	0.880	1.100	1.320	1.540	1.760	1.980
10	2.200	2.420	2.640	2.860	3.080	3.300	3.520	3.740	3.950	4.179
20	4.399	4.619	4.839	5.059	5.279	5.499	5.719	5.939	6.159	6.379
30	6.599	6.819	7.039	7.259	7.479	7.699	7.919	8.139	8.359	8.579
40	8.799	9.019	9.239	9.459	9.679	9.899	10.119	10.339	10.559	10.778
50	10.998	11.281	11.438	11.658	11.878	12.098	12.318	12.528	12.758	12.978
60	13.198	13.418	13.638	13.858	14.078	14.298	14.518	14.738	14.958	15.178
70	15.398	15.618	15.838	16.058	16.278	16.498	16.718	16.938	17.158	17.378
80	17.598	17.818	18.037	18.257	18.477	18.697	18.917	19.137	19.357	19.577
90	19.797	20.017	20.237	20.457	20.677	20.897	21.117	21.337	21.557	21.777

**CONVERSION TABLE**

**kgm to ft.lb**

1 kg.m = 7.233 ft.lb

	0	1	2	3	4	5	6	7	8	9
		7.2	14.5	21.7	28.9	36.2	43.4	50.6	57.9	65.1
10	72.3	79.6	86.8	94.0	101.3	108.5	115.7	123.0	130.2	137.4
20	144.7	151.9	159.1	166.4	173.6	180.8	188.1	195.3	202.5	209.8
30	217.0	224.2	231.5	238.7	245.9	253.2	260.4	267.6	274.9	282.1
40	289.3	296.6	303.8	311.0	318.3	325.5	332.7	340.0	347.2	354.4
50	361.7	368.9	376.1	383.4	390.6	397.8	405.1	412.3	419.5	426.8
60	434.0	441.2	448.5	455.7	462.9	470.2	477.4	484.6	491.8	499.1
70	506.3	513.5	520.8	528.0	535.2	542.5	549.7	556.9	564.2	571.4
80	578.6	585.9	593.1	600.3	607.6	614.8	622.0	629.3	636.5	643.7
90	651.0	658.2	665.4	672.7	679.9	687.1	694.4	701.6	708.8	716.1
100	723.3	730.5	737.8	745.0	752.2	759.5	766.7	773.9	781.2	788.4
110	795.6	802.9	810.1	817.3	824.6	831.8	839.0	846.3	853.5	860.7
120	868.0	875.2	882.4	889.7	896.9	904.1	911.4	918.6	925.8	933.1
130	940.3	947.5	954.8	962.0	969.2	976.5	983.7	990.9	998.2	1005.4
140	1012.6	1019.9	1027.1	1034.3	1041.5	1048.8	1056.0	1063.2	1070.5	1077.7
150	1084.9	1092.2	1099.4	1106.6	1113.9	1121.1	1128.3	1135.6	1142.8	1150.0
160	1157.3	1164.5	1171.7	1179.0	1186.2	1193.4	1200.7	1207.9	1215.1	1222.4
170	1129.6	1236.8	1244.1	1251.3	1258.5	1265.8	1273.0	1280.1	1287.5	1294.7
180	1301.9	1309.2	1316.4	1323.6	1330.9	1338.1	1345.3	1352.6	1359.8	1367.0
190	1374.3	1381.5	1388.7	1396.0	1403.2	1410.4	1417.7	1424.9	1432.1	1439.4



**CONVERSION TABLE**

kg/cm<sup>2</sup> to lb/in<sup>2</sup>

1 kg/cm<sup>2</sup> = 14.2233 lb/in<sup>2</sup>

	0	1	2	3	4	5	6	7	8	9
		14.2	28.4	42.7	56.9	71.1	85.3	99.6	113.8	128.0
10	142.2	156.5	170.7	184.9	199.1	213.4	227.6	241.8	256.0	270.2
20	284.5	298.7	312.9	327.1	341.4	355.6	369.8	384.0	398.3	412.5
30	426.7	440.9	455.1	469.4	483.6	497.8	512.0	526.3	540.5	554.7
40	568.9	583.2	597.4	611.6	625.8	640.1	654.3	668.5	682.7	696.9
50	711.2	725.4	739.6	753.8	768.1	782.3	796.5	810.7	825.0	839.2
60	853.4	867.6	881.8	896.1	910.3	924.5	938.7	953.0	967.2	981.4
70	995.6	1010	1024	1038	1053	1067	1081	1095	1109	1124
80	1138	1152	1166	1181	1195	1209	1223	1237	1252	1266
90	1280	1294	1309	1323	1337	1351	1365	1380	1394	1408
100	1422	1437	1451	1465	1479	1493	1508	1522	1536	1550
110	1565	1579	1593	1607	1621	1636	1650	1664	1678	1693
120	1707	1721	1735	1749	1764	1778	1792	1806	1821	1835
130	1849	1863	1877	1892	1906	1920	1934	1949	1963	1977
140	1991	2005	2020	2034	2048	2062	2077	2091	2105	2119
150	2134	2148	2162	2176	2190	2205	2219	2233	2247	2262
160	2276	2290	2304	2318	2333	2347	2361	2375	2389	2404
170	2418	2432	2446	2460	2475	2489	2503	2518	2532	2546
180	2560	2574	2589	2603	2617	2631	2646	2660	2674	2688
190	2702	2717	2731	2745	2759	2773	2788	2802	2816	2830
200	2845	2859	2873	2887	2901	2916	2930	2944	2958	2973
210	2987	3001	3015	3030	3044	3058	3072	3086	3101	3115
220	3129	3143	3158	3172	3186	3200	3214	3229	3243	3257
230	3271	3286	3300	3314	3328	3343	3357	3371	3385	3399
240	3414	3428	3442	3456	3470	3485	3499	3513	3527	3542

## CONVERSION TABLE

### Temperature

Fahrenheit-Centigrade Conversion. —A simple way to convert a Fahrenheit temperature reading into a Centigrade temperature reading or vice versa is to enter the accompanying table in the center or boldface column of figures.

These figures refer to the temperature in either Fahrenheit or Centigrade degrees.

If it is desired to convert from Fahrenheit to Centigrade degrees, consider the center column as a table of Fahrenheit temperatures and read the corresponding Centigrade temperature in the column at the left.

If it is desired to convert from Centigrade to Fahrenheit degrees, consider the center column as a table of Centigrade values, and read the corresponding Fahrenheit temperature on the right.


°C		°F	°C		°F	°C		°F	°C		°F
-40.4	-40	-40.0	-11.7	11	51.8	7.8	46	114.8	27.2	81	117.8
-37.2	-35	-31.0	-11.1	12	53.6	8.3	47	116.6	27.8	82	179.6
-34.4	-30	-22.0	-10.6	13	55.4	8.9	48	118.4	28.3	83	181.4
-31.7	-25	-13.0	-10.0	14	57.2	9.4	49	120.2	28.9	84	183.2
-28.9	-20	-4.0	-9.4	15	59.0	10.0	50	122.0	29.4	85	185.0
-28.3	-19	-2.2	-8.9	16	60.8	10.6	51	123.8	30.0	86	186.8
-27.8	-18	-0.4	-8.3	17	62.6	11.1	52	125.6	30.6	87	188.6
-27.2	-17	1.4	-7.8	18	64.4	11.7	53	127.4	31.1	88	190.4
-26.7	-16	3.2	-7.2	19	66.2	12.2	54	129.2	31.7	89	192.2
-26.1	-15	5.0	-6.7	20	68.0	12.8	55	131.0	32.2	90	194.0
-25.6	-14	6.8	-6.1	21	69.8	13.3	56	132.8	32.8	91	195.8
-25.0	-13	8.6	-5.6	22	71.6	13.9	57	134.6	33.3	92	197.6
-24.4	-12	10.4	-5.0	23	73.4	14.4	58	136.4	33.9	93	199.4
-23.9	-11	12.2	-4.4	24	75.2	15.0	59	138.2	34.4	94	201.2
-23.3	-10	14.0	-3.9	25	77.0	15.6	60	140.0	35.0	95	203.0
-22.8	-9	15.8	-3.3	26	78.8	16.1	61	141.8	35.6	96	204.8
-22.2	-8	17.6	-2.8	27	80.6	16.7	62	143.6	36.1	97	206.6
-21.7	-7	19.4	-2.2	28	82.4	17.2	63	145.4	36.7	98	208.4
-21.1	-6	21.2	-1.7	29	84.2	17.8	64	147.2	37.2	99	210.2
-20.6	-5	23.0	-1.1	30	86.0	18.3	65	149.0	37.8	100	212.0
-20.0	-4	24.8	-0.6	31	87.8	18.9	66	150.8	40.6	105	221.0
-19.4	-3	26.6	0	32	89.6	19.4	67	152.6	43.3	110	230.0
-18.9	-2	28.4	0.6	33	91.4	20.0	68	154.4	46.1	115	239.0
-18.3	-1	30.2	1.1	34	93.2	20.6	69	156.2	48.9	120	248.0
-17.8	0	32.0	1.7	35	95.0	21.1	70	158.0	51.7	125	257.0
-17.2	1	33.8	2.2	36	96.8	21.7	71	159.8	54.4	130	266.0
-16.7	2	35.6	2.8	37	98.6	22.2	72	161.6	57.2	135	275.0
-16.1	3	37.4	3.3	38	100.4	22.8	73	163.4	60.0	140	284.0
-15.6	4	39.2	3.9	39	102.2	23.3	74	165.2	62.7	145	293.0
-15.0	5	41.0	4.4	40	104.0	23.9	75	167.0	65.6	150	302.0
-14.4	6	42.8	5.0	41	105.8	24.4	76	168.8	68.3	155	311.0
-13.9	7	44.6	5.6	42	107.6	25.0	77	170.6	71.1	160	320.0
-13.3	8	46.4	6.1	43	109.4	25.6	78	172.4	73.9	165	329.0
-12.8	9	48.2	6.7	44	111.2	26.1	79	174.2	76.7	170	338.0
-12.2	10	50.0	7.2	45	113.0	26.7	80	176.0	79.4	175	347.0

---

# ENGINE

## 01 GENERAL


---



GENERAL VIEW .....	01-002
SPECIFICATIONS .....	01-004
ASSEMBLY DRAWING .....	01-012
WEIGHT TABLE .....	01-024
PERFORMANCE CURVE .....	01-025


# GENERAL VIEW

## 6D105-1 (For W70)



1. Fuel filter
2. Fuel injection pump
3. Oil filter
4. Thermostat housing
5. Water pump
6. Air compressor


6136P001



7. Alternator
8. Vibration damper
9. Crank case breather
10. Oil filler
11. Starting motor
12. Oil level gauge


6136P002

S6D105-1 (For W90-2)



- 1. Fuel filter
- 2. Fuel injection pump
- 3. Oil filter
- 4. Thermostat housing
- 5. Water pump
- 6. Air compressor

6137P001



- 7. Alternator
- 8. Vibration damper
- 9. Turbocharger
- 10. Crankcase breather
- 11. Oil filler
- 12. Stating motor
- 13. Oil level gauge

6137P002

# SPECIFICATIONS

Engine model		6D105-1A	6D105-1C	6D105-1D
Mounted machine		W70	EG75-2	EG75S-2
No. of cylinders – Bore x Stroke (mm)		6–105 x 125		
Piston displacement (cc)		6,490		
Firing order		1–5–3–6–2–4		
DIMENSIONS	Overall length (Fan to flywheel housing) (mm)	1,256	1,276	1,255
	Overall width (mm)	730	762	762
	Overall height (Muffler to oil pan) (mm)	1,190	1,237.5	1,115
PERFORMANCE	Flywheel horsepower (HP/rpm)	102/2,500	81/1,500 (50 Hz) 94/1,800 (60 Hz)	
	Max. torque (kgm/rpm)	36/1,600	–	
	High idling speed (rpm)	2,700 – 2,800	Max. 1,560 (50 Hz) Max. 1,872 (60 Hz)	
	Low idling speed (rpm)	650 – 750	–	
	Min. fuel consumption ratio (g/HP.h)	165	175 (rated)	
Dry weight (kg)		530	600	
Fuel		ASTM D975 No. 1 and No. 2		
Fuel pump		Bosch type PE-A		
Governor		Bosch RSV centrifugal, all speed type		
Oil capacity (ℓ)		24	24	
Coolant capacity (ℓ)		35	24.5	
Alternator		24V, 25A		
Starting motor		24V, 5.5 KW		
Battery		24V (12V x 2)-150Ah		
Turbocharger		–	–	–

6D105-1	6D105-1	6D105-1	6D105-1	6D105-1	6D105-1
EG80-1	EG80S-1	D40A,P-3 (Engine No. 10001-49999)	D40A,P-3 (Engine No. 50001-)	D41A,E,P-3 (Engine No. 10001-49999)	D41A,E,P-3 (Engine No. 50001-)

6 – 105 x 125

6,490

1-5-3-6-2-4

1,362 601 1,254	1,374 601 1,162	1,342 780 1,247		1,342 780 1,247	
88/1,500 (50Hz) 100/1,800 (60Hz) - Max. 1,560 (50Hz) Max. 1,872 (60Hz) - 175 (rated)	90/2,350 37/1,300 2,520 – 2,620 700 – 750 175	90/2,350 37/1,300 2,520 – 2,620 700 – 750 170		90/2,350 40/1,500 2,620 – 2,720 700 – 750 175	90/2,350 40/1,500 2,620 – 2,720 700 – 750 170
600	590	640	620	640	620

ASTM D975 No. 1 and No. 2

Bosch type PE-A

Bosch RSV centrifugal, all speed type

24	24 (23)
29	35
24V, 25A 24V, 5.5KW 24V (12V x 2) – 110Ah	24V, 25A 24V, 5.5KW 24V (12V x 2) – 120Ah
-	-

**GENERAL**

**SPECIFICATIONS**

Engine model		6D105-1	6D105-1	6D105-1
Mounted machine		D41S, Q-3 (Engine No. 10001-49999)	D41S, Q-3 (Engine No. 50001-)	W70-2 W70-3
No. of cylinders – Bore x Stroke (mm)		6 – 105 x 125		
Piston displacement (cc)		6,490		
Firing order		1-5-3-6-2-4		
DIMENSIONS	Overall length (Fan to flywheel housing) (mm)	1,332		1,218
	Overall width (mm)	784		707
	Overall height (Muffler to oil pan) (mm)	1,247		1,020
PERFORMANCE	Flywheel horsepower (HP/rpm)	90/2,350	90/2,350	107/2,500
	Max. torque (kgm/rpm)	40/1,500	40/1,500	39.5/1,600
	High idling speed (rpm)	2,620 – 2,720	2,620 – 2,720	2,700 – 2,800
	Low idling speed (rpm)	700 – 750	700 – 750	700 – 750
	Min. fuel consumption ratio (g/HP.h)	175	170	175
Dry weight (kg)		640	620	530
Fuel		ASTM D975 No. 1 and No. 2		
Fuel pump		Bosch type PE-A		
Governor		Bosch RSV centrifugal, all speed type		
Oil capacity (ℓ)		24 (23)		
Coolant capacity (ℓ)		35		
Alternator		24V, 25A		
Starting motor		24V, 5.5KW		
Battery		24V (12V x 2) – 140AH		
Turbocharger		–	–	–
Air compressor		–	–	–



6D105-1	6D105-1	6D105-1	6D105-1	6D105-1	6D105-1
GD405A-1	PC150-1 PC150LC-1	PC200-1	PC200-2 PC200LC-2	W60 W60-2	WA200-1

6 – 105 x 125

6,490

1-5-3-6-2-4

1,228	1,348	1,291	1,392	1,218	1,266
706	874	723	874	735	792
1,081	1,155	1,182	1,219	1,202	1,236 (air cleaner to oil pan)
112/2,500	85/1,900	105/2,350	105/2,150	95/2,500	108/2,400
39/1,500	40/1,400	40.5/1,600	43/1,600	35/1,600	40/1,600
2,700 – 2,800	2,050 – 2,150	2,500 – 2,600	2,300 – 2,400	2,650 – 2,750	2,590 – 2,690
700 – 750	750 – 850	800 – 850	800 – 900	700 – 750	700 – 750
170	165	175	170	175	175
530	600	620	600	560	611

ASTM D975 No. 1 and No. 2

Bosch type PE-A

Bosch RSV centrifugal, all speed type

24  
(23)

35	32	35	24	33	38
24V, 25A 24V, 5.5KW 24V (12V x 2) – 120Ah	24V, 25A 24V, 7.5KW 24V (12V x 2) – 150Ah			24V, 25A 24V, 5.5KW 24V (12V x 2) – 140Ah	24V, 25A 24V, 5.5KW 24V (12V x 2) – 140Ah
–	–	–	–	–	–
–	–	DIESEL KIKI	–	–	–

**Thanks for your reading.**

**Please click here to download complete manual instantly.**

**And can also choose other manuals.**

**Feel free --->write to me with any questions.**

**Our service email:**

**manuals007@hotmail.com**