

Technical Manual

Operational Principle

ZW

310-5B

330-5B

Wheel Loader

ZW310-5B • 330-5B WHEEL LOADER TECHNICAL MANUAL OPERATIONAL PRINCIPLE

 **Hitachi Construction Machinery Co., Ltd.**

URL:<http://www.hitachi-c-m.com>

Service Manual consists of the following separate Part No.
Technical Manual (Operational Principle) : Vol. No.TONFA-EN
Technical Manual (Troubleshooting) : Vol. No.TTNFA-EN
Workshop Manual : Vol. No.WNFA-EN
Engine Manual : Vol. No.ENFA-EN

INTRODUCTION

To The Reader

This manual is written for an experienced technician to provide technical information needed to maintain and repair this machine.

- Be sure to thoroughly read this manual for correct product information and service procedures.

- If you have any questions or comments, at if you found any errors regarding the contents of this manual, please contact using "Service Manual Revision Request Form" at the end of this manual. (Note: Do not tear off the form. Copy it for usage.):
 - Publications Marketing & Product Support Hitachi Construction Machinery Co. Ltd.
 - TEL: 81-29-832-7084
 - FAX: 81-29-831-1162
 - E-mail: dc@hitachi-kenki.com

Additional References

Please refer to the other materials (operator's manual, parts catalog, engine technical material and Hitachi training material etc.) in addition to this manual.

Manual Composition

This manual consists the Technical Manual, the Workshop Manual and the Engine Manual.

- Information included in the Technical Manual: Technical information needed for redelivery and delivery, operation and activation of all devices and systems, operational performance tests, and troubleshooting procedures.

- Information included in the Workshop Manual: Technical information needed for maintenance and repair of the machine, tools and devices needed for maintenance and repair, maintenance standards, and removal / installation and assemble / disassemble procedures.

- Information included in the Engine Manual: Technical information needed for redelivery and delivery and maintenance and repair of the machine, operation and activation of all devices and systems, troubleshooting and assemble / disassemble procedures.

Page Number

Each page has a number, located on the center lower part of the page, and each number contains the following information:

Example:

- Technical Manual: T 1-3-5

T	Technical Manual
1	Section Number
3	Group Number
5	Consecutive Page Number for Each Group


- Workshop Manual: W 1-3-2-5


W	Workshop Manual
1	Section Number
3	Group Number
2	Sub Group Number
5	Consecutive Page Number for Each Group

INTRODUCTION


Safety Alert Symbol and Headline Notations

In this manual, the following safety alert symbol and signal words are used to alert the reader to the potential for personal injury of machine damage.

 This is the safety alert symbol. When you see this symbol, be alert to the potential for personal injury. Never fail to follow the safety instructions prescribed along with the safety alert symbol. The safety alert symbol is also used to draw attention to component/part weights. To avoid injury and damage, be sure to use appropriate lifting techniques and equipment when lifting heavy parts.

 **CAUTION:**
Indicated potentially hazardous situation which could, if not avoided, result in personal injury or death.

IMPORTANT:
Indicates a situation which, if not conformed to the instructions, could result in damage to the machine.

 **NOTE:**
Indicates supplementary technical information or know-how.


Units Used

SI Units (International System of Units) are used in this manual. MKSA system units and English units are also indicated in parentheses just behind SI units.

Example: 24.5 MPa (250 kgf/cm², 3560 psi)

A table for conversion from SI units to other system units is shown below for reference purposes.

Quantity	To Convert From	Into	Multiply By
Length	mm	in	0.03937
	mm	ft	0.003281
Volume	L	US gal	0.2642
	L	US qt	1.057
	m ³	yd ³	1.308
Weight	kg	lb	2.205
Force	N	kgf	0.10197
	N	lbf	0.2248
Torque	N·m	kgf·m	0.10197
Pressure	MPa	kgf/cm ²	10.197
	MPa	psi	145.0
Power	kW	PS	1.360
	kW	HP	1.341
Temperature	°C	°F	°C×1.8+32
Velocity	km/h	mph	0.6214
	min ⁻¹	rpm	1.0
Flow rate	L/min	US gpm	0.2642
	mL/rev	cc/rev	1.0

 **NOTE:** The numerical value in this manual might be different from the above-mentioned table.

Symbol and Abbreviation

Symbol and Abbreviation

Symbol / Abbreviation	Name	Explanation
TO	Technical manual (Operational principle)	Technical manual (Operational Principle).
TT	Technical manual (Troubleshooting)	Technical manual (Troubleshooting).
W, W/M	Workshop manual	Workshop manual (Removal and Installation, Disassembly and Assembly).
MC	Main Controller	Main controller. MC controls the engine, pump, and valve according to the machine operating condition.
ECM	Engine Control Module	Engine controller. ECM controls fuel injection amount according to the machine operating condition.
CAN	Controller Area Network	CAN communication. CAN is a serial communications protocol internationally-standardized by ISO (International Organization for Standardization).
A/C	Air Conditioner	Air conditioner.
OPT	Option	Optional component.
MPDr.	Maintenance Pro Dr.	MPDr. is software that troubleshooting, monitoring, and adjustment.
ATT	Attachment	Attachment.

Symbol and Abbreviation

Symbol / Abbreviation	Name	Explanation
DPF	Diesel Particulate Filter	DPF is a filter which removes particulate matter (PM) including the toxic substance of exhaust gas of the diesel engine. Exhaust particulate removal equipment.
DOC	Diesel Oxidation Catalyst	Oxidation catalyst for the diesel engine. Diesel oxidation catalyst oxidizes unburnt fuel and raises exhaust temperature.
CSF	Catalyzed Soot Filter	Filter. The filter traps, burns, and remove particulate matter (PM) by using high-temperature-exhaust gas with diesel oxidation catalyst. Catalyst is applied onto the filter. This advances PM burning.
PM	Particulate Matter	Particulate matter.
EGR	Exhaust Gas Recirculation	The EGR control re-circulates a part of exhaust gas in the intake manifold and combines it with intake-air. Therefore, combustion temperature is lowered and generation of oxide of nitrogen (NOx) is controlled.

SECTION AND GROUP CONTENTS

TECHNICAL MANUAL

(Operational Principle)

SECTION 1 GENERAL

Group 1 Specifications

Group 2 Component Layout

Group 3 Component Specifications

SECTION 2 SYSTEM

Group 1 Controller

Group 2 Control System

Group 3 ECM System

Group 4 Hydraulic System

Group 5 Electrical System

SECTION 3 COMPONENT OPERATION

Group 1 Pump Device

Group 2 Control Valve

Group 3 Cooling Fan System

Group 4 Steering Pilot Valve

Group 5 Steering Valve

Group 6 Pilot Valve

Group 7 Charging Circuit

Group 8 Drive Unit

Group 9 Axle

Group 10 Brake Valve

Group 11 Others

All information, illustrations and specifications in this manual are based on the latest product information available at the time of publication. The right is reserved to make changes at any time without notice.

TECHNICAL MANUAL (Troubleshooting)

SECTION 4 OPERATIONAL PERFORMANCE TEST

Group 1 Introduction

Group 2 Standard

Group 3 Engine Test

Group 4 Machine Performance Test

Group 5 Component Test

SECTION 5 TROUBLESHOOTING

Group 1 Diagnosing Procedure

Group 2 Monitor

Group 3 e-Service

Group 4 Component Layout

Group 5 Troubleshooting A

Group 6 Troubleshooting B

Group 7 Air Conditioner

SECTION 1

GENERAL

CONTENTS

Group 1 Specifications

Specifications	T1-1-1
----------------------	--------

Group 2 Component Layout

Main Component (ZW310-5B)	T1-2-1
Main Component (ZW310-5B)	T1-2-2
Main Component (ZW310-5B)	T1-2-3
Main Component (Overview)	T1-2-4
Main Component (ZW330-5B)	T1-2-5
Main Component (ZW330-5B)	T1-2-6
Electric Component Layout (Overview).....	T1-2-7
Electrical System (Cab).....	T1-2-8
Engine	T1-2-16
Hydraulic Pump.....	T1-2-18
Transmission and Torque Converter Assembly	T1-2-19
Control Valve.....	T1-2-20
Unloader Valve (Brake Charge Valve).....	T1-2-21
Steering Valve.....	T1-2-21
Combination Valve	T1-2-21
Flow Regulator Valve	T1-2-22
Emergency Steering Pump	T1-2-22
Ride Control Valve.....	T1-2-22

Group 3 Component Specifications

Engine	T1-3-1
Engine Accessories	T1-3-4
Hydraulic Component.....	T1-3-6
Electrical Component.....	T1-3-11

(Blank)

Thanks for your reading.

Please click here to download complete manual instantly.

And can also choose other manuals.

Feel free --->write to me with any questions.

Our service email:

manuals007@hotmail.com