


**QUICK REFERENCE INDEX**

**NISSAN**  
**370Z**  
**MODEL Z34 SERIES**

<b>A GENERAL INFORMATION</b>	<b>GI General Information</b>
<b>B ENGINE</b>	<b>EM Engine Mechanical</b>
	<b>LU Engine Lubrication System</b>
	<b>CO Engine Cooling System</b>
	<b>EC Engine Control System</b>
	<b>FL Fuel System</b>
	<b>EX Exhaust System</b>
	<b>STR Starting System</b>
<b>ACC Accelerator Control System</b>	
<b>C ELECTRIC POWER TRAIN</b>	
<b>D TRANSMISSION &amp; DRIVELINE</b>	<b>CL Clutch</b>
	<b>TM Transaxle &amp; Transmission</b>
	<b>DLN Driveline</b>
	<b>FAX Front Axle</b>
<b>E SUSPENSION</b>	<b>RAX Rear Axle</b>
	<b>FSU Front Suspension</b>
	<b>RSU Rear Suspension</b>
<b>F BRAKES</b>	<b>WT Road Wheels &amp; Tires</b>
	<b>BR Brake System</b>
<b>G STEERING</b>	<b>PB Parking Brake System</b>
	<b>BRC Brake Control System</b>
	<b>ST Steering System</b>
<b>H RESTRAINTS</b>	<b>STC Steering Control System</b>
	<b>SB Seat Belt</b>
	<b>SBC Seat Belt Control System</b>
	<b>SR SRS Airbag</b>
<b>I VENTILATION, HEATER &amp; AIR CONDITIONER</b>	<b>SRC SRS Airbag Control System</b>
	<b>VTL Ventilation System</b>
	<b>HA Heater &amp; Air Conditioning System</b>
<b>J BODY INTERIOR</b>	<b>HAC Heater &amp; Air Conditioning Control System</b>
	<b>INT Interior</b>
	<b>IP Instrument Panel</b>
<b>K BODY EXTERIOR, DOORS, ROOF &amp; VEHICLE SECURITY</b>	<b>SE Seat</b>
	<b>DLK Door &amp; Lock</b>
	<b>SEC Security Control System</b>
	<b>GW Glass &amp; Window System</b>
	<b>PWC Power Window Control System</b>
	<b>RF Roof</b>
<b>L DRIVER CONTROLS</b>	<b>EXT Exterior</b>
	<b>BRM Body Repair</b>
	<b>MIR Mirrors</b>
	<b>EXL Exterior Lighting System</b>
	<b>INL Interior Lighting System</b>
	<b>WW Wiper &amp; Washer</b>
	<b>DEF Defogger</b>
<b>HRN Horn</b>	
<b>M ELECTRICAL &amp; POWER CONTROL</b>	<b>PWO Power Outlet</b>
	<b>BCS Body Control System</b>
	<b>LAN LAN System</b>
	<b>PCS Power Control System</b>
	<b>CHG Charging System</b>
	<b>PG Power Supply, Ground &amp; Circuit Elements</b>
<b>N DRIVER INFORMATION &amp; MULTIMEDIA</b>	<b>MWI Meter, Warning Lamp &amp; Indicator</b>
	<b>WCS Warning Chime System</b>
<b>O CRUISE CONTROL &amp; DRIVER ASSISTANCE</b>	<b>AV Audio, Visual &amp; Navigation System</b>
	<b>CCS Cruise Control System</b>
<b>P MAINTENANCE</b>	<b>MA Maintenance</b>

© 2011 NISSAN MOTOR CO.,LTD.

All rights reserved. No part of this Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, recording or otherwise, without the prior written permission of NISSAN MOTOR CO., LTD.



# FOREWORD

---

This manual contains maintenance and repair procedure for the 2012 NISSAN 370Z.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

## IMPORTANT SAFETY NOTICE

---

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately. Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.

**NISSAN MOTOR CO., LTD.**



## PLEASE HELP MAKE THIS SERVICE MANUAL BETTER!

Your comments are important to NISSAN and will help us to improve our Service Manuals. Use this form to report any issues or comments you may have regarding our Service Manuals. Please print this form and type or write your comments below. Mail or fax to:

Nissan North America, Inc.  
Technical Service Information  
39001 Sunrise Drive, P.O. Box 9200  
Farmington Hills, MI USA 48331  
FAX: (248) 488-3880

**SERVICE MANUAL: Model:** \_\_\_\_\_ **Year:** \_\_\_\_\_

**PUBLICATION NO. (Refer to Quick Reference Index):** \_\_\_\_\_

Please describe any Service Manual issues or problems in detail:

Page number(s) \_\_\_\_\_ *Note: Please include a copy of each page, marked with your comments.*

---

---

---

---

---

---

---

---

**Are the trouble diagnosis procedures logical and easy to use? (circle your answer) YES NO**

If no, what page number(s)? \_\_\_\_\_ *Note: Please include a copy of each page, marked with your comments.*

Please describe the issue or problem in detail: \_\_\_\_\_

---

---

---

**Is the organization of the manual clear and easy to follow? (circle your answer) YES NO**

Please comment: \_\_\_\_\_

---

---

---

---

**What information should be included in NISSAN Service Manuals to better support you in servicing or repairing customer vehicles?**

---

---

---

---

DATE: \_\_\_\_\_ YOUR NAME: \_\_\_\_\_ POSITION: \_\_\_\_\_

DEALER: \_\_\_\_\_ DEALER NO.: \_\_\_\_\_ ADDRESS: \_\_\_\_\_

CITY: \_\_\_\_\_ STATE/PROV./COUNTRY: \_\_\_\_\_ ZIP/POSTAL CODE: \_\_\_\_\_

**QUICK REFERENCE CHART 370Z**  
**ENGINE TUNE-UP DATA (VQ37VHR)**

PFP:00000

ELS0003W

Engine model		VQ37VHR
Firing order		1-2-3-4-5-6
Idle speed A/T (In "P or N" position) M/T (In Neutral position)	rpm	650 ± 50
Ignition timing (BTDC at idle speed)		10° ± 5°
Tensions of drive belt		Auto adjustment by auto tensioner
Radiator cap relief pressure	kPa (kg/cm <sup>2</sup> , psi)	
Standard		78.2 - 97.8 (0.8 - 1.0, 11 - 14)
Limit		59 (0.6, 9)
Cooling system leakage testing pressure	kPa (kg/cm <sup>2</sup> , psi)	157 (1.6, 23)
Compression pressure	kPa (kg/cm <sup>2</sup> , psi)/200 rpm	
Standard		1,667 - 2,354 (17 - 24, 242 - 341)
Minimum		1,226 (12.5, 178)
Differential limit between cylinders		98 (1.0, 14)
Spark plug (Iridium-tipped type)		
Make		DENSO
Standard type		FXE24HR11
Gap (Nominal)	mm (in)	1.1 (0.043)

**FRONT WHEEL ALIGNMENT**

ELS0003X

Camber Degree minute (Decimal degree)	Minimum	-1° 25' (-1.41°)	
	Nominal	-0° 40' (-0.67°)	
	Maximum	0° 05' (0.08°)	
	Left and right difference	0° 33' (0.55°) or less	
Caster Degree minute (Decimal degree)	Minimum	4° 25' (4.42°)	
	Nominal	5° 10' (5.17°)	
	Maximum	5° 55' (5.91°)	
	Left and right difference	0° 39' (0.65°) or less	
Kingpin inclination Degree minute (Decimal degree)	Minimum	6° 55' (6.92°)	
	Nominal	7° 40' (7.67°)	
	Maximum	8° 25' (8.41°)	
Toe-in	Total toe-in Distance	Minimum	In 1 mm (0.04 in)
		Nominal	In 2 mm (0.08 in)
		Maximum	In 3 mm (0.11 in)
	Toe angle (Left wheel or right wheel) Degree minute (Decimal degree)	Minimum	In 0° 03' (0.05°)
		Nominal	In 0° 05' (0.08°)
		Maximum	In 0° 07' (0.11°)

Measure value under unladen\* conditions.

\*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

**REAR WHEEL ALIGNMENT**

ELS0003Y

Wheel size		18 inch	19 inch
Camber Degree minute (Decimal degree)	Minimum	-2° 10' (-2.16°)	
	Nominal	-1° 40' (-1.67°)	
	Maximum	-1° 10' (-1.17°)	
Toe-in	Total toe-in Distance	Minimum	In 2.0 mm (0.079 in)
		Nominal	In 3.8 mm (0.150 in)
		Maximum	In 5.6 mm (0.221 in)
	Toe angle (Left wheel or right wheel) Degree minute (Decimal degree)	Minimum	In 0° 05' (0.09°)
		Nominal	In 0° 09' (0.15°)
		Maximum	In 0° 13' (0.21°)

Measure value under unladen\* conditions.

\*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

**BRAKE PEDAL**

Unit : mm (in.)

Brake pedal height (H1)	171.5 - 181.5 (6.75 - 7.15)
Depressed brake pedal height (H2) [Depressing 490 N (50 kg, 110 lb) while turning the engine ON]	124.0 (4.88) or more

**FRONT DISC BRAKE**

**2 Piston Type**

Unit : mm (in.)

Brake pad	Wear limit thickness	2.0 (0.079)
Disc rotor	Wear limit thickness	26.0 (1.024)

**4 Piston Type**

Unit : mm (in.)

Brake pad	Wear limit thickness	2.0 (0.079)
Disc rotor	Wear limit thickness	30.0 (1.181)

**REAR DISC BRAKE**

**1 Piston Type**

Unit : mm (in.)

Brake pad	Wear limit thickness	2.0 (0.079)
Disc rotor	Wear limit thickness	14.0 (0.551)

**2 Piston Type**

Unit : mm (in.)

Brake pad	Wear limit thickness	2.0 (0.079)
Disc rotor	Wear limit thickness	18.0 (0.709)

**REFILL CAPACITIES**

ELS00040

UNIT		Liter	US measure	Imp measure
Fuel tank		71.9	19 gal	15-7/8 gal
Engine Coolant (With reservoir tank) at MAX level	A/T models	8.5	9 qt	7-1/2 qt
	M/T models	8.6	9-1/8 qt	7-5/8 qt
Engine oil	Drain and refill			
	With oil filter change	4.9	5-1/8 qt	4-1/4 qt
	Without oil filter change	4.6	4-7/8 qt	4 qt
	Dry engine (Overhaul)	5.7	6 qt	5 qt
Transmission	A/T	9.2	9-3/4 qt	8-1/8 qt
	M/T	2.83	6 pt	5 pt
Final drive	Rear	1.4	3 pt	2-1/2 pt
Power steering system		1.0	1-1/8 qt	7/8 qt
Air conditioning system	Compressor oil	0.15	5.07 fl oz	5.3 fl oz
	Refrigerant	0.5 kg	1.1 lb	1.1 lb

**Thanks for your reading.**

**Please click here to download complete manual instantly.**

**And can also choose other manuals.**

**Feel free --->write to me with any questions.**

**Our service email:**

**manuals007@hotmail.com**