

SERVICE/MAINTENANCE MANUAL

This manual has been prepared for and is considered part of -

10000A-1

Model Number

XXXXXRef

Serial Number

This Manual is Divided into the following Sections:

	SAFETY SECTION
SECTION 1	REFERENCE MATERIALS
SECTION 2	TEST PROCEDURES
SECTION 3	GENERAL
SECTION 4	POWER TRAIN
SECTION 5	HYDRAULIC SYSTEM
SECTION 6	HOIST SYSTEM
SECTION 7	BOOM HOIST SYSTEM
SECTION 8	SWING SYSTEM
SECTION 9	TRAVEL SYSTEM
SECTION 10	ELECTRICAL SYSTEM
SECTION 11	AIR CONDITIONER
SECTION 12	TRANSLIFTER SYSTEM
SECTION 13	TROUBLESHOOTING

NOTICE

The serial number of the crane is the only method the Manitowoc Crane Care Lattice Team has of providing you with correct parts and service information.

Always furnish serial number of crane and its attachments when ordering parts or discussing service problems with your Manitowoc distributor or the Manitowoc Crane Care Lattice Team.



WARNING

To prevent death or serious injury:

- Avoid unsafe operation and maintenance.
Crane and attachments must be operated and maintained by trained and experienced personnel. Manitowoc is not responsible for qualifying these personnel.
- Do not operate or work on crane or attachments without first reading and understanding instructions contained in Operator Information Manual and Service Manual supplied with crane and applicable attachments.
- Store Operator Information Manual and Service Manual in operator's cab.

If Operator Information Manual or Service Manual is missing from cab, contact your Manitowoc distributor for a new one.

THE ORIGINAL LANGUAGE OF THIS PUBLICATION IS ENGLISH

	TABLE OF CONTENTS	
	SAFETY	
1.	REFERENCE MATERIALS	1
2.	MAINTENANCE STANDARDS TEST PROCEDURES	2
3.	GENERAL WORK STANDARD	3
4.	POWER TRAIN	4
5.	HYDRAULIC SYSTEM	5
6.	HOIST SYSTEM	6
7.	BOOM HOIST SYSTEM	7
8.	SWING SYSTEM	8
9.	TRAVEL SYSTEM	9
10.	ELECTRIC SYSTEM	10
11.	AIR CONDITIONER	11
12.	TRANSLIFTER SYSTEM	12
13.	TROUBLESHOOTING	13

Reference Only

SAFETY

1. REFERENCE MATERIALS

1.1	11000-1 SPECIFICATION.....	1-1
1.1.1	CRANE OUTSIDE DIMENSION.....	1-1
1.1.2	CRANE SPECIFICATION, PERFORMANCE.....	1-2
1.1.3	CRANE WORKING RANGES.....	1-4
1.2	11000-1 DIMENSION, WEIGHT OF EACH COMPONENT.....	1-7
1.2.1	BASE MACHINE.....	1-7
1.2.2	COUNTERWEIGHT WITH SELF REMOVAL DEVICE.....	1-9
1.2.3	ATTACHMENT.....	1-10
1.3	11000-1 CLAMSHELL RATED LOADS (OPTION).....	1-12
1.4	11000-1 SWING AND TRAVEL STABILITY.....	1-16
1.5	11000-1 TRAVEL ALLOWABLE SLOPE ANGLE.....	1-19
1.5.1	CRANE ATTACHMENT INSTALLED : BOOM INSERT CONFIGURATION.....	1-19
1.6	ENGINE MAIN SPECIFICATION.....	1-25

2. MAINTENANCE STANDARDS TEST PROCEDURES

2.1	MAINTENANCE STANDARD.....	2-1
2.1.1	PIN, BUSHING, SPRING, LINING AND SHEAVE.....	2-1
2.1.2	TRAVEL DEVICE.....	2-8
2.2	PERFORMANCE STANDARD AND TEST PROCEDURE.....	2-15
2.2.1	OPERATING SPEED.....	2-17
2.2.2	HYDRAULIC PRESSURE.....	2-18
2.2.3	SWING BEARING.....	2-22

3. GENERAL WORK STANDARD

3.1	STANDARD TIGHTENING TORQUE	3-1
3.1.1	TIGHTENING TORQUE OF CAP SCREWS AND NUTS	3-1
3.1.2	TIGHTENING TORQUE OF HYDRAULIC FITTINGS.....	3-5
3.2	STANDARD PARTS	3-7
3.2.1	BOLT	3-7
3.2.2	O-RING	3-8
3.2.3	BACK-UP RING	3-9
3.2.4	BITE TYPE FITTING	3-10
3.3	CONVERSION TABLE.....	3-12
3.3.1	UNIT CONVERSION.....	3-12
3.3.2	MILLIMETER : INCH CONVERSION TABLE	3-13
3.3.3	METER AND FOOT CONVERSION TABLE	3-15
3.3.4	GRADE CONVERSION TABLE	3-16
3.3.5	UNIT WEIGHT TABLE	3-17
3.3.6	SYSTEM INTERNATIONAL (SI) UNIT CONVERSION TABLE	3-18

4. POWER TRAIN

4.1	APPARATUS AND COMPONENTS LOCATION	4-3
4.2	ENGINE.....	4-6
4.2.1	REMOVAL OF THE ENGINE.....	4-6
4.2.2	REPAIR AND MAINTENANCE OF THE ENGINE.....	4-9
4.2.3	INSTALLATION OF THE ENGINE	4-10
4.3	PUMP DRIVE ASSEMBLY	4-14
4.3.1	CONSTRUCTION OF THE POWER DIVIDER.....	4-15
4.3.2	CONSTRUCTION OF THE COUPLING.....	4-20
4.3.3	REMOVAL OF EACH PUMP	4-21
4.3.4	REMOVAL OF THE POWER DIVIDER	4-22
4.3.5	REMOVAL OF THE COUPLING.....	4-23
4.3.6	DISASSEMBLING THE POWER DIVIDER.....	4-24
4.3.7	CHECK AND REPAIR OF THE POWER DIVIDER.....	4-26
4.3.8	ASSEMBLING THE POWER DIVIDER.....	4-27
4.3.9	INSTALLATION OF THE COUPLING	4-28
4.3.10	INSTALLATION OF EACH PUMP.....	4-29
4.4	ASSEMBLY AND DISASSEMBLY OF RADIATOR.....	4-30
4.4.1	CONSTRUCTION OF THE RADIATOR	4-30
4.4.2	REPLACEMENT ORDER OF RADIATOR CORE.....	4-31
4.5	DEF/AdBlue® SCR SYSTEM	4-32
4.5.1	DEF/AdBlue® TANK	4-37
4.5.2	INDUCEMENT CONTROL SYSTEM	4-40

5. HYDRAULIC SYSTEM

5.1	LOCATION OF MAIN HYDRAULIC COMPONENTS.....	5-2
5.1.1	COMPONENTS LOCATION ON THE HYDRAULIC SCHEMATIC.....	5-2
5.1.2	HYDRAULIC COMPONENTS LIST.....	5-7
5.1.3	LAYOUT OF HYDRAULIC COMPONENTS.....	5-11
5.2	CONSTRUCTION AND FUNCTION.....	5-18
5.2.1	OIL FLOW FROM No.1 AND No.2 PUMPS.....	5-18
5.2.2	OIL FLOW FROM No.3 PUMP.....	5-20
5.2.3	OIL FLOW FROM No.4 AND No.5 PUMPS (FRONT, REAR DRUM BRAKE COOLING).....	5-22
5.2.4	OIL FLOW FROM No.6 PUMP.....	5-24
5.2.5	OIL FLOW FROM No.7 PUMP.....	5-28
5.3	VALVE.....	5-36

6. HOIST SYSTEM

6.1	APPARATUS AND LOCATION OF COMPONENTS.....	6-2
6.2	CONSTRUCTION AND FUNCTION.....	6-6
6.2.1	HYDRAULIC SCHEMATIC.....	6-6
6.2.2	LIFTING A LOAD.....	6-8
6.2.3	HOLDING A HOISTED LOAD.....	6-10
6.2.4	LOWERING A LOAD (POWER LOWERING).....	6-12
6.2.5	FREE FALL OPERATION.....	6-14
6.2.6	G WINCH MODE LIFTING.....	6-22
6.2.7	G WINCH MODE LOWERING.....	6-23
6.3	WINCH.....	6-24
6.3.1	WINCH INSTALLATION.....	6-24
6.3.2	WINCH ASSEMBLY.....	6-25
6.3.3	REDUCTION UNIT ASSEMBLY.....	6-26
6.3.4	ADJUSTMENT OF DRUM LOCK.....	6-28
6.4	BRAKE PEDAL.....	6-30
6.4.1	ASSEMBLY DRAWING.....	6-30
6.4.2	ADJUSTING THE BRAKE PEDAL.....	6-32
6.4.3	BLEEDING AIR FROM BRAKE CIRCUIT.....	6-33

7. BOOM HOIST SYSTEM

7.1	APPARATUS AND COMPONENTS LOCATION.....	7-2
7.2	CONSTRUCTION AND FUNCTION.....	7-4
7.2.1	HYDRAULIC SCHEMATIC.....	7-4
7.2.2	RAISING BOOM.....	7-5
7.2.3	NEUTRAL (HOLDING BOOM).....	7-6

7.2.4	LOWERING BOOM	7-7
7.3	BOOM HOIST WINCH.....	7-9
7.3.1	BOOM HOIST WINCH INSTALLATION	7-9
7.3.2	REDUCTION UNIT ASSEMBLY	7-10
7.3.3	BOOM DRUM LOCK ASSEMBLY.....	7-12
7.3.4	ADJUSTMENT OF BOOM DRUM LOCK	7-13
8.	SWING SYSTEM	
8.1	APPARATUS AND COMPONENTS LOCATION	8-1
8.2	CONSTRUCTION AND FUNCTION.....	8-3
8.2.1	HYDRAULIC SCHEMATIC.....	8-3
8.2.2	SWING (NEUTRAL FREE).....	8-5
8.2.3	STOPPING (NEUTRAL FREE).....	8-6
8.2.4	SWING (NEUTRAL FREE/BRAKE MODE SELECT).....	8-7
8.2.5	STOPPING (NEUTRAL FREE/BRAKE MODE SELECT).....	8-9
8.3	CONSTRUCTION OF THE SWING SYSTEM.....	8-11
8.3.1	SWING REDUCTION UNIT	8-11
8.3.2	REDUCTION UNIT ASSEMBLY	8-12
8.3.3	SWING BEARING.....	8-13
8.3.4	SWING LOCK	8-14
9.	TRAVEL SYSTEM	
9.1	APPARATUS AND COMPONENTS LOCATION	9-1
9.2	CONSTRUCTION AND FUNCTION.....	9-2
9.2.1	HYDRAULIC SCHEMATIC.....	9-2
9.2.2	TRAVELING (RIGHT SIDE FORWARD).....	9-3
9.2.3	STOPPING.....	9-4
9.3	CRAWLER.....	9-5
9.3.1	DRIVE ASSEMBLY.....	9-5
9.3.2	MOTOR AND REDUCTION UNIT	9-6
9.3.3	ADJUSTMENT OF SHOE	9-9
10.	ELECTRIC SYSTEM	
10.1	ELECTRICAL	10-3
10.1.1	ELECTRICAL WIRING SCHEMATIC.....	10-3
10.1.2	CONNECTOR LAYOUT	10-24
10.1.3	LOCATION AND USE OF FUSE	10-162
10.1.4	WIPER CONTROL RELAY	10-167
10.1.5	PRESSURE SWITCH (FOR TRAVEL MOTION DETECT)	10-168
10.1.6	PRESSURE SWITCH (FOOT BRAKE).....	10-169

10.1.7	PRESSURE SENSOR.....	10-170
10.1.8	INCLINATION SENSOR.....	10-173
10.1.9	BUZZER UNIT	10-174
10.1.10	RELAY BOX	10-175
10.1.11	RELAY BOX.....	10-186
10.1.12	LOAD DETECTOR (CRANE).....	10-189
10.1.13	ANGLE SENSOR.....	10-190
10.1.14	HOW TO CHECK THE FAILURE CONTENTS	10-192
10.1.15	WARNING DISPLAY CONDITION.....	10-196
10.1.16	ENGINE ECU.....	10-207
10.2	LOAD SAFETY DEVICE	10-210
10.2.1	CONFIGURATION OF SCREENS.....	10-211
10.2.2	SYSTEM DAIGRAM.....	10-212
10.2.3	MONITOR DISPLAY.....	10-213
10.2.4	DETAIL OF ML CONTROLLER	10-220
10.2.5	SHIFTING TO MAINTENANCE SCREEN	10-233
10.2.6	INPUT / OUTPUT SIGNAL.....	10-235
10.2.7	ML FUNCTION SETTING.....	10-244
10.2.8	DATA COPY, FORMAT	10-246
10.2.9	LANGUAGE, UNIT SETTING.....	10-250
10.2.10	ML ADJUSTMENT (NORMAL).....	10-251
10.2.11	ML ADJUSTMENT (TEMPORARY).....	10-274
10.2.12	OPERATION PROGRESS	10-275
10.2.13	VERSION INFORMATION	10-278
10.2.14	FAILURE HISTORY.....	10-279
10.2.15	ADJUSTMENT DATA.....	10-282
10.2.16	DOWNLOAD ML PROGRAM.....	10-288
10.2.17	DOWNLOAD OF MONITOR PROGRAM	10-290
10.3	MAIN CONTROLLER.....	10-295
10.3.1	ARRANGEMENT OF MAIN CONTROLLER.....	10-295
10.3.2	COMPOSITION OF SYSTEM	10-296
10.3.3	FUNCTION OF MAIN CONTROLLER.....	10-297
10.3.4	MAIN CONTROLLER 1, 2 (HARDWARE).....	10-333
10.3.5	SPECIFICATIONS OF MAIN CONTROLLER INPUT/OUTPUT	10-334
10.3.6	ARRANGEMENT OF MAIN CONTROLLER CONNECTOR PIN	10-348
10.3.7	ADJUSTMENT OF MAIN CONTROLLER	10-364
10.3.8	CONTROLLER MALFUNCTION EMERGENCY MEASURES.....	10-369

11. AIR CONDITIONER

11.1	NAME OF THE AIR CONDITIONER PARTS	11-1
11.2	ELECTRIC WIRING DIAGRAM	11-7
11.3	PARTS ILLUSTRATION	11-8
11.4	DISASSEMBLY AND ASSEMBLY OF THE UNIT	11-10
11.4.1	REMOVAL OF THE BLOWER UNIT	11-10
11.4.2	REPLACING THE BLOWER MOTOR	11-11
11.4.3	REPLACING THE BLOWER CONTROLLER.....	11-11
11.4.4	REMOVAL OF THE HEATER CORE	11-11
11.4.5	REMOVAL OF THE AIR CON. UNIT CASE-FRONT, REAR AND LOWER.....	11-12
11.4.6	REPLACING THE EVAPORATOR AND EXPANSION VALVE	11-13
11.4.7	INSTALLATION OF EVAPORATOR SENSOR.....	11-13
11.4.8	REPLACING THE MOTOR ACTUATOR.....	11-14
11.5	FAULT DETECTION FROM THE CONTROL PANEL INDICATION	11-15
11.5.1	GENERAL	11-15
11.5.2	FAULT IN THE INPUT AND OUTPUT CIRCUIT OF THE MOTOR ACTUATOR.....	11-15
11.5.3	FAULT IN THE THERMISTOR SENSOR CIRCUIT	11-16
11.6	BASIC SYSTEM OF HVAC	11-17
11.7	RECHARGING OF THE COOLANT.....	11-23
11.7.1	CAUTION AT WORK.....	11-23
11.7.2	WORK PROCEDURE.....	11-25
11.7.3	RECHARGING PROCEDURE.....	11-27
11.8	TROUBLESHOOTING.....	11-32

12. TRANSLIFTER SYSTEM

12.1	APPARATUS AND COMPONENTS LOCATION	12-1
12.2	CONSTRUCTION AND FUNCTION.....	12-2
12.2.1	HYDRAULIC SCHEMATIC.....	12-2
12.2.2	RAISING THE TRANSLIFTER.....	12-3
12.2.3	LOWERING THE TRANSLIFTER	12-4
12.3	REMOTE CONTROL SWITCH BOX.....	12-5

13. TROUBLESHOOTING

13.1	ENGINE.....	13-1
13.2	WINCH SYSTEM.....	13-3
13.3	SWING SYSTEM.....	13-8
13.4	TRAVELING SYSTEM.....	13-11

Thanks for your reading.

Please click here to download complete manual instantly.

And can also choose other manuals.

Feel free --->write to me with any questions.

Our service email:

manuals007@hotmail.com