



## Workshop literature

**STILL**  
**ELECTRONIC**  
**DOCUMENTATION**  
**SYSTEM**

## Electric forklift truck RX60-25 - 35, RX60-40 - 50

RX60-25  
RX60-30  
RX60-35  
RX60-40  
RX60-45  
RX60-50



6321 6322 6323 6324 6325 6327  
6328 6329 6330 6361 6362 6364  
6367 6368 6369

first in intralogistics



## Edition 2013/06

- **Version 4**
- Various corrections and enhancements
- Integration of new type carriers 6361–6369 (RX60-xx/LSP600)
- Chapter 22 - "Mechanical drive axle", chapter re-structured
- Chapter 42 - "Steering axle", curve switch revised
- Chapter 49 - "Brake system", chapter re-structured
- Chapter 60 - "Insulation testing" revised
- Chapter 60 - "Power cables" added
- Chapter 64 - "MCU2" integrated
- Chapter 69 - "Maintenance guidelines for appliance plugs" added

## Edition 2011/12

- **Version 3**
- Various corrections and additions.
- Introduction re-summarised.
- Chapter 00 — maintenance and diagnostics added.
- Chapter 42 — CSC revised.
- Chapter 49 — electric parking brake revised.
- Chapter 60 — insulation testing and intermediate circuit summarised.
- Chapter 64 — SAC converter added

## Edition 2010/10

- **Version 2**
- Various corrections and enhancements
- Facelift integration, Step 1 and 2
- Integration RX60–50 LP600 (6330)
- Chapter 22 - "Mechanical drive axle", drive wheel unit and power unit revised.
- Chapter 49 - "Brake system", electric parking brake added
- Chapter 50 - "Operating devices" revised
- Chapter 56 "Display elements" revised, all documentation about the display operating unit is now contained in a separate workshop manual
- Chapter 60 "Electrics / Electronics" revised and expanded
- Chapter 69 "Batteries and accessories" added
- Chapter 70 - "Hydraulics, general" revised
- Chapter 71 "Auxiliary hydraulics" revised and expanded
- Chapter 76 - "Valves", hand lever and servo hydraulics revised and added
- Chapter 81 "Lift mast" revised and expanded
- Chapter X - "Circuit diagrams" added

## Edition 2007/12

- **Version 1**
- First issue



## Documentation

This workshop manual contains all the information required to assist trained service engineers with all work, repairs and maintenance on this truck.

In addition, some of the components have been deliberately excluded from this workshop manual and are explained elsewhere in order to ensure a clear overview. These components are explained in workshop handbooks, special documentation and circuit diagrams.

Changes may be made at short notice and at any time, and are communicated via Service Information documents.

### Workshop manuals

- Display elements - display
- FleetManager™

### Special documentation

- Error list
- Overview of truck software
- STILL Flasher
- Overview of consumables
- FEM 4.004 test log book

### Operating circuit diagrams

- see the circuit diagram overview

## Symbols Used

The signal terms **Danger**, **Warning**, **Caution**, **Note** and **Environment note** are used in this document as hazard warnings or for unusual information that requires special identification:

### DANGER

means that failure to comply involves risk to life and/or major damage to property can occur.

### WARNING

means that failure to comply involves risk of serious injury and/or major damage to property can occur.

### CAUTION

means that failure to comply involves risk of material damage or destruction.



### NOTE

means that particular attention is drawn to combinations of technical factors which may not be evident even to a specialist.



### ENVIRONMENT NOTE

*The instructions listed here must be complied with as otherwise environmental damage may result.*

For your safety, additional symbols are also used.  
Please heed the various symbols.

## Changes and retrofitting

### Warnings before making changes to the truck

If the truck is used for work not listed in the guidelines or truck-specific original operating instructions and has to be converted or retrofitted accordingly, you should be aware of the following:

- Any structural modification can affect the handling and stability of the truck, and can result in accidents.
- Without authorisation from STILL, no changes that affect the stability, the load capacity and the safety systems may be carried out.
- Operation of the truck without an overhead guard at a lift height of over 1800 mm is prohibited.
- It is prohibited to install and use restraint systems that are not approved by STILL.
- It is prohibited to drill holes in the overhead guard or to perform welding on it.
- When carrying out welding on other parts of the truck, it is essential that the battery and all connections to the electronic controls are disconnected.
- **Only for electric forklift trucks:** It is prohibited to drill holes in the area of the driver's seat into the battery hood because hydrogen can enter through the bores into the driver's cab.


### CE conformity

With the CE declaration of conformity, STILL confirms that the truck complies with the standards and regulations valid at the time of marketing. The CE conformity mark is shown on the nameplate and indicates compliance with the above regulations.

A subsequent structural change or addition to the truck can compromise safety, thus invalidating the CE declaration of conformity. In this case, a new CE declaration of conformity is essential for the structural changes. The company that was instructed by the truck operating company to carry out the change is responsible for issuing a new CE declaration of conformity.

The contractor of the operating company must also fulfil the following prerequisites:

- Construction documents, test documents and assembly instructions associated with the change must be archived and remain accessible at all times.
- Check that the capacity rating plate, decal information, hazard warnings and the operating



CE-Symbol

instructions are consistent with regard to the changes and modify if necessary.

The change must be processed by a design office that specialises in the area of industrial trucks.

The change must be planned, checked and implemented in accordance with the standards and directives valid at the time.

## Working with spare parts

### Warning regarding non-original parts

Original parts, attachments and accessories are specially designed for this truck. We specifically draw your attention to the fact that parts, attachments and accessories supplied by other companies have not been tested and approved by STILL.

#### **▲ CAUTION**

Installation and/or use of such products may therefore have a negative impact on the design features of the truck and thus impair active and/or passive driving safety.

We recommend that you obtain approval from the manufacturer and, if necessary, from the relevant regulatory authorities before installing such parts. STILL accepts no liability for any damage caused by the use of non-original parts and accessories without approval.

## Working with electronic controls

It is not generally permitted to open controls. STILL's liability and the warranty are no longer applicable once the seal has been damaged.

In exceptional cases, personnel authorised by STILL are allowed to open the controls.



## Table of contents

### 00 Product information

<b>Foreword</b> .....	00- 1
<b>About the RX60-25 - 50</b> .....	00- 1
<b>Safety instructions</b> .....	00- 4
<b>Safety instructions Electrical system</b> .....	00- 4
<b>Jacking up the front of the truck</b> .....	00- 4
<b>Jacking up the rear of the truck</b> .....	00- 6
<b>Securing the fork carriage</b> .....	00- 7

### 01 Service

<b>Maintenance</b> .....	01- 1
<b>Maintenance instructions</b> .....	01- 1
<b>Maintenance — 1000 hours/annually</b> .....	01- 3
<b>Maintenance — 3000 hours/every six months</b> .....	01- 5
<b>Tool</b> .....	01- 7
<b>Measuring and testing equipment</b> .....	01- 7
<b>Standard torques</b> .....	01- 8

### 11 Electrical motor

<b>Traction motor</b> .....	11- 1
<b>General technical data</b> .....	11- 1
<b>Electrical connections</b> .....	11- 1
<b>Traction drive</b> .....	11- 3
<b>Speed sensor</b> .....	11- 5
<b>Pin sensor</b> .....	11- 5
<b>Temperature sensor</b> .....	11- 7
<b>Temperature sensor KTY84</b> .....	11- 7

### 22 Mechanical drive axle

<b>Drive axle EC35-EC50</b> .....	22- 1
<b>General technical data Carraro EC 35</b> .....	22- 1
<b>General technical data Carraro EC 50</b> .....	22- 3
<b>Drive axle</b> .....	22- 5
<b>Drive axle without pump motor Removal and installation</b> .....	22- 6
<b>Drive axle with pump motor Removal and installation</b> .....	22- 10
<b>Wheel drive</b> .....	22- 13
<b>Traction motor</b> .....	22- 17

Removing/installing the service brake .....	22-19
Differential gearbox and brake .....	22-21
Removal of the differential gearbox and brake .....	22-23
Installation of the differential gearbox and brake .....	22-26
<b>31 Chassis</b>	
<b>Chassis .....</b>	<b>31- 1</b>
Battery door .....	31- 1
Battery lock .....	31- 2
Battery door sensor .....	31- 4
<b>Counterweight .....</b>	<b>31- 5</b>
Counterweight .....	31- 5
<b>34 Driver's compartment</b>	
<b>Overhead guard .....</b>	<b>34- 1</b>
Overhead guard .....	34- 1
Removing the overhead guard .....	34- 3
Installing the overhead guard .....	34- 8
<b>42 Steering system</b>	
<b>Hydraulic steering .....</b>	<b>42- 1</b>
General technical data .....	42- 1
Steering system .....	42- 2
Steering — error detection .....	42- 4
Steering unit .....	42- 5
6S3 diaphragm pressure switch .....	42- 7
Priority valve .....	42- 9
<b>Steering wheel and steering column .....</b>	<b>42-11</b>
Steering column .....	42-11
Steering angle sensor .....	42-13
Steering angle-dependent handling performance — CSC .....	42-15
CSC — functional test .....	42-16
<b>Steering axle .....</b>	<b>42-20</b>
General technical data .....	42-20
General technical data 6330 .....	42-21
Cornering switch .....	42-21
Swing axle .....	42-23
Swing axle, reinforced for LP600 .....	42-24

## Table of contents

Removing/installing the swing axle .....	42-24
Wheel hub .....	42-27
Steering angle .....	42-29
Tie rod .....	42-30
Axe stub .....	42-31
<b>49 Brake installation</b>	
<b>Mechanical service brake .....</b>	<b>49- 1</b>
Service brake .....	49- 1
Changing the brake cable Service brake .....	49- 1
<b>Handbrake .....</b>	<b>49- 3</b>
Brake cable change, handbrake .....	49- 3
Actuating force of the handbrake .....	49- 5
Parking brake switch 1S3 .....	49- 6
<b>Electric parking brake .....</b>	<b>49- 8</b>
Electric parking brake .....	49- 8
Function .....	49- 9
Cause and effect .....	49-11
Design and system description .....	49-13
Maintenance instructions .....	49-15
Checking the brake .....	49-16
Calibration and functional test .....	49-18
Changing the parking brake cable .....	49-21
Limit position switch .....	49-24
Drive unit Installation and removal .....	49-26
Central lubrication device Installation and removal .....	49-28
<b>50 Driver's controls</b>	
<b>Brake pedal .....</b>	<b>50- 1</b>
Brake sensor .....	50- 1
<b>Single pedal .....</b>	<b>50- 3</b>
Accelerator — single-pedal .....	50- 3
Dead man switch 7S13 .....	50- 6
<b>Double pedal .....</b>	<b>50- 7</b>
Accelerator – dual pedal 2nd generation .....	50- 7
Accelerator – dual pedal 1st generation .....	50-12

<b>Driver's controls</b>	.....	50-17
<b>Hand lever</b>	.....	50-17
<b>Joystick</b>	.....	50-18
<b>Joystick operation</b>	.....	50-20
<b>Generation 1 mini-lever</b>	.....	50-21
<b>Generation 2 mini-lever</b>	.....	50-23
<b>Generation 2 mini-leverActuation</b>	.....	50-25
<b>Tip switch</b>	.....	50-27
<b>Axle assignment</b>	.....	50-29
<b>Direction indicator module (Fabli)</b>	.....	50-32

## 56 Display elements

<b>Operating console</b>	.....	56- 1
Drive direction turn indicator display	.....	56- 1
<b>Display</b>	.....	56- 3
Display operating unit (ABE 1) Generation 1	.....	56- 3
ABE 1 Installation and removal	.....	56- 5
Display operating unit (ABE 2) Generation 2	.....	56- 6
ABE 2 Installation and removal	.....	56- 8

## 60 Electrics / Electronics

<b>General</b>	.....	60- 1
General technical data 6321 - 6325	.....	60- 1
General technical data 6326 - 6330	.....	60- 3
Overview of the controllers	.....	60- 4
Electrical system	.....	60- 5
Electrical components	.....	60- 5
Switching on procedure for the electrical system	.....	60- 7
Software compatibility	.....	60-12
PAN process	.....	60-13
Parameter management	.....	60-14
Error ring buffer	.....	60-15
Intermediate circuit	.....	60-16
Insulation testing for electric trucks	.....	60-18
Component insulation testing	.....	60-20
Traction motor temperature monitoring	.....	60-23
Pump motor temperature monitoring	.....	60-25
Converter temperature monitoring	.....	60-26
Drive mode — driving behaviour Availability	.....	60-27

## Table of contents

Drive mode — driving behaviour Description .....	60-27
Blue-Q = IQ .....	60-29
<b>Wiring .....</b>	<b>60-31</b>
CAN bus connections .....	60-31
Power cables .....	60-32
Maintenance guidelines for power cables .....	60-33
Repair - Contact elements .....	60-33
<b>Electrical system .....</b>	<b>60-35</b>
Fuse box .....	60-35
Fuses .....	60-35
Contactor .....	60-37
<b>Sensor system .....</b>	<b>60-39</b>
Vertical lift mast position .....	60-39
Tilt angle sensor 7B46 .....	60-40
Tilt angle sensor parameters .....	60-42
Installation of the vertical lift mast position .....	60-43
Load measurement .....	60-46
Load measurement pressure sensor .....	60-48
<b>Additional electrical installation .....</b>	<b>60-50</b>
Distributor card .....	60-50
Option board .....	60-51
CAN-Power-Port (CPP) .....	60-52
CPP 1/CPP 3 .....	60-52
CPP 2B .....	60-54
CPP 2/CPP 4 .....	60-55
CPP battery carrier (CPP5) .....	60-55
Relay-Power-Port .....	60-56

## 64 Electronic controllers

<b>Traction and working hydraulics control .....</b>	<b>64- 1</b>
Main Control Unit (MCU) .....	64- 1
MCU with servo hydraulics .....	64- 2
MCU generation 2 .....	64- 3
Main Control Unit (MCU) Removal and installation .....	64- 3
Supply Unit (SU) .....	64- 5
Supply Unit (SU) Removal and installation .....	64- 7

<b>Inverters</b>	.....	64-10
Inverters	.....	64-10
Converter LAC - 80 Volt	.....	64-10
SAC converter — 80 Volt	.....	64-12
Inverters Removal and installation	.....	64-13

## 69 Batteries and accessories

<b>Traction battery</b>	.....	69- 1
Battery	.....	69- 1
Battery plug	.....	69- 3
Maintenance guidelines for appliance plugs	.....	69- 4
Repair - Battery male connector contacts	.....	69- 6
Working with reducer sleeves	.....	69- 8
Discharge indicator	.....	69- 9

## 70 Hydraulics

<b>General</b>	.....	70- 1
General technical data	.....	70- 1
Lifting operating speeds	.....	70- 2
Tilting operating speeds	.....	70- 3
Lowering operating speeds	.....	70- 4
Forward tilt safety test	.....	70- 4
Lowering safety test	.....	70- 5
Safety checks of hose assembly	.....	70- 5
Depressurising the hydraulics	.....	70- 6
<b>Basic hydraulics</b>	.....	70- 8
Basic hydraulics	.....	70- 8
Steering hydraulics	.....	70- 9
Working hydraulics	.....	70-10
Hydraulic tank	.....	70-11
Hydraulic oil	.....	70-11
Return filter	.....	70-12
Breather filter	.....	70-14
Suction filter	.....	70-15
High-pressure filter	.....	70-16
Conical nipple fittings (CNF)	.....	70-17
Bolted joint	.....	70-17

## Table of contents

### 71 Working hydraulics

Pump unit .....	71- 1
General technical data .....	71- 1
Pump unit .....	71- 2
Electrical connections .....	71- 3
Pump motor without rev sensor .....	71- 3
Pump motor temperature sensor .....	71- 4
Pump motor Removal and installation .....	71- 6
Hydraulic pump .....	71- 7
Hydraulic pump Removal and installation .....	71- 9
Tilt cylinder .....	71-12
Mast tilt .....	71-12
Tilt cylinder Removal and installation .....	71-13
Changing the set of seals 2200 - 5000 kg .....	71-14
Changing the set of seals 5000 kg - LP600 .....	71-16
Auxiliary hydraulics .....	71-19
Attachments .....	71-19
Second operating function for attachments .....	71-22
Clamp locking mechanism with servo hydraulics .....	71-22
Clamp locking mechanism for hand levers .....	71-24

### 76 Valves

Hand lever .....	76- 1
General technical data .....	76- 1
Hand lever valve block .....	76- 2
Emergency lowering .....	76- 3
Hydraulic transmitter .....	76- 4
Valve block Removal / installation .....	76- 6
Directional control valve block .....	76- 8
Check valve for hydraulics blocking function .....	76-10
Servo hydraulics .....	76-11
General technical data .....	76-11
Servo hydraulics valve block .....	76-12
Manual lowering .....	76-13
Directional control valve block .....	76-14

**81 Lift mast**

Lift mast .....	81- 1
General technical data .....	81- 1
Telescopic lift mast .....	81- 2
NiHo lift mast .....	81- 3
Triple mast .....	81- 4
Lift mast — removal .....	81- 6
Lift mast — installation .....	81- 8
Load chains .....	81-10
Load chains Checking, cleaning .....	81-10
Adjusting the load chains Telescopic mast .....	81-11
Adjusting the load chains NiHo lift mast .....	81-13
Outer load chain Triple mast .....	81-15
Middle load chain Triple mast .....	81-17
End damping .....	81-20
End position damping of outer cylinder .....	81-20
Middle cylinder end dampener .....	81-21
Line breakage protection .....	81-22
Hose safety valve of triplex mast .....	81-22
Shock valve installation positions .....	81-22
Lift cylinders .....	81-24
Lift jack .....	81-24
Outer cylinder .....	81-24
Centre cylinder .....	81-26
Cylinder head .....	81-27
Rollers / support rollers .....	81-30
Support roller clearance .....	81-30

**84 Load support**

Fork carriage .....	84- 1
Fork carriage .....	84- 1
Roller .....	84- 2

### Annex

#### X Diagrams

<b>Hydraulics</b> .....	<b>X- 1</b>
<b>Hydraulic circuit diagram Multi-levers</b> .....	<b>X- 1</b>
<b>Hydraulic circuit diagram Servo hydraulics</b> .....	<b>X- 3</b>

**Thanks for your reading.**  
**Please click here to download complete manual**  
**instantly.**  
**And can also choose other manuals.**

**Feel free --->write to me with any questions.**  
**Our service email:**  
**manuals007@hotmail.com**