

DX210W

Shop Manual

K1017314AE

Serial Number 5001 and Up

Table of Contents

Safety

Wheel Excavator Safety	SP000956
------------------------------	----------

Specifications

Specification for DX210W	SP000957
--------------------------------	----------

General Maintenance

General Maintenance Procedures	SP000016
Standard Torques	SP000813

Upper Structure

Cabin	SP001231
Counterweight.....	SP000959
Fuel Tank.....	SP000961
Fuel Transfer Pump	SP000021
Swing Bearing.....	SP001232
Swing Reduction Gear.....	SP001233

Lower Structure and Chassis

Ram Lock Valve.....	SP000923
Selector Valve.....	SP000926
Double Pilot Check Valve	SP000927
Solenoid Valve.....	SP000928
Front Axle	SP000929
Rear Axle	SP000930

Engine and Drive Train

Transmission	SP000962
Drive Coupling (Main Pump).....	SP000963

Hydraulics

Hydraulic System Troubleshooting, Testing and Adjustment	SP001097
Accumulator	SP000984
Center Joint (Swivel).....	SP000919
Cylinders.....	SP001098
Main Control Valve	SP000966
Swing Motor.....	SP000985
Travel Motor.....	SP001110
Counterbalance Valve	SP000991
Main Pump & PTO.....	SP000988
Gear Pump	SP000989
Service Brake Supply Valve	SP000990
Dozer Control Valve.....	SP000992
Steering Valve	SP000993
Accelerator Pedal Valve (Hydraulic)	SP000964
One Spool Valve.....	SP000996
Remote Control Valve (Work Lever / Joystick)	SP000069
Breaker EPPR Valve (Opt)	SP000192
Service Brake Pedal Valve	SP001006
Solenoid Valve Assembly	SP000997
Hydraulic Schematic	SP001107

Electrical System

Electrical System	SP001108
Electrical Schematic	SP001256

Attachments

Boom and Arm.....	SP001255
Bucket.....	SP001001

Safety

Wheel Excavator Safety

Edition 1

MEMO

Table of Contents

Wheel Excavator Safety

Safety Precautions	5
Applicable Models	5
To the Operator of a DOOSAN Excavator.....	6
General Safety Essentials	10
Location of Safety Labels	11
Summary of Safety Precautions for Lifting in Digging Mode	12
Unauthorized Modifications	13
General Hazard Information	13
Before Starting Engine	22
Machine Operation	26
Maintenance	32
Battery	40
Towing	42
Shipping and Transportation	43
Lifting with Sling.....	43

Please Click Here To Download The Complete Manual
Download Other Manuals
If Having Any Questions Feel Free To Contact us

admin@servicemanualbit.com