

# **DX300LC**

Shop Manual

K1006409E

Serial Number 5001 and Up

Daewoo reserves the right to improve our products in a continuing process to provide the best possible product to the market place. These improvements can be implemented at any time with no obligation to change materials on previously sold products. It is recommended that consumers periodically contact their distributors for recent documentation on purchased equipment.

This documentation may include attachments and optional equipment that is not available in your machine's package. Please call your distributor for additional items that you may require.

Illustrations used throughout this manual are used only as a representation of the actual piece of equipment, and may vary from the actual item.



**DX300LC**

Serial Number 5001 and Up

Pub.No. K1006409E



**Product Label**



**Instructions**

**Trim Out The Label Along  
The Lines And Insert Into  
Pocket On The Binder Spine**



# Table Of Contents

## Safety

Track Excavator Safety.....	SP000014
-----------------------------	----------

## Specifications

Specification for DX300LC.....	SP000015
--------------------------------	----------

## General Maintenance

General Maintenance Procedures.....	SP000016
Standard Torques.....	SP000017

## Upper Structure

Cabin .....	SP000018
Counterweight.....	SP000019
Fuel Tank.....	SP000020
Fuel Transfer Pump.....	SP000021
Swing Bearing.....	SP000022
Swing Reduction Gear.....	SP000023

## Lower Structure and Chassis

Track Assembly .....	SP000024
Air Conditioner .....	SP000025

## Engine and Drive Train

Drive Coupling (Main Pump).....	SP000026
---------------------------------	----------

## Hydraulics

Hydraulic System Troubleshooting, Testing and Adjustment .....	SP000027
Accumulator.....	SP000028
Center Joint (Swivel).....	SP000029

Cylinders.....	SP000030
Swing Motor.....	SP000031
Travel Motor.....	SP000032
Gear Pump .....	SP000033
Main Control Valve .....	SP000034
Hydraulic Schematic (DX300LC).....	SP000037
Axial Piston Pump.....	SP000068
Remote Control Valve (Work Lever / Joystick).....	SP000069
Travel Control Valve (With Damper).....	SP000070

## **Electrical System**

Electrical System .....	SP000038
Electrical Schematic (DX300LC) .....	SP000039

## **Attachments**

Boom and Arm.....	SP000040
Bucket.....	SP000041

**Please Click Here To Download The Complete Manual**  
**Download Other Manuals**  
**If Having Any Questions Feel Free To Contact us**

**[admin@servicemanualbit.com](mailto:admin@servicemanualbit.com)**