## Mega 400-V

Shop Manual
023-00040E
Serial Number 1001 and Up
February 2001

Daewoo reserves the right to improve our products in a continuing process to provide the best possible product to the market place. These improvements can be implemented at any time with no obligation to change materials on previously sold products. It is recommended that consumers periodically contact their distributors for recent documentation on purchased equipment.

This documentation may include attachments and optional equipment that is not available in your machine's package. Please call your distributor for additional items that you may require.

Illustrations used throughout this manual are used only as a representation of the actual piece of equipment, and may vary from the actual item.

## **TABLE OF CONTENTS**

Safety	
Wheel Loader Safety S0103010k	<
Specifications	
Specifications for Mega 400-VS0203060k	<b>〈</b>
General Maintenance	
General Maintenance ProceduresS030200	0
Standard TorquesS030900	Э
Upper Structure	
CounterweightS0403030ł	<
Fuel Transfer PumpS040550	
Hydraulic oil tank	
Lower Structure and Chassis	
Center Joint (Articulation Joint)	<
Engine and Drive Train	
Engine and Drive Train Front Axle S0602150k	<b>〈</b>
_	
Front Axle S0602150	<
Front Axle	<b>〈</b>
Front Axle	< < <
Front Axle         \$0602150k           Rear Axle         \$0602160k           Air-Conditioner         \$0605050k           Transmission and Torque Converter (ZF)         \$0607070k	< < <
Front Axle	< < < C
Front Axle S0602150k Rear Axle S0602160k Air-Conditioner S0605050k Transmission and Torque Converter (ZF) S0607070k Transmission Error Codes (ZF) S06079000  Hydraulics	< < < < < < < < < < < < < < < < < < <

Main Pump (Denison T6DMY Series)	S0708460K
Steering and Brake Pump (Denison T67DB Siries)	S0708470K
Brake Pedal Valve	S0709230K
Main Control Valve (Toshiba)	S0709455K
Pilot Control Valve	S0709475K
Flow Amplifier (Danfoss)	S0709665K
Power Steering Unit	S0709730K
Unloader Valve	S0709850K
Hydraulic Schematic (Mega 400-V)	S0793050K
Electrical System	
Electrical System	S0802180K
Electrical Schematic (Mega 400-V)	S0893050K

## **Attachments**

## Please Click Here To Download The Complete Manual Download Other Manuals If Having Any Questions Feel Free To Contact us

admin@servicemanualbit.com