Solar 130LC-V

Shop Manual
2023-7117E
Serial Number 0001 and Up

Daewoo reserves the right to improve our products in a continuing process to provide the best possible product to the market place. These improvements can be implemented at any time with no obligation to change materials on previously sold products. It is recommended that consumers periodically contact their distributors for recent documentation on purchased equipment.

This documentation may include attachments and optional equipment that is not available in your machine's package. Please call your distributor for additional items that you may require.

Illustrations used throughout this manual are used only as a representation of the actual piece of equipment, and may vary from the actual item.

Product Label

Instructions

Trim Out The Label Along
The Lines And Insert Into
Pocket On The Binder Spine



TABLE OF CONTENTS

Safety	
Track Excavator Safety	S0102000
Specifications	
Specifications for Solar 130LC-V	S0206000
General Maintenance	
General Maintenance Procedures	\$0302000
Standard Torques	
Standard Torques	
Upper Structure	
Cab	S0402000
Counterweight	S0403000
Fuel Tank	S0405000
Swing Bearing	S0407000
Swing Reduction Gearbox	S0408020
Lower Structure and Chassis	
Track Assembly	S0505050
Engine and Drive Train	
Air-Conditioner	S0605010
Hydraulics	
Hydraulic System Troubleshooting, Testing and Adjustment	S0702050
Accumulator	S0703000
Center Joint (Swivel)	S0704020
Cylinders	S0705000
Swing Motor	S0707220
Travel Motor (With Gearbox)	S0707340

Main Pump (With Regulator)	S0708340
Main Control Valve	S0709420
Remote Control Valve (Work Lever / Joystick)	S0709450
Travel Control Valve (RCV8C4015A)	S0709800
Hydraulic Schematic (S130LC-V)	S0792040
Electrical System	
Electrical System	S0802060
Electrical Schematic (S130LC-V)	S0892040
Attachments	
Boom and Arm	S0902030
Bucket	S0904000

Please Click Here To Download The Complete Manual Download Other Manuals If Having Any Questions Feel Free To Contact us

admin@servicemanualbit.com