

DL420

Shop Manual

950106-00009E

Serial Number 5001 and Up

DOOSAN reserves the right to improve our products in a continuing process to provide the best possible product to the market place. These improvements can be implemented at any time with no obligation to change materials on previously sold products. It is recommended that consumers periodically contact their distributors for recent documentation on purchased equipment.

This documentation may include attachments and optional equipment that is not available in your machine's package. Please call your distributor for additional items that you may require.

Illustrations used throughout this manual are used only as a representation of the actual piece of equipment, and may vary from the actual item.

DL420

Serial Number 5001 and Up

Pub.No. 950106-00009E

Product Label



Instructions

**Trim Out The Label Along
The Lines And Insert Into
Pocket On The Binder Spine**

Table of Contents

Safety

Wheel Loader Safety.....	SP002004
--------------------------	----------

Specifications

Specification for DL420.....	SP002005
------------------------------	----------

General Maintenance

General Maintenance Procedures	SP000097
Standard Torques	SP000098

Engine

QSM11 Engine.....	SP001669
-------------------	----------

Drive Train

Transmission and Torque Converter (ZF 4WG-260-4).....	SP002033
Transmission Error Codes (ZF).....	SP000100
Front Axle (ZF - MT-L 3105).....	SP000101
Rear Axle (ZF - MT-L 3095).....	SP000107
Drive Shaft.....	SP000119

Brake

Service Brake.....	SP002006
Brake Supply Valve.....	SP002007
Parking Brake	SP000122
Brake Pedal Valve.....	SP000123
Accumulator.....	SP002008

Steering

Steering Unit.....	SP002009
--------------------	----------

Flow Amplifier	SP000126
Emergency Steering	SP002018

Frame

Articulation Center	SP002010
Counterweight.....	SP000130

Tank

Oil Tank.....	SP002011
Fuel Tank.....	SP002012

Hydraulics

Main Control Valve.....	SP000144
Load Isolation System.....	SP002013
Cooling System.....	SP002014
Pilot System.....	SP002015
Hydraulic Schematic (DL420)	SP002016

Electrical System

Air Conditioner	SP000172
Electrical System	SP002032
Electrical Schematic (DL420).....	SP002017

Safety

Wheel Loader Safety

Edition 1

Please Click Here To Download The Complete Manual
Download Other Manuals
If Having Any Questions Feel Free To Contact us

admin@servicemanualbit.com