

DX60R

Shop Manual

K1042957E

Serial Number 50001 and Up

Table of Contents

Safety

Track Excavator Safety	SP001614
------------------------------	----------

Specifications

Specification for DX60R.....	SP001615
------------------------------	----------

General Maintenance

General Maintenance Procedures.....	SP000016
Standard Torques.....	SP000813

Upper Structure

Cabin	SP001623
Swing Bearing	SP001624

Lower Structure and Chassis

Track Assembly	SP001625
----------------------	----------

Engine and Drive Train

Engine.....	SP001693
Drive Coupling (Main Pump)	SP001627

Hydraulics

Accumulator	SP000028
Center Joint (Swivel).....	SP001628
Cylinders.....	SP001629
Swing Motor.....	SP001630
Travel Motor.....	SP001686
Main Control Valve.....	SP001639
Main Pump.....	SP001488

Remote Control Valve (Work Lever / Joystick)	SP001640
Dozer Valve	SP001490
Travel Control Valve.....	SP001641
Pedal Valve.....	SP001073
Hydraulic Schematic	SP001692

Electrical System

Electrical System	SP001687
Electrical Schematic (DX60R/DX80R)	SP001688

Attachments

Boom and Arm.....	SP001642
Bucket.....	SP001643

SP001614

Track Excavator Safety

Edition 1

MEMO

Table of Contents

Track Excavator Safety

Safety Precautions.....	5
Applicable Models	5
To the Operator of a Excavator	6
General Safety Essentials.....	10
Location of Safety Labels	11
Summary of Safety Precautions for Lifting in Digging Mode.....	11
Unauthorized Modifications.....	13
General Hazard Information	13
Before Starting Engine	22
Machine Operation.....	26
Maintenance	33
Battery	44
Towing	46
Shipping and Transportation	47
Lifting With Sling	47

MEMO

SAFETY PRECAUTIONS



Follow all safety recommendations and safe shop practices outlined in the front of this manual or those contained within this section.

Always use tools and equipment that are in good working order.

Use lifting and hoisting equipment capable of safely handling the load.

Remember that ultimate safety is your own responsibility.

APPLICABLE MODELS

The contents of this section apply to the following models and serial number ranges.

MODEL	SERIAL NUMBER RANGE
DX60R	50001 and Up

Please Click Here To Download The Complete Manual
Download Other Manuals
If Having Any Questions Feel Free To Contact us

admin@servicemanualbit.com