

PARTS MANUAL

ELECTRIC

**N30XMADR3, N45MXR3
(B264)**

CUSTOMER EDITION

HYSTER

SECTIONS

1	FRAME
2	ELECTRICAL SYSTEM
3	DRIVE UNIT
4	STEERING SYSTEM
5	BRAKE/ACCELERATOR SYSTEM
6	HYDRAULIC SYSTEM
7	MAST-THREE STAGE FULL FREE-LIFT
8	CARRIAGE
9	OPTIONS
10	NUMERICAL INDEX

This Parts Manual is divided into 10 major sections which are listed above. Quick reference to these sections can be made by placing the right thumb on the tab of the desired section, bending the book back and thumbing the pages to the corresponding tab.

TABLE OF CONTENTS

DESCRIPTION	PAGE
A	
AMBER STROBE LIGHT	9-10
B	
BACK UP ALARM	9-12
BATTERY CONNECTOR	2-15
BATTERY RETAINERS AND ROLLERS	1-8
BRAKE ASSEMBLY	5-2
BRAKE PEDAL ASSEMBLY	5-3
C	
CARRIAGE	
24-INCH REACH	8-10
INNER FRAME	8-14
CARRIAGE (42 INCH REACH)	8-12
CASTER WHEEL	4-18
CHAINS, PINS, AND ANCHORS	
THREE STAGE FULL FREE-LIFT	7-10
CONTACTOR PANEL	2-8
D	
DECAL AND PLATE LOCATION	1-2
DOUBLE REACH HYDRAULICS	6-10
DRIVE UNIT ASSEMBLY	
20.2:1 GEAR RATIO	
S/N B264N-1530Z⇒	3-4
⇒S/N B264N-1529Z	3-6
E	
ELECTRICAL ARRANGEMENT	2-2
ELECTRICAL COMPONENTS.....	2-6
F	
FLOOR PAD AND OPERATOR SENSING SWITCH.....	1-10
FORKS	
HOOK TYPE	
D/B 10/2001⇒	8-4
⇒D/B 10/2001	8-3
SHAFT TYPE.....	8-2
FREE LIFT CYLINDER	
THREE STAGE FULL FREE-LIFT	7-16
H	
HEADLIGHTS.....	9-7
HOODS AND COVERS.....	1-6
HOSE AND WIRE TAKE-UP	7-20
HYDRAULIC CONTROL VALVE	
D/B 05/2002⇒	6-18
⇒D/B 05/2002	6-16
HYDRAULIC PUMP.....	6-14
HYDRAULIC PUMP MOTOR	6-12

TABLE OF CONTENTS (Continued)

DESCRIPTION	PAGE
H (continued)	
HYDRAULIC STEER MOTOR	
⇒S/N B264N-1529Z	4-8
S/N B264N-1530Z⇒	4-6
HYDRAULIC SYSTEM	6-2
HYDRAULIC TANK ASSEMBLY	6-6
I	
INNER, INTERMEDIATE, AND OUTER MAST	
THREE STAGE FULL FREE-LIFT	7-2
INTEGRAL TILT ASSEMBLY	8-6
WITH SIDE-SHIFT	8-8
L	
LIFT CONTACTOR	2-14
LIFT LIMIT SWITCH	
THREE STAGE FULL FREE-LIFT	7-18
LIGHT AND FAN ASSEMBLY	
WITHOUT SPOTLIGHT	9-8
LOAD BACKREST	8-5
M	
MAIN CYLINDER ARRANGEMENT	
THREE STAGE FULL FREE-LIFT	7-14
MAIN FREE-LIFT	
THREE STAGE FULL FREE-LIFT	7-8
MAIN LIFT CYLINDER	
THREE STAGE FULL FREE-LIFT	7-12
MAST ATTACHING PARTS	7-6
MASTER DRIVE UNIT	3-2
MULTI-FUNCTION CONTROL HANDLE	2-10
O	
OPERATOR GUARD	1-4
P	
PMC HEATER	9-4
POWER STEER ARRANGEMENT	
S/N B264N-1530Z⇒	4-4
POWER STEER ARRANGEMENT	
⇒S/N B264N-1529Z	4-2
POWER STEER CONTACTOR	2-12
R	
REACH CYLINDER	8-18
REAR WORKING LIGHT	9-6

TABLE OF CONTENTS (Continued)

DESCRIPTION	PAGE
S	
SHELF HEIGHT SELECTOR	9-2
SINGLE REACH HYDRAULICS.....	6-8
STEER AND AUXILIARY MOTOR 36 VOLT "E" CONSTRUCTION.....	4-14
STEER AND AUXILIARY PUMP	4-16
STEER AND AUXILIARY PUMP AND MOTOR	4-12
STEER CONTROL UNIT	4-10
T	
TANDEM LOAD WHEEL	5-4
TRACTION CONTACTOR	2-13
TRACTION MOTOR ⇒S/N B264N-1529Z	3-8
S/N B264N-1530Z⇒	3-10

ABBREVIATIONS QUICK REFERENCE SHEET

Listed below are abbreviations used in parts manuals to denote the following expressions:

TERM	DEFINITION	TERM	DEFINITION
Amp	Amperes	FRE	Freezer Environment
AR	As Required	in.	inches
BDI	Battery Discharge Indicators	LPG	Liquefied Petroleum Gas
BWI	Brush Wear Indicator	MAP	Manifold Absolute Pressure
CE	Communicator End	mm	millimeters
CRE	Corrosive Environment	MSTS	Microprocessor Spark Timing System
D/B	Date Break	NPT	National Pipe Threads
dbA	Decibel "A" Scale	O/S	Oversize
DE	Drive End	PTO	Power Take Off
ECH	Empty Container Handler	RPM	Revolutions per Minute
ECH-3	Empty Container Handler - 3 High Stacking	S/N	Serial Number
ECH-4	Empty Container Handler - 4 High Stacking	TMM	Truck Management Module
ECH-5	Empty Container Handler - 5 High Stacking	UL Type D	Diesel-Powered Safety Rating
ECH-6	Empty Container Handler - 6 High Stacking	UL Type DS	Diesel-Powered Safety Rating
ECH-7	Empty Container Handler - 7 High Stacking	UL Type E	Battery-Powered Safety Rating
ECM	Electronic Control Module	UL Type EE	Battery-Powered Safety Rating
ECN	Engineering Change Notice	UL Type ES	Battery-Powered Safety Rating
EEPROM	Electrically Erasable Programmable Read Only Memory	UL Type G	Gasoline-Powered Safety Rating
EPROM	Electrically Programmable Read Only Memory	UL Type GS	Gasoline-Powered Safety Rating
		UL Type LP	Gas-Powered Safety Rating
		UL Type LPS	LP Gas-Powered Safety Rating
		U/S	Undersize
		UL	Underwriters Laboratory
		V	Volts

HOW TO USE THE ILLUSTRATED PARTS MANUAL

This parts manual describes and illustrates assemblies, subassemblies, and detail parts needed for service replacement.

The different constructions are indicated by keys and footnotes. The callouts correspond to descriptions found on the the next page.

HYSTER UNIT CODE D001 NORTH AMERICA 06/2001

TABLE OF CONTENTS

DESCRIPTION	PAGE
AIR INTAKE AND FILTER DIESEL (⇒ D/B 11/96).....	3-22
AIR INTAKE AND FILTER DIESEL (D/B 11/96 ⇒).....	
AIR INTAKE AND FILTER GASOLINE AND LPG.....	
ALTERNATOR GASOLINE, LPG, AND DIESEL -	
ALTERNATOR TYPES GS, LPS, AND DS.....	
AUXILIARY FUNCTION TUBE TWO AND THREE STAGE FULL F	

SECTION 13 NUMERICAL INDEX

PART NO.	ITEM PAGE NO.	PART NO.	ITEM PAGE NO.	PART NO.	ITEM PAGE NO.	PART NO.	ITEM PAGE NO.
142	3-4 19	10-13	25	11-27	29	12-31	12
12445	3-32 19	10-17	6	11-31	25	16719	3-36 5
	3-34 1	10-27	11	11-32	37	16751	3-16 27
		11	6	16485	29	16849	3-34 21
		11	6	8-4	45		3-36 20
		12	6	8-8	34	16863	3-26 17
		3	17	9-7	9	16865	3-6 18
		4	13	9-7	9		4-27 41
		12	6	9-7	19	16882	9-7 30
		3	10	9-11	9		9-11 27
		23	46	10-9	21		10-10 36
		27	46	10-9	28		10-13 32
		26	14	10-13	16		11-7 24
		28	14	11-7	19		11-9 17
		30	14				

SECTIONS

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11

TRANSMISSION HOUSING
⇒ S/N D001H-2628

KEY:
A: Diesel
B: Gasoline and LPG

ITEM	PART NO.	DESCRIPTION	QTY
			A B
		Transmission	1
	2022547	Transmission	1
	2023329	Transmission	2
	2021670	Case	4
1	2023418	Bearing Cap	4
2	296426	Washer	4
3	293592	Bolt	2
4	2021390	Cover	2
5	1371656	Colter Pin	4
6	2021329	O-Ring	4
7	2021915	Plug	4
8	2021675	Housing	22
9	2021336	Pin	39
10	287860	Bolt	1
11	292682	Lockwasher	1
12		Hydraulic Pump	1
13		Figure 5-3	8
14	2021345	Gasket	8
15	214364	Bolt	1
16	296418	Washer	1
17	2021388	Temperature Switch	1
18	2021389	Breather	9
19	2021383	Dipstick	9
20	292515	Bolt	2
21	136692	Nut	3
22	292527	Bolt	3
23	292531	Lockwasher	4
24	292683	Lockwasher	4
25	293637	Bolt	1
26	296420	Washer	1
	996403	Transmission Kit (Includes Item 7)	1
	996405	Transmission Kit (Includes Item 14)	1

This Parts Manual is divided into 11 major sections which are listed above. Quick be made by placing the right thumb on the tab of the desired section, bending the pages to the corresponding tab.

©2002 Hyster Company
See Service Manual for service procedures.

Please Click Here To Download The Complete Manual
Download Other Manuals
If Having Any Questions Feel Free To Contact us

admin@servicemanualbit.com