

PARTS MANUAL

ELECTRIC

**N30XMH2
(C210)**

CUSTOMER EDITION

HYSTER

SECTIONS

1	FRAME
2	ELECTRICAL SYSTEM
3	DRIVE UNIT
4	STEERING SYSTEM
5	BRAKE/ACCELERATOR SYSTEM
6	HYDRAULIC SYSTEM
7	MAST-THREE STAGE FULL FREE-LIFT
8	OPTIONS
9	NUMERICAL INDEX

This Parts Manual is divided into 9 major sections which are listed above. Quick reference to these sections can be made by placing the right thumb on the tab of the desired section, bending the book back and thumbing the pages to the corresponding tab.

TABLE OF CONTENTS

DESCRIPTION	PAGE
A	
ACCELERATOR	5-22
ACCELERATOR PEDAL.....	5-24
B	
BACK-UP ALARM	8-12
BATTERY CONNECTOR	2-16
BATTERY SLIDE AND ROLLER TRAY	
⇒S/N C210V-1642	8-16
S/N C210V-1642⇔S/N PENDING PER ECN 65067.....	8-18
S/N PENDING PER ECN 65067⇒	8-22
BRAKE	5-6
BRAKE AND BACK-UP LIGHT	8-4
BRAKE PEDAL LINKAGE	5-2
C	
CHAINS, PINS, AND ANCHORS	7-4
CONTACTOR	2-12
CONTACTOR PANEL	
CONTROL	2-8
CONTACTOR STEERING	2-10
CONTROL PANEL.....	2-6
CONTROL VALVE	
FOUR FUNCTION	6-42
CONTROL VALVE ATTACHING PARTS.....	6-34
COUNTERWEIGHT	1-14
COVERS	1-6
COWL ELECTRICAL.....	2-14
CYLINDER INSTALLATION	
MAIN LIFT AND FREE-LIFT.....	7-6
D	
DC CONVERTOR	
36/48 VOLT TO 12 VOLT	8-10
DRIVE AND REAR LIGHTS	8-6
DRIVE AXLE	3-2
DRIVE MOTOR MOUNT	6-6
E	
E/EE/ES AND CRE/FRE INSTALLATION	3-10
ECM GUIDANCE.....	2-27
ELECTRIC BRAKE.....	5-26
ELECTRICAL GUIDANCE	2-24
ELECTRICAL SYSTEM.....	2-2
F	
FORK	
HOOK TYPE WITHOUT SIDE-SHIFT	
STANDARD TAPER, 100 MM X 40 MM	7-34
PIN TYPE WITH SIDE-SHIFT OR FORK TILT	7-36
FRAME.....	1-2

TABLE OF CONTENTS (Continued)

DESCRIPTION	PAGE
F (continued)	
FREE-LIFT CYLINDER	7-10
FULL SUSPENSION SEAT	
SHEET 1 OF 2	1-22
SHEET 2 OF 2	1-24
G	
GEAR PUMP	4-11
OPTIONAL	4-12
GUIDANCE HYDRAULICS	6-48
GUIDANCE SWITCH AND SIGNAL	2-28
GUIDE ROLLER	8-15
H	
HAND LEVER	
S/N PENDING PER ECN 64940⇒	6-40
⇒S/N PENDING PER ECN 64940	6-38
HEADER HOSE	7-30
HOOD	1-8
HOSE REEL	7-32
HYDRAULIC	6-2
HYDRAULIC MOTOR	
CLOSED CONSTRUCTION WITH BWI	
S/N PENDING PER ECN 73755⇒	6-32
⇒S/N PENDING PER ECN 73755	6-30
OPEN CONSTRUCTION WITH BWI	6-24
OPTIONAL	
⇒S/N PENDING PER ECN 73755	6-26
OPEN CONSTRUCTION WITHOUT BWI	6-22
S/N PENDING PER ECN 73755⇒	6-28
HYDRAULIC PUMP	
12 CC SINGLE GEAR PUMP	6-8
OPTIONAL	6-10
19 CC DOUBLE GEAR PUMP	6-14
19 CC DOUBLE GEAR PUMP LOW NOISE	6-18
19 CC PUMP - LOW NOISE	
OPTIONAL	6-20
19 CC SINGLE GEAR	
OPTIONAL	6-16
OPTIONAL	6-12
HYDRAULIC TANK	6-46
L	
LABELS	1-27
LIFT HYDRAULICS	7-8
LOAD END SENSOR	2-26

TABLE OF CONTENTS (Continued)

DESCRIPTION	PAGE
M	
MAIN LIFT CYLINDER.....	7-12
MAST MOUNTING.....	7-14
MASTER CYLINDER.....	5-4
N	
NON-SUSPENSION SEAT.....	1-16
O	
OUTER, INTERMEDIATE, AND INNER MAST.....	7-2
OVERHEAD GUARD.....	1-12
P	
PARK BRAKE	
LEVER ACTUATED.....	5-8
SEAT ACTUATED	
S/N PENDING PER ECN 64854⇒.....	5-20
⇒S/N PENDING PER ECN 64854.....	5-18
PARK BRAKE LINKAGE	
SEAT ACTUATED	
S/N PENDING PER ECN 64854⇒.....	5-16
⇒S/N PENDING PER ECN 64854.....	5-12
S	
SHIFT LEVER.....	4-4
SIDE-SHIFT CYLINDER.....	7-28
STEERING AXLE	
⇒S/N C210V-01653X.....	4-22
S/N C210V-01654X⇒.....	4-26
STEERING AXLE GUIDANCE.....	4-32
STEERING CONTROL UNIT	
OPTION 1.....	4-6
OPTION 2.....	4-30
STEERING CYLINDER.....	4-10
STEERING HYDRAULIC.....	4-8
STEERING MOTOR	
WITH BWI	
S/N C210V-01744A⇒.....	4-20
⇒S/N C210Y-01743A.....	4-18
WITHOUT BWI	
⇒S/N C210V-01743A.....	4-14
S/N C210V-01744A⇒.....	4-16
STEERING POD.....	4-2
STROBE LIGHT.....	8-8
SUSPENSION SEAT.....	1-18
T	
TIRE AND WHEEL.....	8-2
TRACTION MOTOR	
11.0-INCH.....	3-14
9-INCH.....	3-12

TABLE OF CONTENTS (Continued)

DESCRIPTION	PAGE
T (continued)	
TRANSMISSION AND DIFFERENTIAL	3-6
TRAVERSE BOOM	7-16
TRAVERSE CYLINDER	7-26
TRAVERSE FRAME	
WITH SIDE-SHIFT	7-20
WITHOUT SIDE-SHIFT	7-24
W	
WIRE HARNESS	
CONTROL VALVE SWITCH	2-22
DASH	2-18
LIGHT	2-19
MAIN	2-20
REAR LIGHT	8-13
SWITCH	8-14
TRACTION CUT-OUT	8-24

ABBREVIATIONS QUICK REFERENCE SHEET

Listed below are abbreviations used in parts manuals to denote the following expressions:

TERM	DEFINITION	TERM	DEFINITION
Amp	Amperes	FRE	Freezer Environment
AR	As Required	in.	inches
BDI	Battery Discharge Indicators	LPG	Liquefied Petroleum Gas
BWI	Brush Wear Indicator	MAP	Manifold Absolute Pressure
CE	Communicator End	mm	millimeters
CRE	Corrosive Environment	MSTS	Microprocessor Spark Timing System
D/B	Date Break	NPT	National Pipe Threads
dbA	Decibel "A" Scale	O/S	Oversize
DE	Drive End	PTO	Power Take Off
ECH	Empty Container Handler	RPM	Revolutions per Minute
ECH-3	Empty Container Handler - 3 High Stacking	S/N	Serial Number
ECH-4	Empty Container Handler - 4 High Stacking	TMM	Truck Management Module
ECH-5	Empty Container Handler - 5 High Stacking	UL Type D	Diesel-Powered Safety Rating
ECH-6	Empty Container Handler - 6 High Stacking	UL Type DS	Diesel-Powered Safety Rating
ECH-7	Empty Container Handler - 7 High Stacking	UL Type E	Battery-Powered Safety Rating
ECM	Electronic Control Module	UL Type EE	Battery-Powered Safety Rating
ECN	Engineering Change Notice	UL Type ES	Battery-Powered Safety Rating
EEPROM	Electrically Erasable Programmable Read Only Memory	UL Type G	Gasoline-Powered Safety Rating
EPROM	Electrically Programmable Read Only Memory	UL Type GS	Gasoline-Powered Safety Rating
		UL Type LP	Gas-Powered Safety Rating
		UL Type LPS	LP Gas-Powered Safety Rating
		U/S	Undersize
		UL	Underwriters Laboratory
		V	Volts

Please Click Here To Download The Complete Manual
Download Other Manuals
If Having Any Questions Feel Free To Contact us

admin@servicemanualbit.com