

# **PARTS MANUAL**

## **CHALLENGER**

**H150H, H165H, H180H, H200HS,  
H200H, H225H, H250H & H275H  
(H7.00HS, H7.50H, H8.00H,  
H9.00HS H9.00H, H10.00H,  
H11.50H & H12.50H)**


**P150B & P200B  
(P7.00B & P9.00B)**

**(C007)**

**CUSTOMER EDITION**

# ***HYSTER***

## ILLUSTRATED CONTENTS



REF	SECTION	PAGE
1	FRAME .....	Page 3
2	ENGINE .....	Page 23
3	FUEL SYSTEM .....	Page 93
4	ELECTRICAL SYSTEM .....	Page 139
5	CLUTCH .....	Page 163
6	TRANSMISSION .....	Page 171
7	DRIVE AXLE .....	Page 209
8	BRAKE SYSTEM .....	Page 225
9	STEERING SYSTEM .....	Page 245
10	HYDRAULIC SYSTEM .....	Page 253
11	MAST .....	Page 287
12	OPTIONAL EQUIPMENT .....	Page 317
..	NUMERIC INDEX .....	Page 361

## TABLE OF CONTENTS

DESCRIPTION	PAGE
<b>A</b>	
AIR COMPRESSOR (Figure 122) USED ON S/N C7D-1501 ⇒ C7D-1891, AND C7N-1501 ⇒ C7N-1524, FIRST USED ON C7A-2257, C7H-1542, C7P-3501 AND C7S-1589 .....	Page 238
AIR COMPRESSOR (Figure 123) FIRST USED ON S/N C7D-1892 AND C7N-1525 .....	Page 240
AIR COMPRESSOR USED ON S/N C7D-1501 ⇒ C7D-1891, AND C7N-1501 ⇒ C7N-1524, FIRST USED ON C7A-2257, C7H-1542, C7P-3501 AND C7S-1589 .....	Page 239
AIR FILTER (Figure 73) GASOLINE AND LPG .....	Page 132
AIR FILTER (Figure 74) DETROIT DIESEL .....	Page 134
AIR FILTER (Figure 75) PERKINS DIESEL .....	Page 136
ALTERNATOR BRACKET (Figure 81) .....	Page 154
ALTERNATOR (Figure 82) LAST USED ON S/N C7D-2752 .....	Page 156
ALTERNATOR (Figure 83) FIRST USED ON S/N C7D-2753 .....	Page 158
ALTERNATOR (Figure 84) LAST USED ON S/N C7D-2753 .....	Page 160
AUXILIARY DRIVE (Figure 32) 6-354 DIESEL LAST USED ON S/N C7P-2573 AND C7S-1517 .....	Page 63
AUXILIARY DRIVE (Figure 41) 6-354.4 DIESEL FIRST USED ON S/N C7D-1501, C7H-1501, C7P-2574 AND C7S-1518 .....	Page 78
<b>B</b>	
BRAKE CHAMBER (Figure 117) HEAVY DUTY AIR BRAKE .....	Page 228
BRAKE (Figure 118) AIR ACTIVATED FIRST USED ON S/N C7A-2257, C7D-1501, C7H-1542, C7P-3501 AND C7S-1589 .....	Page 230

## TABLE OF CONTENTS

DESCRIPTION	PAGE
<b>B (Continued)</b>	
BRAKE (Figure 119) HYDRAULICALLY ACTIVATED .....	Page 232
BRAKE LINKAGE (Figure 116) AIR BRAKE FIRST USED ON S/N C7A-2257, C7D-1501, C7H-1542, C7P-3501 AND C7S-1589 .....	Page 226
BRAKE LINKAGE (Figure 120) HYDRAULIC BRAKE .....	Page 234
BRAKE PEDAL (Figure 121) .....	Page 236
<b>C</b>	
CAB (Figure 169) TWO DOOR .....	Page 334
CAB GLASS (Figure 178) TWO DOOR CAB .....	Page 352
CAMSHAFT, CRANKSHAFT AND PISTONS (Figure 12) V8-350 GASOLINE AND LPG LAST USED ON 5W 1985 SERIES ENGINE .....	Page 28
CAMSHAFT, CRANKSHAFT AND PISTONS (Figure 19) V8-350 GASOLINE AND LPG FIRST USED ON 6W 1986 SERIES ENGINE .....	Page 42
CAMSHAFT, CRANKSHAFT AND PISTONS V8-350 GASOLINE AND LPG FIRST USED ON 6W 1986 SERIES ENGINE .....	Page 43
CARBURETOR (Figure 52) V8-350 GASOLINE .....	Page 100
CARRIAGE (Figure 161) H150H-H200HS (H7.00H-H9.00HS) .....	Page 314
CARRIAGE (Figure 162) H200H-H275H AND P150-200B (H9.00H-H12.50H AND P7.00-9.00B) .....	Page 315
CHARGE PUMP (Figure 101) POWERSHIFT .....	Page 194
CLUTCH LINKAGE (Figure 86) OIL CLUTCH .....	Page 166

**TABLE OF CONTENTS**

<b>DESCRIPTION</b>	<b>PAGE</b>
<b>C (Continued)</b>	
CONTROL KNOBS (Figure 181) .....	Page 359
CONTROL VALVE ATTACHING PARTS (Figure 137) .....	Page 268
CONTROL VALVE ATTACHING PARTS (Figure 140) ONE FUNCTION .....	Page 274
CONTROL VALVE ATTACHING PARTS (Figure 142) TWO FUNCTION .....	Page 278
CONTROL VALVE ATTACHING PARTS (Figure 144) THREE FUNCTION .....	Page 282
CONTROL VALVE (Figure 100) POWERSHIFT FIRST USED ON S/N C7D-1501, C7H-1501, C7P-2574 AND C5S-1518 .....	Page 192
CONTROL VALVE (Figure 141) ONE FUNCTION .....	Page 276
CONTROL VALVE (Figure 143) TWO FUNCTION .....	Page 280
CONTROL VALVE (Figure 145) THREE FUNCTION .....	Page 284
COOLING (Figure 44) .....	Page 82
COUNTERWEIGHT (Figure 5) .....	Page 10
COWL AND FLOORPLATES (Figure 2) .....	Page 4
CRANKSHAFT, PISTONS AND FLYWHEEL (Figure 26) 6-354 DIESEL LAST USED ON S/N C7P-2573 AND C7S-1517 .....	Page 54
CRANKSHAFT, PISTONS AND FLYWHEEL (Figure 35) 6-354.4 DIESEL FIRST USED ON S/N C7D-1501, C7H-1501, C7P-2574 AND C7S-1518 .....	Page 68
CYLINDER BLOCK (Figure 11) V8-350 GASOLINE LAST USED ON 8W 1978 SERIES ENGINE .....	Page 26
CYLINDER BLOCK (Figure 16) V8-350 GASOLINE AND LPG USED ON 9W 1979 ⇒ 5W 1985 SERIES ENGINE .....	Page 36

## TABLE OF CONTENTS

DESCRIPTION	PAGE
<b>C (Continued)</b>	
CYLINDER BLOCK (Figure 18) V8-350 GASOLINE AND LPG FIRST USED ON 6W 1986 SERIES ENGINE .....	Page 40
CYLINDER BLOCK (Figure 25) 6-354 DIESEL LAST USED ON S/N C7P-2573 AND C7S-1517 .....	Page 52
CYLINDER BLOCK (Figure 34) 6-354.4 DIESEL FIRST USED ON S/N C7D-1501, C7H-1501, C7P-2574 AND C7S-1518 .....	Page 66
CYLINDER (Figure 167) PULPWOOD BOOM PIVOT .....	Page 331
CYLINDER (Figure 168) PULPWOOD BOOM TRIP .....	Page 332
CYLINDER HEAD (Figure 13) V8-350 GASOLINE AND LPG LAST USED ON 5W 1985 SERIES ENGINE .....	Page 30
CYLINDER HEAD (Figure 20) V8-350 GASOLINE AND LPG FIRST USED ON 6W 1986 SERIES ENGINE .....	Page 44
CYLINDER HEAD (Figure 27) 6-354 DIESEL LAST USED ON S/N C7P-2573 AND C7S-1517 .....	Page 56
CYLINDER HEAD (Figure 36) 6-354.4 DIESEL FIRST USED ON S/N C7D-1501, C7H-1501, C7P-2574 AND C7S-1518 .....	Page 70
<b>D</b>	
DIFFERENTIAL AND CARRIER (Figure 113) WITH PLANETARY AXLE .....	Page 216
DIFFERENTIAL (Figure 112) WITHOUT PLANETARY AXLE H150-250H (H7.00-11.50H) .....	Page 214
DISTRIBUTOR (Figure 78) V8-350 GASOLINE AND LPG .....	Page 148

## TABLE OF CONTENTS

DESCRIPTION	PAGE
<b>D (Continued)</b>	
DRIVE AXLE AND HUB (Figure 110) WITHOUT PLANETARY FINAL DRIVE H150-250H (H7.00-11.50H) .....	Page 210
DRIVE AXLE MOUNT (Figure 111) PLANETARY FINAL DRIVE .....	Page 212
DRIVE SHAFT (Figure 102) POWERSHIFT .....	Page 195
DRIVE SHAFT (Figure 93) OIL CLUTCH .....	Page 180
DROP BOX (Figure 107) .....	Page 204
<b>E</b>	
ELECTRICAL SYSTEM (Figure 76) V8-350 GASOLINE AND LPG .....	Page 140
ELECTRICAL SYSTEM (Figure 77) PERKINS AND DETROIT DIESEL .....	Page 144
ENGINE GUARDS (Figure 24) GASOLINE AND LPG .....	Page 50
ENGINE MOUNTS (Figure 43) .....	Page 80
EXHAUST (Figure 48) GASOLINE AND LPG .....	Page 90
EXHAUST (Figure 49) DETROIT DIESEL .....	Page 91
EXHAUST (Figure 50) PERKINS DIESEL .....	Page 92
<b>F</b>	
FIRE EXTINGUISHER (Figure 177) .....	Page 351
FLOW CONTROL VALVE (Figure 146) .....	Page 286
FORKS (Figure 179) IDENTIFY BY PART NUMBER .....	Page 354

## TABLE OF CONTENTS

<b>DESCRIPTION</b>	<b>PAGE</b>
<b>F (Continued)</b>	
FORWARD/REVERSE CLUTCH (Figure 95) POWERSHIFT .....	Page 184
FORWARD/REVERSE CONTROLS (Figure 106) OIL CLUTCH .....	Page 202
FORWARD/REVERSE GEAR BOX (Figure 91) OIL CLUTCH .....	Page 176
FUEL (Figure 55) PERKINS DIESEL .....	Page 106
FUEL (Figure 59) DETROIT DIESEL .....	Page 114
FUEL FILTER (Figure 61) .....	Page 118
FUEL INJECTION (Figure 57) 6-354 DIESEL LAST USED ON S/N C7P-2573 AND C7S-1517 .....	Page 110
FUEL INJECTION (Figure 58) 6-354.4 DIESEL FIRST USED ON S/N C7A-1501, C7D-1501, C7P-2574 AND C7S-1518 .....	Page 112
FUEL SYSTEM (Figure 51) V8-350 GASOLINE .....	Page 96
FUEL SYSTEM (Figure 53) LPG LAST USED ON S/N C7A-2885 AND C7D-2067 .....	Page 102
FUEL SYSTEM (Figure 54) LPG FIRST USED ON S/N C7A-2886 AND C7D-2068 .....	Page 104
<b>H</b>	
HEADER HOSES (Figure 160) .....	Page 312
HEAT EXCHANGER (Figure 108) POWERSHIFT .....	Page 206
HEATER AND DEFROSTER (Figure 174) .....	Page 346
HIGH SPEED CLUTCH (Figure 96) POWERSHIFT .....	Page 186



**TABLE OF CONTENTS**

<b>DESCRIPTION</b>	<b>PAGE</b>
<b>H (Continued)</b>	
HOOD AND LINKAGE (Figure 3) .....	Page 6
HYDRAULIC OIL FILTER (Figure 87) OIL CLUTCH .....	Page 168
HYDRAULIC PUMP (Figure 131) .....	Page 258
HYDRAULIC SYSTEM (Figure 129) .....	Page 254
HYDRAULIC TANK (Figure 130) .....	Page 257
<b>I</b>	
INCHING CONTROL (Figure 104) POWERSHIFT .....	Page 198
<b>L</b>	
LABELS AND PAINT (Figure 4) .....	Page 8
LIFT CYLINDER (Figure 157) H150H-H180H AND H200HS (H7.00H-H8.00H AND H9.00HS) .....	Page 308
LIFT CYLINDER (Figure 158) H200H-H275H (H9.00H-H12.50H) .....	Page 309
LIFT CYLINDER (Figure 159) P150-200B (P7.00-9.00B) .....	Page 310
LIFT CYLINDER GUARD (Figure 176) .....	Page 350
LIFT (Figure 152) H150H-H180H (H7.00H-H8.00H) .....	Page 298
LIFT (Figure 153) H200HS (H9.00HS) .....	Page 300
LIFT (Figure 154) H200H-H250H (H9.00H-H11.50H) .....	Page 302
LIFT (Figure 155) H275H (H12.50H) .....	Page 304
LIFT (Figure 156) P150-200B (P7.00-9.00B) .....	Page 306

## TABLE OF CONTENTS

DESCRIPTION	PAGE
<b>L (Continued)</b>	
LIFT PUMP AND WATER SEPARATOR FILTER (Figure 60) 6-354 DIESEL LAST USED ON S/N C7P-2573 AND C7S-1517 .....	Page 116
LIGHTS (Figure 175) .....	Page 348
LOW PRESSURE FUEL (Figure 56) 6-354.4 DIESEL FIRST USED ON S/N C7A-1501, C7D-1501, C7P-2574 AND C7S-1518 .....	Page 108
LPG CARBURETOR (Figure 66) .....	Page 124
LPG CONVERTER (Figure 65) .....	Page 122
LPG LOCK-OFF FILTER (Figure 64) .....	Page 121
LPG TANK (Figure 63) .....	Page 120
<b>M</b>	
MAIN CONTROL VALVE (Figure 138) LAST USED ON S/N C7H-1522, C7P-2812 AND C7S-1543 .....	Page 270
MAIN CONTROL VALVE (Figure 139) FIRST USED ON S/N C7A-1501, C7D-1501, C7H-1523, C7P-2813 AND C7S-1544 .....	Page 272
MANIFOLDS (Figure 14) V8-350 GASOLINE LAST USED ON 8W 1978 SERIES ENGINE .....	Page 32
MANIFOLDS (Figure 17) V8-350 GASOLINE AND LPG USED ON 9W 1979 ⇒ 5W 1985 SERIES ENGINE .....	Page 38
MANIFOLDS (Figure 21) V8-350 GASOLINE AND LPG FIRST USED ON 6W 1986 SERIES ENGINE .....	Page 46
MANIFOLDS (Figure 29) 6-354 DIESEL LAST USED ON S/N C7P-2573 AND C7S-1517 .....	Page 58
MANIFOLDS (Figure 39) 6-354.4 DIESEL FIRST USED ON S/N C7D-1501, C7H-1501, C7P-2574 AND C7S-1518 .....	Page 76

## TABLE OF CONTENTS

DESCRIPTION	PAGE
<b>M (Continued)</b>	
MEDIUM SPEED PLANET (Figure 97) POWERSHIFT .....	Page 187
MONOTROL PEDAL (Figure 109) POWERSHIFT .....	Page 208
<b>O</b>	
OIL CLUTCH (Figure 85) .....	Page 164
OIL FILTER (Figure 33) 6-354 DIESEL LAST USED ON S/N C7P-2573 AND C7S-1517 .....	Page 64
OIL FILTER (Figure 42) 6-354.4 DIESEL FIRST USED ON S/N C7D-1501, C7H-1501, C7P-2574 AND C7S-1518 .....	Page 79
OIL PAN AND PUMP (Figure 30) 6-354 DIESEL LAST USED ON S/N C7P-2573 AND C7S-1517 .....	Page 60
OIL PAN AND PUMP (Figure 38) 6-354.4 DIESEL FIRST USED ON S/N C7D-1501, C7H-1501, C7P-2574 AND C7S-1518 .....	Page 74
OIL PAN (Figure 15) V8-350 GASOLINE AND LPG LAST USED ON 5W 1985 SERIES ENGINES .....	Page 34
OIL PAN (Figure 22) V8-350 GASOLINE AND LPG FIRST USED ON 6W 1986 SERIES ENGINES .....	Page 48
OIL PUMP (Figure 23) V8-350 GASOLINE AND LPG .....	Page 49
OPERATOR PROTECTION GUARD (Figure 166) .....	Page 330
OUTER AND INNER MASTS (Figure 147) H150H-H180H (H7.00H-H8.00H) .....	Page 288
OUTER AND INNER MASTS (Figure 148) H200HS (H9.00HS) .....	Page 290
OUTER AND INNER MASTS (Figure 149) H200H-H250H (H9.00H-H11.50H) .....	Page 292

## TABLE OF CONTENTS

<u>DESCRIPTION</u>	<u>PAGE</u>
<b>O (Continued)</b>	
OUTER AND INNER MASTS (Figure 150) H275H (H12.50H) .....	Page 294
OUTER AND INNER MASTS (Figure 151) P150-200B (P7.00-9.00B) .....	Page 296
OUTPUT PLANET (Figure 98) POWERSHIFT .....	Page 188
<b>P</b>	
PARK BRAKE (Figure 124) .....	Page 242
PLANETARY DRIVE AXLE (Figure 114) HYDRAULIC BRAKE H150-275H AND P150-200B (H7.00-12.50H AND P7.00-9.00B) .....	Page 220
PLANETARY DRIVE AXLE (Figure 115) AIR BRAKE FIRST USED ON S/N C7A-2257, C7D-1501, C7H-1542, C7P-3501 AND C7S-1589 .....	Page 222
PUBLICATIONS (Figure 1) .....	Page 1
PULPWOOD LOADER (Figure 164) PIVOTING BOOM .....	Page 326
PULPWOOD LOADER (Figure 165) RIGID BOOM .....	Page 328
PUMP DRIVE SHAFT (Figure 134) .....	Page 264
<b>R</b>	
RANGE SELECTOR (Figure 105) POWERSHIFT .....	Page 200
REGULATOR AND PUMP (Figure 88) OIL CLUTCH .....	Page 169
<b>S</b>	
SEAT (Figure 6) NON-ADJUSTABLE SUSPENSION AND NON-SUSPENSION LAST USED ON S/N C7D-2674 .....	Page 12
SEAT (Figure 7) ADJUSTABLE SUSPENSION LAST USED ON S/N C7D-2674 .....	Page 14

## TABLE OF CONTENTS

DESCRIPTION	PAGE
<b>S (Continued)</b>	
SEAT (Figure 8) NON-ADJUSTABLE SUSPENSION AND NON-SUSPENSION FIRST USED ON S/N C7D-2675 .....	Page 16
SEAT (Figure 9) ADJUSTABLE SUSPENSION FIRST USED ON S/N C7D-2675 .....	Page 18
SHIFT LINKAGE (Figure 92) OIL CLUTCH .....	Page 178
SIDESHIFT CARRIAGE (Figure 172) .....	Page 342
SIDESHIFT CYLINDER (Figure 173) .....	Page 344
SOUND LINERS (Figure 170) .....	Page 338
STARTER (Figure 79) V8-350 GASOLINE, LPG AND DETROIT DIESEL .....	Page 150
STARTER (Figure 80) PERKINS DIESEL .....	Page 152
STEER AXLE (Figure 126) .....	Page 248
STEER CYLINDER (Figure 128) .....	Page 252
STEERING PUMP AND COLUMN (Figure 127) .....	Page 250
STEERING SYSTEM (Figure 125) .....	Page 246
STROBE LIGHT (Figure 180) .....	Page 358
<b>T</b>	
THROTTLE LINKAGE (Figure 67) PERKINS DIESEL LAST USED ON S/N C7P-2573 AND C7S-1517 .....	Page 126
THROTTLE LINKAGE (Figure 68) PERKINS DIESEL FIRST USED ON S/N C7D-1501, C7H-1501, C7P2574 AND C7S-1518 .....	Page 127
THROTTLE LINKAGE (Figure 69) DETROIT DIESEL .....	Page 128

## TABLE OF CONTENTS

DESCRIPTION	PAGE
<b>T (Continued)</b>	
THROTTLE LINKAGE (Figure 70) GASOLINE AND LPG .....	Page 129
THROTTLE LINKAGE (Figure 71) OIL CLUTCH .....	Page 130
THROTTLE LINKAGE (Figure 72) POWERSHIFT .....	Page 131
TILT CYLINDER (Figure 132) LAST USED ON S/N C7H-1508 AND C7P-2752 .....	Page 260
TILT CYLINDER (Figure 133) FIRST USED ON S/N C7A-1501, C7D-1501, C7H-1509, C7P-2753 AND C7S-1501 .....	Page 262
TILT VALVE (Figure 135) LAST USED ON S/N C7H-1617, C7P-2864 AND C7S-1532 .....	Page 265
TILT VALVE (Figure 136) FIRST USED ON S/N C7A-1501, C7D-1510, C7H-1618, C7P-2865 AND C7S-1533 .....	Page 266
TIMING GEAR (Figure 31) 6-354 DIESEL LAST USED ON S/N C7P-2573 AND C7S-1517 .....	Page 62
TIMING GEAR (Figure 40) 6-354.4 DIESEL FIRST USED ON S/N C7D-1501, C7H-1501, C7P-2574 AND C7S-1518 .....	Page 77
TIRE AND WHEEL (Figure 163) P150-200B (P7.00-9.00B) .....	Page 318
TORQUE CONVERTER (Figure 99) POWERSHIFT .....	Page 190
TRANSMISSION (Figure 90) OIL CLUTCH .....	Page 174
TRANSMISSION (Figure 94) POWERSHIFT .....	Page 182
TRANSMISSION HYDRAULICS (Figure 103) POWERSHIFT .....	Page 196
TRANSMISSION MOUNTS (Figure 89) .....	Page 172

## TABLE OF CONTENTS

<u>DESCRIPTION</u>	<u>PAGE</u>
<b>V</b>	
VALVE GEAR AND COVER (Figure 37) 6-354.4 DIESEL FIRST USED ON S/N C7D-1501, C7H-1501, C7P-2574 AND C7S-1518 .....	Page 72
VALVE GEAR AND COVER(Figure 28) 6-354 DIESEL LAST USED ON S/N C7P-2573 AND C7S-1517 .....	Page 57
<b>W</b>	
WATER PUMP AND FAN (Figure 45) DETROIT DIESEL, GASOLINE AND LPG .....	Page 84
WATER PUMP AND FAN (Figure 46) PERKINS 6-354 DIESEL LAST USED ON S/N C7P-2573 AND C7S-1517 .....	Page 86
WATER PUMP AND FAN (Figure 47) PERKINS 6-354.4 DIESEL FIRST USED ON S/N C7D-1501, C7H-1501, C7P-2574 AND C7S-1518 .....	Page 88
WATER SEPARATOR FILTER (Figure 62) PERKINS DIESEL 6-354.4 FIRST USED ON S/N C7D-1501, C7P-2574 AND C7S-1518 .....	Page 119
WIPER MOTOR (Figure 171) .....	Page 340

**Please Click Here To Download The Complete Manual**  
**Download Other Manuals**  
**If Having Any Questions Feel Free To Contact us**

**[admin@servicemanualbit.com](mailto:admin@servicemanualbit.com)**