

PARTS MANUAL

W40Z (B218)

W45Z (C215)

CUSTOMER EDITION

HYSTER

SECTIONS

1	FRAME/DRIVE UNIT	
2	ELECTRICAL SYSTEM	
3	STEER HANDLE/BRAKE SYSTEM	
4	LIFT LINKAGE AND FORKS	
5	HYDRAULIC SYSTEM	
6	OPTIONS	
7	NUMERICAL INDEX	

This Parts Manual is divided into 7 major sections which are listed above. Quick reference to these sections can be made by placing the right thumb on the tab of the desired section, bending the book back and thumbing the pages to the corresponding tab.

TABLE OF CONTENTS

DESCRIPTION	PAGE
B	
BATTERY AND CHARGER ASSEMBLY	
B218.....	6-4.. 2-
C215	6-2
BATTERY ROLLER	
C215	6-6
BATTERY SPACER	
C215	2-2
BATTERY TRAY	
B218.....	2-12
C	
CASTER ASSEMBLY	6-8
CONTROL PANEL ASSEMBLY	
B218.....	2-6
C215	2-8
COVERS	1-2
D	
DECAL AND PLATE LOCATION	1-4
DRIVE MOTOR	
12/24V.....	2-10
DRIVE UNIT AND BRAKE ASSEMBLY	
12/24V.....	1-6
F	
FORK AND FRAME WELDMENT	
B218.....	4-2
C215	4-4
FORK AND FRAME WELDMENT OPTION WITH BOLT-ON LOAD BACKREST	
C215.....	6-10
H	
HYDRAULIC POWER UNIT	
B218.....	5-2
C215	
12V	5-4
24V	5-6
HYDRAULIC SYSTEM	
B218.....	5-8
C215	
12V	5-10
24V	5-12
L	
LIFT CYLINDER ASSEMBLY	5-14
LOAD BACKREST	
B218.....	6-12
C215	6-14
LOAD WHEEL AND LINK ASSEMBLY	4-6

TABLE OF CONTENTS (Continued)

DESCRIPTION	PAGE
L (continued)	
LOWER LINK	4-8
P	
POWER HEAD ASSEMBLY	1-10
S	
STABILIZER	6-16
STEER ARM ASSEMBLY	3-2
STEER HANDLE ASSEMBLY	3-4
U	
UPPER LINK	4-10

ABBREVIATIONS QUICK REFERENCE SHEET

Listed below are abbreviations used in parts manuals to denote the following expressions:

TERM	DEFINITION	TERM	DEFINITION
Amp	Amperes	FRE	Freezer Environment
AR	As Required	in.	inches
BDI	Battery Discharge Indicators	LPG	Liquefied Petroleum Gas
BWI	Brush Wear Indicator	MAP	Manifold Absolute Pressure
CE	Communicator End	mm	millimeters
CRE	Corrosive Environment	MSTS	Microprocessor Spark Timing System
D/B	Date Break	NPT	National Pipe Threads
dbA	Decibel "A" Scale	O/S	Oversize
DE	Drive End	PTO	Power Take Off
ECH	Empty Container Handler	RPM	Revolutions per Minute
ECH-3	Empty Container Handler - 3 High Stacking	S/N	Serial Number
ECH-4	Empty Container Handler - 4 High Stacking	TMM	Truck Management Module
ECH-5	Empty Container Handler - 5 High Stacking	UL Type D	Diesel-Powered Safety Rating
ECH-6	Empty Container Handler - 6 High Stacking	UL Type DS	Diesel-Powered Safety Rating
ECH-7	Empty Container Handler - 7 High Stacking	UL Type E	Battery-Powered Safety Rating
ECM	Electronic Control Module	UL Type EE	Battery-Powered Safety Rating
ECN	Engineering Change Notice	UL Type ES	Battery-Powered Safety Rating
EEPROM	Electrically Erasable Programmable Read Only Memory	UL Type G	Gasoline-Powered Safety Rating
EPROM	Electrically Programmable Read Only Memory	UL Type GS	Gasoline-Powered Safety Rating
		UL Type LP	Gas-Powered Safety Rating
		UL Type LPS	LP Gas-Powered Safety Rating
		U/S	Undersize
		UL	Underwriters Laboratory
		V	Volts

Please Click Here To Download The Complete Manual
Download Other Manuals
If Having Any Questions Feel Free To Contact us

admin@servicemanualbit.com