

## 407B ZX, 408B ZX, 409B Z, 410B ZX, 411B ZX

[Section 1 - General Information](#)

[Section 2 - Care and Safety](#)

[Section 3 - Maintenance](#)

[Section B - Body and Framework](#)

[Section C - Electrics](#)

[Section E - Hydraulics](#)

[Section F - Transmission](#)

[Section G - Brakes](#)

[Section H - Hydraulic Steering](#)

[Section K - Engine](#)



Publication No.  
**9803/4210-08**



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

Issued by JCB Technical Publications, JCB Aftermarket Training, Woodseat, Rocester, Staffordshire, ST14 5BW, England. Tel +44 1889 591300 Fax +44 1889 591400

World Class  
Customer Support

**Notes:**

# Section 1



## General Information

Service Manual - 407B ZX, 408B ZX, 409B Z, 410B ZX, 411B ZX

[Section 1 - General Information](#)

[Section 2 - Care and Safety](#)

[Section 3 - Maintenance](#)

[Section B - Body and Framework](#)

[Section C - Electrics](#)

[Section E - Hydraulics](#)

[Section F - Transmission](#)

[Section G - Brakes](#)

[Section H - Hydraulic Steering](#)

[Section K - Engine](#)



Publication No.  
**9803/4210-08**



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

Issued by JCB Technical Publications, JCB Aftermarket Training, Woodseat, Rocester, Staffordshire, ST14 5BW, England. Tel +44 1889 591300 Fax +44 1889 591400

World Class  
Customer Support



## Section 1 - General Information

---

**Notes:**



# Section 1 - General Information

---

| <b>Contents</b>                                                          | <b>Page No.</b> |
|--------------------------------------------------------------------------|-----------------|
| <b>Introduction</b>                                                      |                 |
| About this Publication .....                                             | 1 - 1           |
| <b>Identifying your Machine</b>                                          |                 |
| Identification Plates .....                                              | 1 - 2           |
| Identification Plate .....                                               | 1 - 2           |
| Explanation of Vehicle Identification Number (VIN) .....                 | 1 - 2           |
| Unit Identification .....                                                | 1 - 2           |
| Typical Engine Identification Number .....                               | 1 - 2           |
| <b>Torque Settings</b>                                                   |                 |
| JCB Standard Torque Settings B.S.P. Port Connection (Colour Coded) ..... | 1 - 4           |
| JCB Standard Torque Settings for Hose Ends and .....                     |                 |
| Flanged Fittings (Colour Coded) .....                                    | 1 - 5           |
| Zinc Plated Fasteners (golden finish) .....                              | 1 - 6           |
| UNF Grade `S' Bolts .....                                                | 1 - 6           |
| Metric Grade 8.8 Bolts .....                                             | 1 - 6           |
| Rivet Nut Bolts/Screws .....                                             | 1 - 6           |
| <b>Service Tools</b>                                                     |                 |
| Numerical List Section B - Body and Framework .....                      | 1 - 7           |
| Tool Detail Reference Section B - Body and Framework .....               | 1 - 8           |
| Numerical List Section C - Electrics .....                               | 1 - 11          |
| Tool Detail Reference Section C - Electrics .....                        | 1 - 12          |
| Numerical List Section E - Hydraulics .....                              | 1 - 13          |
| Tool Detail Reference Section E- Hydraulics .....                        | 1 - 15          |
| Numerical List Section F - Transmission .....                            | 1 - 18          |
| Tool Detail Reference Section F - Transmission .....                     | 1 - 19          |
| Numerical List Section K - Engine .....                                  | 1 - 22          |
| Tool Detail Reference Section K - Engine .....                           | 1 - 23          |
| <b>Service Consumables</b>                                               |                 |
| Sealing and Retaining Compounds .....                                    | 1 - 24          |

**Please Click Here To Download The Complete Manual**  
**Download Other Manuals**  
**If Having Any Questions Feel Free To Contact us**

**[admin@servicemanualbit.com](mailto:admin@servicemanualbit.com)**