

Service Manual



467 Wheeled Loading Shovel

[Section 1 - General Information](#)

[Section 2 - Care and Safety](#)

[Section 3 - Maintenance](#)

[Section A - Attachments](#)

[Section B - Body and Framework](#)

[Section C - Electrics](#)

[Section E - Hydraulics](#)

[Section F - Transmission](#)

[Section G - Brakes](#)

[Section H - Steering](#)

[Section K - Engine](#)



Publication No.
9813/0500-01



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

Issued by JCB Technical Publications, JCB Aftermarket Training, Woodseat, Rocester, Staffordshire, ST14 5BW, England. Tel +44 1889 591300 Fax +44 1889 591400

World Class
Customer Support



Section i - Front Cover

Notes:



Section 1

General Information

Service Manual - 467 Wheeled Loading Shovel

[Section 1 - General Information](#)

[Section 2 - Care and Safety](#)

[Section 3 - Maintenance](#)

[Section A - Attachments](#)

[Section B - Body and Framework](#)

[Section C - Electrics](#)

[Section E - Hydraulics](#)

[Section F - Transmission](#)

[Section G - Brakes](#)

[Section H - Steering](#)

[Section K - Engine](#)



Publication No.
9813/0500-01



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

World Class
Customer Support



Section 1 - General Information

Notes:



Section 1 - General Information

Contents	Page No.
Introduction	
About this Publication	1-1
Schematic Codes	1-2
Basic Operation	
Moving a Disabled Machine	1-5
Transporting the Machine	1-8
Lifting the Machine	1-11
Identifying the Machine	
Identification Plates	1-13
Torque Settings	
Zinc Plated Fasteners and Dacromet Fasteners	1-15
Service Tools	
Numerical List Section B - Body and Framework	1-19
Tool Detail Reference Section B - Body and Framework	1-20
Numerical List Section C - Electrics	1-23
Tool Detail Reference Section C - Electrics	1-24
Numerical List Section E - Hydraulics	1-26
Tool Detail Reference Section E - Hydraulics	1-28
Numerical List Section F - Transmission	1-30
Tool Detail Reference Section F - Transmission	1-31
Numerical List Section G - Brakes	1-34
Tool Detail Reference Section G - Brakes	1-35
Service Consumables	
Sealing and Retaining Compounds	1-37

**Please Click Here To Download The Complete Manual
Download Other Manuals
If Having Any Questions Feel Free To Contact us**

admin@servicemanualbit.com