

**workshop
manual for
3.152 series
diesel engines
3.152 D3.152
3.1522 3.1524
T3.1524 and
D3.152M, 3HD46
marine engines.**

©

Perkins Engines Limited

Peterborough, England

1991

All rights reserved

Publication No. TPD 1091 1208E

This publication supersedes the previous edition number
601 TPD 0786 1208.

*This publication is written in
Perkins Approved Clear English*

PACE

This Publication is written for world wide use. In countries where legislation controls engine smoke emission, noise, safety factors, etc., then all instructions, data and dimensions given must be applied so that, after service (preventive maintenance) or repair, the engine operation is correct to the local regulations.

Amendment status

Number	Description	Date
1	Note: Amendment page set number 1 is included in this manual.	November 1991

Contents

GENERAL INFORMATION	A
ENGINE VIEWS	B
TECHNICAL DATA	C
MAINTENANCE	D*
FAULT DIAGNOSIS	E
CYLINDER HEAD	F
PISTONS AND CONNECTING RODS	G
CYLINDER BLOCK AND LINERS	H
CRANKSHAFT AND MAIN BEARINGS	J
TIMING CASE AND DRIVE	K
TIMING	L
LUBRICATION SYSTEM	M
COOLING SYSTEM	N
FUEL SYSTEM	P
FLYWHEEL AND FLYWHEEL HOUSING	Q
ELECTRICAL SYSTEM	R
TURBOCHARGER	T
MARINE ENGINES	W
APPROVED SERVICE TOOLS	Y
INDEX	Z

* Operating and maintenance information can be found in section 3 of the multi-lingual 3.152 Series Users handbook

Please Click Here To Download The Complete Manual
Download Other Manuals
If Having Any Questions Feel Free To Contact us

admin@servicemanualbit.com