Group 2 Drive Unit

Special Tools (For Transmission Assembly and Disassembly)

Part Name	ST No.
Output Shaft Removal Tool	ST 7676
Stud Bolt (M16)	ST 7677
Nut (M16)	ST 7678

Part Name	ST No.
Bearing Pusher (For 33210)	ST 7650
Bearing Pusher (For 311)	ST 7653
Bearing Pusher (For 5313, 2213)	ST 7654
Bearing Pusher (For 7018)	ST 7671
Bearing Pusher (For 6014)	ST 7672
Bearing Pusher (For 5312)	ST 7673
Bearing Pusher (For 6010)	ST 7674
Bearing Pusher (For 6307)	ST 7675
Bearing Pusher (For 33212)	ST 7719

Group 2 Drive Unit

Part Name	ST No.
Solenoid Valve Removal Tool	ST 7679
Bolt (M6)	ST 7686

Part Name	ST No.
Shaft Rotation Tool (for FR Shaft)	ST 7655
Shaft Rotation Tool (for IDLER Shaft)	ST 7726
Shaft Rotation Tool (for OUTPUT Shaft)	ST 7657

Part Name	ST No.
Hydraulic Unit	ST 7688


Group 2 Drive Unit

Part Name	ST No.
Pre-Load Adjustment Tool (for FR)	ST 7620
Pre-Load Adjustment Tool (for FR)	ST 7621
Pre-Load Adjustment Tool (for F)	ST 7714
Pre-Load Adjustment Tool (for R)	ST 7715
Pre-Load Adjustment Tool (for FR) Bolt	ST 7665
Pre-Load Adjustment Tool (for FR) Ring	ST 7666
Pre-Load Adjustment Tool (for IDLER)	ST 7625
Pre-Load Adjustment Tool (for IDLER)	ST 7626
Pre-Load Adjustment Tool (for IDLER)	ST 7716
Pre-Load Adjustment Tool (for IDLER) Bolt	ST 7667
Pre-Load Adjustment Tool (for IDLER) Ring	ST 7668
Pre-Load Adjustment Tool (for RANGE)	ST 7630
Pre-Load Adjustment Tool (for RANGE)	ST 7717
Pre-Load Adjustment Tool (for RANGE)	ST 7718
Pre-Load Adjustment Tool (for RANGE) Bolt	ST 7669
Pre-Load Adjustment Tool (for RANGE) Ring	ST 7670


Group 2 Drive Unit

Drawings for Special Tools

Output Shaft Removal Tool




ST7676_90E



ST7677_90E

Group 2 Drive Unit



ST7678_90E

Thanks for your reading.

Please click here to download complete manual instantly.

And can also choose other manuals.

Feel free --->write to me with any questions.

Our service email:

manuals007@hotmail.com