



Form No.
904073

318/320 Finger Wheel V-Rakes

WR318



WR320



OPERATOR'S AND SERVICE PARTS MANUAL

GEHL[®] COMPANY

Warranty

GEHL COMPANY New Agricultural Equipment

GEHL Company (Incorporated), hereinafter referred to as **GEHL**, as manufacturer of quality machinery since 1859, warrants new **GEHL** machinery and/or attachments at the time of delivery to the original purchaser to be free from defects in material and workmanship if properly set up and operated in accordance with the recommendations set forth in **GEHL**'s Operator Manual.

GEHL's liability for any defect with respect to accepted goods shall be limited to repairing the goods at an authorized **GEHL** dealer or other **GEHL** designated location, or replacing them, as **GEHL** shall elect. The above shall be in accordance with **GEHL** warranty adjustment policies. **GEHL**'s obligation shall terminate twelve (12) months after the delivery of the goods to the original user or when the equipment is first put into use.

This warranty shall not apply to any machine or attachment which shall have been repaired or altered outside the **GEHL** factory or authorized **GEHL** dealership or in any way so as in **GEHL**'s judgment, to affect its stability or reliability, nor which has been subject to misuse, negligence or accident, nor to any machine or attachment which shall not have been operated in accordance with **GEHL**'s printed instructions or beyond the Company recommended machine rated capacity.

This warranty shall not be limited to items which are subject to the warranties of their respective manufacturers. Such items would include but would not be limited to engines, clutches, universal joints, knives, hydraulic components, bearings, tires, belts and other trade accessories.

EXCLUSION OF WARRANTIES

Except as otherwise expressly stated herein, **GEHL** makes no representation or warranty of any kind, express or implied, AND MAKES NO WARRANTY OF MERCHANTABILITY IN RESPECT TO ITS MACHINERY AND/OR ATTACHMENTS AND MAKES NO WARRANTY THAT ITS MACHINERY AND/OR ATTACHMENTS ARE FIT FOR ANY PARTICULAR PURPOSE. **GEHL** shall not be liable for incidental or consequential damages for any breach of warranty, including but not limited to inconvenience, rental or replacement equipment, loss of profits or other commercial loss. **GEHL** shall not be liable for, and the buyer assumes all liability for, all personal injury and property damage resulting from the handling, possession or use of the goods by the buyer.

No agent, employee or representative of **GEHL** has any authority to bind **GEHL** to any affirmation, representation or warranty concerning its machinery and/or attachments except as specifically set forth herein.

TABLE OF CONTENTS

Chapter	Description	Page
	Warranty	Inside Front Cover
1	Introduction	2
2	Specifications	3
3	Check Lists	5-7
4	Safety	8
5	Operation	9-11
6	Adjustments	12-14
7	Maintenance & Service	14
8	Set-up & Assembly	15-18
9	Decal Locations	20-21
10	Service Parts & Numerical Index	22-28
	Index	28
	Standard Hardware Torque	Inside Back Cover

Thanks for your reading.

Please click here to download complete manual instantly.

And can also choose other manuals.

Feel free --->write to me with any questions.

Our service email:

manuals007@hotmail.com