

# 95 MX

"Mix-All" Mixer



Service Parts Manual

Form No.  
901532  
Replaces  
901088

>

Z

A

B

S

O

U

L

I

W

U

# 95MX - INTRODUCTION

## Mr. Dealer:

Give complete information when ordering service parts. Always give complete part numbers and also complete part description. The model number and serial number should always be given. Numbers for the Mixer are stamped on a plate located on the rear frame member below Concentrate Hopper. Hammer Mill numbers are located on the Left Frame Sheet. Hay Feeder numbers are located on the Roller Cover and Swinging Auger Feeder numbers are located on the right side of the Pivot Frame.

"Right" and "Left" are determined from a position standing at the rear of the Mixer and looking toward the Drawbar Hitch. The Mill Feeder is on the "Right" side and the Mixer Unloading Conveyor on the "Left" side.

**NOTE:** You will find common hardware such as nuts, bolts, etc. listed but not illustrated in parts lists in this manual. Hardware listed with the particular part is for mounting purposes and is not included when the part is ordered for replacement.

Gehl Company reserves the right to make changes or improvements in the design or construction of any part without incurring the obligation to install such changes on any unit previously delivered.

## Table of Contents

	Page
Introduction .....	2
Decal Locations .....	3-4
Transmission .....	5
Frame .....	6-7
Tank and Hopper .....	8-10
Mixer Drive .....	10
Power Take-Off Drive .....	11-13
Unloading Conveyor .....	14-15
Conveyor Drive .....	16-18
Mill Cylinder .....	19
Mill Frame and Blower .....	20-21
95SAF Feeder Trough .....	22-23
95SAF Feeder Drive .....	24-26
150HF Hay Feeder .....	27-29
150HF Hay Feeder Drive .....	30-31
150PBF Feeder Head (Used after Serial No. 1410) .....	32-34
150PBF Feeder Head (Used before Serial No. 1411) .....	35-38
150PBF Feed Conveyor .....	39-41
Accessories .....	42-43
150PBF Hydraulic Feeder Head .....	44-46
150PBF Hydraulic Feed Conveyor .....	48-49
Hydraulic Unloading Conveyor .....	50-51
Hydraulic Conveyor Drive .....	52-53
95SAF Hydraulic Feeder Trough .....	54-55
95SAF Hydraulic Feeder Drive .....	56-57
150HF Hydraulic Hay Feeder .....	58-59
Hydraulic System .....	60-61
Folding Conveyor .....	62-63
Hopper .....	64
Winch .....	65
Selector Valve .....	65
95MX/955AF Hydraulic Motor .....	66
955AF/150HF Flow Control Valve .....	66
150HF Hydraulic Motor .....	67
Selector Valve .....	67
95MX/955AF Hydraulic Motor .....	68
150HF Hydraulic Motor .....	68
Universal Drives .....	69-71
Hitch Jack .....	72
Numerical Index .....	73-79

Parts lists in this manual contain various abbreviations. Below is an explanation of these abbreviations.

HN - Hexagon Nut  
HJN - Hexagon Jam Nut  
HLN - Hexagon Lock Nut  
SN - Slotted Nut  
CN - Castellated Nut  
WN - Wing Nut  
  
PW - Plain Washer  
LW - Lock Washer

ILW - Internal Tooth Lock Washer  
ELW - External Tooth Lock Washer  
  
L.H. - Left-Hand Thread  
NF - National Fine Thread  
S-L - Self-Locking  
DPT - Double Pitch Tooth

## DECAL LOCATIONS

Decal locations are shown to assist in application of new decals in the event of damage to the decal or refinishing of the machine. Check below for their locations.

Surfaces must be free from dirt, dust, grease and other foreign material before applying decals. To apply decals, remove the smaller portion of the decal backing paper and apply this part of the exposed adhesive backing to the clean surface in respective position. Peel other portion of the backing paper off slowly and apply decal.

The Decal Set Number for 95MX is 600157. The set includes the following Decals:

1 - 047974	Fast, Slow	16 - 053369	Gehl (5 x 46) - (Two Places)
2 - 041070	High, Low	17 - 053354	Be Careful (Two Places)
3 - 053370	Direction Arrow	18 - 042614	Do Not Operate Below Horizontal - Raise Flap
4 - 053456	Gehl Mix-All	19 - 053359	Grease Arrow
5 - 053351	Universal Drive Instructions	20 - 053366	Do Not Remove
6 - 042298	Lubricate Every 5 Hours	21 - 041066	6, 7, 8, 9, 10 - (Two Places)
7 - 050263	Shear Bolts	21 - 041067	1, 2, 3, 4, 5 - (Two Places)
8 - 053374	Be Careful and Chain Instructions	22 - 047803	Weights and Measurements (without Electronic Scale)
9 - 049062	Gehl - 21"	23 - 053514	Caution
10 - 041069	Important	24 - 053513	Remove Before Operating
11 - 041065	Important - Keep Belts Tight	25 - 052134	Instructions
12 - 053461	Clutch Pin Instructions	26 - 053890	Caution
13 - 049262	Adjust Chain	27 - 052162	High - Neutral - Low
14 - 049452	95 (Two Places)		
15 - 050202	Caution		



Thanks for your reading.

Please click [here](#) to download complete manual instantly.

And can also choose other manuals.

Feel free ---> write to me with any questions.

Our service email:

[manuals007@hotmail.com](mailto:manuals007@hotmail.com)