

SL7610, SL7710 (EU) and SL7810 Skid-Steer Loaders

Form No.
917031

Revision D
03/05



PARTS MANUAL

GEHL[®]

Introduction

For your safety and continued proper operation, use only genuine GEHL service parts. When ordering service parts, specify the correct part number, full description, quantity required, the unit model number and serial number.

The model and serial number decal for this unit is located behind the left lift cylinder. “Right” and “left” are determined from a position sitting on the seat and facing forward.

IMPORTANT

For SL7710 (EU) parts ordering information, use SL7610 parts, except where noted separately.

GEHL Company reserves the right to make changes or improvements in the design or construction of any part of the unit without incurring the obligation to install such changes on any previously delivered units.

NOTE: *Purchase equivalent-quality tires for your loader. Contact your dealer for replacement tire information.*

NOTE: *Replacement batteries are not provided by the GEHL Company. For battery specifications see “Electrical - Chassis” chapter. ALL REPLACEMENT BATTERIES MUST BE PURCHASED LOCALLY.*

Refer to the abbreviations table located on this page for the various fastener descriptions. Standard attaching hardware torque values are also provided on the inside back cover. **If a part requires lubrication or a nonstandard torque value, it will be specified behind the part number description in parenthesis.**

Items shown in the parts list that do not have part numbers are shown for reference purposes only and are NOT available for purchase.

Dimensions are in inches unless otherwise specified.

NOTE: *The following abbreviations and symbols may be used herein:*

A	Ampere
AR	As Required
ASSY	Assembly
AUX	Auxiliary
CCA	Cold Cranking Amperage
CYL	Cylinder
FOPS	Falling Object Protective Structure
FRT	Front
FL	Flare
GA	Gauge
HEX	Hexagon
HF	High Flow
HYD	Hydraulics
JIC	Joint Industrial Council
JS	Joystick
kW	Kilowatt
LBS	Pounds
LT	Left
M (m)	Meter
MM (mm)	Millimeter
NA	Naturally Aspirated
N/A	Not Applicable
NEG	Negative
NILN	Nylon Insert Lock Nut
NO	Number
N•m	Newton Meter
NPT	National Pipe Thread
OPER	Operator
PN	Part Number
POS	Positive
PSI	Pounds per Square Inch
QTY	Quantity
REF	Reference
REQ'D	Required
ROPS	Roll Over Protective Structure
RPM	Revolutions Per Minute
RT	Right
SAE	Society of Automotive Engineers
SN	Serial Number
SQ	Square
ST	Straight
TURBO	Turbocharged
V	Volt

TABLE OF CONTENTS

DESCRIPTION

PAGE

SECTION A: MAIN LOADER COMPONENTS

Chassis	1
Wheel Drives	9
Engine	11
Air Cleaner and Exhaust	15
Radiator and Cooler	19
Hydrostatic System with Drive Motors	25
Hydraulics - Chassis	31
Hydraulics - Lift Arm	43
Hydraulics - Auxiliary	45
Controls - Auxiliary Hydraulics	51
Controls - Lift and Tilt	55
Controls - Wheel Drives	63
Controls - Engine	69
Lift Arm	81
All-Tach™ and Power-A-Tach™ Hitch	83
ROPS and Interior	87
Seat	91
Restraint Bar	97
Electrical - Chassis	99
Electrical - ROPS	107
Electrical - Lights	113
Electrical - Controls	115
Ignition Switch	117
Tires	119
Decals	122

SECTION B: HYDRAULIC COMPONENTS

Drive Motor and Parking Brake - Single and Two Speed	133
Tandem Pump	137
Load-Sensing Axial Piston Pump	141
Self-Level Valve	145
Solenoid Valves - Lift and Tilt	147
Solenoid Valve - Brake	149
ROPS Lift-Assist Pump Valve	151
Lift Cylinder	153
Tilt Cylinder	155
Main Control Valve	157
Manifold - Hydraglide™ Ride Control	161

(continued on next page)

TABLE OF CONTENTS

DESCRIPTION

PAGE

SECTION C: KITS

Backup Alarm Kit 810387.	165
Engine Block Heater Kit 808203	166
Rear View Mirror Kit 806894	166
Strobe Light Kit 805803	167
Cab - Side Window Kit 808403	168
Cab - Front Door Kit 808624	169
Cab - Heater Kit 810445.	170
Cab - Heater Kit Service Parts Assemblies	171
Cab - Air Conditioning/Heater Combination Kit 810446.	172
Cab - Air Conditioning/Heater Combination Kit Service Parts Assemblies.	173
Impact Resistant Door Kit 810088	174
Single Point Lift Kit 810101	175
Pre-Cleaner Kit 810442	176
Electric ROPS/FOPS Lift Kit 810448.	177
Block Heater Kit 810441	178
Power-A-Tach™ Kit 810443	178
810588 Backup Alarm Kit (Joystick Controls)	179
Cab - Air Conditioning/Heater Combination Kit 810638.	180
Cab - Air Conditioning/Heater Combination Kit Service Parts Assemblies.	181
Cab - Heater Kit 810640.	183
Cab - Heater Kit Service Parts Assemblies	184
Numerical Index	186
O-Ring Table, Coupling & Adapter Torque Table	194

SECTION D: SCHEMATICS

Hydrostatic/Hydraulic Schematic	197
Hydrostatic/Hydraulic Schematic - Joystick Controls	198
HVAC Schematic - 810446	199
HVAC Schematic - 810638	200
Heater Schematic - 810640 Kit	201
ROPS/FOPS Electrical Schematic.	202
Chassis Electrical Schematic - Naturally Aspirated	203
Chassis Electrical Schematic - Turbocharged.	204

Torque Specifications Table	Inside Back Cover
---------------------------------------	-------------------

SECTION A: MAIN LOADER COMPONENTS

Chassis	1
Wheel Drives	9
Engine	11
Air Cleaner and Exhaust	15
Radiator and Cooler	19
Hydrostatic System with Drive Motors	25
Hydraulics - Chassis	31
Hydraulics - Lift Arm	43
Hydraulics - Auxiliary	45
Controls - Auxiliary Hydraulics	51
Controls - Lift and Tilt	55
Controls - Wheel Drives	63
Controls - Engine	69
Lift Arm	81
All-Tach™ and Power-A-Tach™ Hitch	83
ROPS and Interior	87
Seat	91
Restraint Bar	97
Electrical - Chassis	99
Electrical - ROPS	107
Electrical - Lights	113
Electrical - Controls	115
Ignition Switch	117
Tires	119
Decals	122

Thanks for your reading.

Please click here to download complete manual instantly.

And can also choose other manuals.

Feel free --->write to me with any questions.

Our service email:

manuals007@hotmail.com