

Werkstatt-Handbuch

STILL
ELECTRONIC
DOCUMENTATION
SYSTEM

Diesel- / Treibgas-Gabelstapler

R70-40
R70-45
R70-50



Ausgabe 05/2011

- Version 2 Beta
- Diverse Korrekturen in allen Kapiteln
- Kapitel 22 - „Mechanische Antriebsachse“ Radantrieb und Triebwerk überarbeitet.
- Kapitel 49 - „Mechanische Betriebsbremse“ Bremsgeber überarbeitet.
- Kapitel 50 - „Bedienelemente“ überarbeitet.
- Kapitel 56 - „Anzeigeelemente“ überarbeitet, die komplette Dokumentation der Anzeige-Bedieneinheit wurde in ein separates Werkstatt-Handbuch ausgegliedert.

- Kapitel 60 - „Elektrik / Elektronik“ überarbeitet.
- Kapitel 69 - „Batterie und Zubehör“ neu hinzu
-

Ausgabe 08/2008

- Version 1
- Erstausgabe
- Zu diesem Werkstatt-Handbuch gehört auch das Werkstatt-Handbuch „VW 2,0l Turbodiesel“

00 Produktinformation

Vorwort	00- 1
About the R70 4.0t - 5.0t	00- 1
Sicherheitshinweise	00- 2
Symbols Used	00- 2
Securing the fork carriage	00- 2
Working on live electrical components	00- 4

11 Elektromotor

Fahrmotor	11- 1
General technical data	11- 1
Electrical connections	11- 1
Traction drive	11- 2
Traction motor	11- 4
Drehzahlsensor	11- 6
Pin sensor	11- 6
Temperatursensor	11- 8
Temperature sensor KTY84	11- 8
Generator	11-10
General technical data	11-10
Alternator	11-11
Removing and installing the alternator	11-12

12 Verbrennungsmotor

Verbrennungsmotor	12- 1
Engine unit	12- 1
Engine unit Removal and installation	12- 2
Starter ring gear	12- 5
Starter motor	12- 6
Dieselmotor	12- 7
General technical data VW 2.0 I turbodiesel	12- 7
Diesel engine VW 2.0 I TDI	12- 8
Treibgasmotor	12-10
General technical data — VW 3.2 I TG	12-10
VW VR6 3.2 I LPG engine	12-11

13 Verbrennungsmotor - Anbauteile

Treibgasanlage	13- 1
Impco components	13- 1
Evaporator function - gas mixer	13- 2
Suction module	13- 4
0B6 MAP/MAT sensor	13- 6
Chassis module	13- 6
Actuator unit	13- 8
Gas shut-off valve unit	13- 9
Shut-down due to lack of gas	13-10
Maintenance and test specifications	13-11
Servicing the LPG filter	13-12
Testing CO level in exhaust gases	13-12
Evaporator - maintenance	13-15
Checking the evaporator for leaks	13-18
High-pressure relief valve - 1.7 bar	13-20
Treibgasflasche / -tank	13-21
LPG cylinder	13-21

14 Verbrennungsmotor - Abgasanlage

Abgasanlage - Treibgas	14- 1
Lambda control system	14- 1
Lambda sensor	14- 2
Three-way catalytic converter	14- 5

22 Mechanische Antriebsachse

Radantrieb	22- 1
Drive wheel unit	22- 1
Triebwerk	22- 5
General technical data Carraro EC 50 l	22- 5
Drive axle	22- 7
Removing/installing the drive axle	22- 8
Differential gearbox and brake	22-11
Removal of the differential gearbox and brake	22-13
Installation of the differential gearbox and brake	22-16

31 Chassis

Gegengewicht	31- 1
Counterweight	31- 1

42 Lenksystem

Hydraulische Lenkung	42- 1
General technical data	42- 1
Steering system	42- 2
Steering — error detection	42- 3
Steering unit	42- 4
Priority valve	42- 5

Lenkrad und Lenksäule	42- 6
Steering column	42- 6

Lenkachse	42- 8
General technical data	42- 8
Swing axle	42- 9
Removing/installing the swing axle	42-10
Wheel hub	42-11
Steering angle	42-14
Tie rod	42-15
Axle stub	42-16

49 Bremsanlage

Mechanische Betriebsbremse	49- 1
Service brake	49- 1
Brake sensor 1B2	49- 1
Removing/installing the service brake	49- 3
Changing the brake cable Service brake	49- 4
Handbremse	49- 6
Changing the brake cable Parking brake	49- 6
Parking brake switch	49- 8

50 Bedienelemente

Einpedal	50- 1
Accelerator – single-pedal	50- 1
Zweipedal	50- 4
Accelerator – double-pedal 1. Generation	50- 4

Bedienelemente	50- 9
Multi-levers	50- 9
Joystick	50-10
Joystick operation	50-11
Tip switch	50-13
Axle assignment	50-15
Depressurising the hydraulics	50-16
Direction of travel flasher module (Fabli)	50-17

56 Anzeigeelemente

Bedienkonsole	56- 1
Direction of travel flasher display	56- 1
Display	56- 3
Display operating unit (ABE 1) Generation 1	56- 3
ABE 1 Installation and removal	56- 5

60 Elektrik / Elektronik

Allgemein	60- 1
General technical data	60- 1
Übersicht der Steuerungen	60- 2
Electrical components	60- 2
Software compatibility	60- 4
PAN process	60- 5
Parameter management	60- 6
Error ring buffer	60- 7
Insulation measurement	60- 8
Traction motor temperature monitoring	60-13
Drive mode — driving behaviour Availability	60-14
Driving mode — driving behaviour Description	60-15
Blue-Q = IQ	60-17
Verkabelung	60-19
CAN bus connections	60-19
Elektrische Anlage	60-21
Brake resistor	60-21
Fuse box	60-22
Fuses	60-24
Relays	60-25

Sonstige Komponenten	60-27
Option board	60-27
CAN power port (CPP)	60-28
Soot CPP (CPP5)	60-30
Relay-Power-Port	60-31
64 Elektronische Steuerungen	
Fahr- und Arbeitshydrauliksteuerung	64- 1
Truck control unit (TCU)	64- 1
Truck control unit (TCU) Removal and installation	64- 2
Umrichter	64- 4
Inverter	64- 4
InvertersRemoval and installation	64- 6
69 Batterien und Zubehör	
Starterbatterie und Zubehör	69- 1
Starter battery	69- 1
70 Hydraulik	
Allgemein	70- 1
Allgemeine Technische Daten	70- 1
Lifting operating speeds	70- 2
Tilting operating speeds	70- 3
Lowering operating speeds	70- 3
Forward tilt safety test	70- 4
Lowering safety test	70- 4
Safety checks of hose assembly	70- 5
Grundhydraulik	70- 6
Basic hydraulics	70- 6
Fan motor control unit	70- 7
Fan control valve	70- 8
Steering hydraulics	70- 9
Working hydraulics	70-10
Variable displacement pump	70-11
Pump regulator	70-12
Variable displacement pumpRemoval and installation	70-14
Hydraulic tank	70-16
Hydraulic oil	70-16

Return filter	70-18
Breather	70-19
Suction filter	70-20
High-pressure filter	70-21
Conical nipple fittings (CNF)	70-22
Bolted joint	70-22

71 Arbeitshydraulik

Neigezylinder	71- 1
Mast tilt	71- 1
Tilt cylinders Removal and installation	71- 2
Changing the set of seals 2200 - 5000 kg	71- 3
Zusatzhydraulik	71- 6
Attachments	71- 6
Second operating function for attachments	71- 8
Clamp locking mechanism for hand levers	71- 9

76 Ventile

Handhebel	76- 1
General technical data	76- 1
Hand lever valve block	76- 2
Valve block Removal / installation	76- 3
Directional control valve block	76- 5
Check valve for hydraulics blocking function	76- 7
Hydraulic transmitter	76- 9
Servohydraulik	76-11
Allgemeine Technische Daten	76-11
Servo hydraulics valve block	76-12
Directional control valve block	76-13
Directional control valve function Lifting	76-16
Directional control valve function Lowering	76-18

81 Hubgerüste

Hubgerüst	81- 1
General technical data	81- 1
Telescopic lift mast	81- 2
Triple mast	81- 3

Lastketten	81- 5
Load chains Checking, cleaning	81- 5
Adjusting the load chains Telescopic mast	81- 6
Outer load chain Triple mast	81- 9
Middle load chain Triple mast	81-11
Endlagendämpfung	81-14
End position damping of outer cylinder	81-14
Middle cylinder end dampener	81-15
Leitungsbruchsicherung	81-16
Hose safety valve of triplex mast	81-16
Shock valve installation positions	81-17
Hubzylinder	81-19
Lift jack	81-19
Rollen / Stützrollen	81-20
Support roller clearance	81-20
84 Lastträger	
Gabelträger	84- 1
Fork carriage	84- 1
Anhang	
X Schaltpläne	
Hydraulik	X- 1
Hydraulic circuit diagram Multi-levers	X- 1
Hydraulic circuit diagram Proportional technology	X- 3

Thanks for your reading.

Please click here to download complete manual instantly.

And can also choose other manuals.

Feel free --->write to me with any questions.

Our service email:

manuals007@hotmail.com