

JCB Dieselmix Tier 3 SE Engine

[Section 1 - General Information](#)

[Section 2 - Care and Safety](#)

[Section 3 - Routine Maintenance](#)

[Section 4 - Systems Description](#)

[Section 5 - Fault Finding](#)

[Section 6 - Test Procedures](#)

[Section 7 - Fuel System](#)

[Section 8 - Cooling System](#)

[Section 9 - Lubrication System](#)

[Section 10 - Electrical System](#)

[Section 11 - Induction and Exhaust System](#)

[Section 12 - Base Engine](#)

[Section 13 - Electronic Data Systems](#)



Publication No.
9806/3030-01



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

Issued by JCB Technical Publications, JCB Aftermarket Training, Woodseat, Rocester, Staffordshire, ST14 5BW, England. Tel +44 1889 591300 Fax +44 1889 591400

World Class
Customer Support



Page left intentionally blank

Section 1



General Information

Service Manual - JCB Dieselmix Tier 3 SE Engine

[Section 1 - General Information](#)

[Section 2 - Care and Safety](#)

[Section 3 - Routine Maintenance](#)

[Section 4 - Systems Description](#)

[Section 5 - Fault Finding](#)

[Section 6 - Test Procedures](#)

[Section 7 - Fuel System](#)

[Section 8 - Cooling System](#)

[Section 9 - Lubrication System](#)

[Section 10 - Electrical System](#)

[Section 11 - Induction and Exhaust System](#)

[Section 12 - Base Engine](#)

[Section 13 - Electronic Data Systems](#)



Publication No.
9806/3030-02



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

Issued by JCB Technical Publications, JCB Aftermarket Training, Woodseat, Rocester, Staffordshire, ST14 5BW, England. Tel +44 1889 591300 Fax +44 1889 591400

World Class
Customer Support



Page left intentionally blank

Contents	Page No.
Introduction	
About this Manual	1 - 1
Using the Service Manual	1 - 1
Section Numbering	1 - 1
Left Side, Right Side	1 - 1
Units of Measurement	1 - 1
Machine Related Data	1 - 2
Cleanliness Requirements	
Effects of Contamination	1 - 3
Common Rail Fuel Injection System	1 - 3
Maintenance Environment, Common Rail Fuel Injection	1 - 4
Cleaning the Engine	1 - 6
Further Cleaning Procedures, Common Rail Fuel Injection	1 - 7
Terms and Definitions	
Acronyms and Abbreviations	1 - 8
Technical Data	
Fuel	1 - 9
Acceptable and Unacceptable Fuels	1 - 9
Fuel Types	1 - 11
Usage and Effects of Fuels	1 - 12
Sulphur Content	1 - 13
Effects of Fuel Contaminates	1 - 14
Basic Engine Data	1 - 15
Engine Block & Bedplate Data	1 - 16
Cylinder Head Data	1 - 17
Inlet and Exhaust Valve Data	1 - 18
Rocker Levers, Rocker Shaft and Tappets Data	1 - 19
Pistons and Connecting Rods Data	1 - 20
Crankshaft Data	1 - 21
Camshaft Data	1 - 22
Fuel System Data	1 - 23
Lubrication System Data	1 - 24
Cooling System Data	1 - 25
Electrical Equipment Data	1 - 26
Switches and Sensors	1 - 26
Identifying the Engine	
Engine Identification Plate	1 - 29
Typical Engine Identification Number	1 - 29
Component Labels	1 - 29
Engine Component Identification	1 - 30
External	1 - 30
Torque Settings	
Zinc Plated Fasteners and Dacromet Fasteners	1 - 38
Introduction	1 - 38
Bolts and Screws	1 - 38
Hydraulic Connections	1 - 42
'O' Ring Face Seal System	1 - 42
'Torque Stop' Hose System	1 - 45
Torque + Angle Explanation	1 - 46
Torque + Angle Tightening Procedure	1 - 47

Contents	Page No.
Engine Torque Figures	1 - 48
Lubricants and Capacities	
Engine Lubricating Oil	1 - 62
Recommended Oils	1 - 62
Engine Oil Capacity	1 - 62
Coolant	1 - 63
Coolant Mixtures	1 - 64
Coolant Mixtures	1 - 64
Service Aids	
Sealing, Retaining and Care Compounds	1 - 65
Service Tools	
General Engine Tools	1 - 66
Specialist Engine Tools	1 - 68
Service Tool Drawings	1 - 74
892/01146 - Core Plug Fitting Tool	1 - 74
892/01147 - Crankshaft Turning Tool	1 - 75
892/01148 - Timing Pin	1 - 76
892/01149 - Sump Sealant Template	1 - 77
892/01150 - Oil Sump Location Dowel	1 - 78
892/01151 - Injector Sleeve Removal Tool	1 - 79
892/01152 - Valve Stem Seal Fitting Tool	1 - 80
892/01154 - FIP Cover Removal Tool	1 - 81
892/01155 - FIP Gear Removal Tool	1 - 82
892/01157 - Crankshaft Front Seal Fitting Tool	1 - 83
892/01156 - Crankshaft Rear Seal Fitting Tool	1 - 84
892/01158 - Crankshaft Rear Seal Alignment Tool	1 - 85
892/01159 - Injector Seal Fitting Tool	1 - 85
892/01168 - Dummy Injector	1 - 86
Engine Mounting Frame	1 - 87
Service Parts and Repair Kits	
Engine Repair Parts and Kits Identification	1 - 88
Engine Lifting	
Lifting Information	1 - 101
Operating Procedures	
Starting the Engine	1 - 102
Pre-Start Notes	1 - 102
Start Procedure	1 - 103
Engine Checks After Start-up	1 - 104
Engine Running-in Procedure	1 - 105
Stopping the Engine	1 - 106
Storage and Preservation	
Storage	1 - 108
Preservation	1 - 109
Capping Engine Openings	1 - 109
Hot Test Description	1 - 110

Please Click Here To Download The Complete Manual
Download Other Manuals
If Having Any Questions Feel Free To Contact us

admin@servicemanualbit.com