

YANMAR

LIGHTING TOWER

SERVICE MANUAL

MODEL LIGHT BOY LB446HB-1/H-1

FOREWORD

This manual explains the service procedure for Yanmar lighting tower model LB446HB-1 & LB446H-1.

Please use this manual for correct, quick, safe servicing of the lighting tower.

Please be advised that the contents of this manual may be different from actual lighting tower because of any later modification of parts or specifications for improving the quality.

CONTENTS

| | |
|---|------------|
| 1.Safety..... | 1-2 |
| 1-1. Warning Symbols..... | 1-2 |
| 1-2-1. Service Shop (Location)..... | 1-3 |
| 1-2-2. Working Wear | 1-3 |
| 1-2. Loading generator..... | 1-3 |
| 1-2-3. Tools to Be Used..... | 1-4 |
| 1-2-4. Parts..... | 1-4 |
| 1-2-5. Bolt Tightening Torque | 1-4 |
| 1-2-6. Product Handling..... | 1-4 |
| 1-2-7. Installation | 1-5 |
| 1-2-8. Transport | 1-5 |
| 1-2-9. Warning Labels | 1-6 |
| 2.Outline of Lighting Tower..... | 2-2 |
| 2-1. Specifications..... | 2-2 |
| 2-2. External View and Components of Lighting Tower..... | 2-3 |
| 3.Structure of Lighting Tower | 3-2 |
| 3-1. Outline of Structure..... | 3-2 |
| 3-2. Electrical Group | 3-2 |
| 3-2-1. Balloon Unit..... | 3-3 |
| 1) Balloon assembly | 3-3 |
| 2) Stand assembly | 3-4 |
| 3-2-2. Lamp Stand Unit | 3-5 |
| 1) Lighting unit assembly | 3-5 |
| 2) Lamp stand assembly | 3-5 |
| 3-2-3. Power Cable Unit | 3-6 |
| 3-3. Mast Group | 3-7 |
| 3-4. Outrigger group..... | 3-8 |
| 3-5-1. Base Plate Unit | 3-9 |
| 3-5. Base Plate Group | 3-9 |
| 3-5-2. Steering Unit | 3-10 |
| 3-5-3. Brake Unit | 3-10 |
| 4.Disassembly and Assembly | 4-2 |
| 4-1. Before Starting Operation | 4-2 |
| 4-1-1. Grasp of Service History | 4-2 |
| 4-1-2. Preparing the Necessary Tools, Parts and Materials | 4-2 |

| | |
|---|-------------|
| 4-2. Disassembly and Assembly Procedures | 4-2 |
| 4-2-1. General Instructions | 4-2 |
| 1) Disassembly | 4-2 |
| 2) Reassembly..... | 4-2 |
| 4-2-2. Disassembly Procedure of Each Assembly /Unit /Group | 4-3 |
| 4-2-3. Disconnection of Couplers | 4-4 |
| 1) Removal of connector covers..... | 4-4 |
| 2) Disconnection of coupler..... | 4-5 |
| 4-2-4. Removal of Balloon Assembly | 4-6 |
| 4-2-5. Removal of Lighting Unit Assembly | 4-7 |
| 4-2-6. Removal of Pin (Socket) Contact | 4-8 |
| 4-2-7. Removal of Stand Assembly | 4-9 |
| 4-2-8. Removal of Lamp Stand Assembly | 4-9 |
| 4-2-9. Unloading of Generator | 4-10 |
| 4-2-10. Removal of Mast Group | 4-11 |
| 4-2-11. Removal of Outrigger Group | 4-11 |
| 4-2-12. Disassembly of Balloon Assembly | 4-12 |
| 4-2-13. Disassembly of Stand Assembly | 4-14 |
| 4-2-14. Disassembly of Lighting Unit Assembly | 4-14 |
| 4-2-15. Disassembly of Lamp Stand Assembly | 4-15 |
| 4-2-16. Disassembly of Power Cable Unit..... | 4-15 |
| 4-2-17. Disassembly of Mast Group | 4-16 |
| 4-2-18. Disassembly of Outrigger Group | 4-17 |
| 4-2-19. Disassembly of Base Plate Unit..... | 4-18 |
| 4-2-20. Disassembly of Steering Unit | 4-19 |
| 4-2-21. Disassembly of Brake Unit | 4-20 |
| 5.Inspection and Maintenance | 5-2 |
| 5-1. Electrical Group | 5-2 |
| 5-1-1. Balloon Unit..... | 5-2 |
| 1) Balloon assembly | 5-2 |
| 5-1-2. Lamp Stand Unit | 5-4 |
| 1) Lighting unit assembly..... | 5-4 |
| 2) Lamp stand assembly | 5-5 |
| 5-1-3. Replacement of Balloon Unit and Lamp Stand Unit..... | 5-6 |
| 1) Replacement | 5-6 |
| 2) Storage of removed balloon unit and lamp stand unit | 5-6 |

| | |
|---|-------------|
| 5-1-4. Power Cable Unit | 5-6 |
| 1) Connection of power cable..... | 5-6 |
| 2) Voltage check..... | 5-7 |
| 3) Replacement of lamp cable..... | 5-8 |
| 5-2-1. Mast Group | 5-9 |
| 1) Shaft of mast | 5-9 |
| 2) Sliding surface of mast | 5-9 |
| 3) Winch | 5-9 |
| 5-2. Mast Group | 5-9 |
| 4) Wire | 5-10 |
| 5-4. Base Plate Group | 5-12 |
| 5-4-1. Base Plate Unit | 5-12 |
| 5-4-2. Steering Unit | 5-12 |
| 5-3. Outrigger Group..... | 5-12 |
| 5-4-3. Brake Unit | 5-13 |
| 5-5. Grounding | 5-13 |
| 6. Periodic Inspection Items | 6-2 |
| 6-1. Inspection Items and Intervals | 6-2 |
| 7. Circuit | 7-2 |
| 7-1. Electrical Circuit | 7-2 |
| 7-1-1. How to Read Electrical Circuit Diagram | 7-2 |
| 7-1-2. Electrical Circuit Diagram | 7-2 |
| 8. Tools, Instruments and Other Materials for Inspection and Maintenance | 8-2 |
| 8-1. Machines, Tools and Instruments | 8-2 |
| 8-1-1. General Tools..... | 8-2 |
| 8-1-2. Special Tool | 8-3 |
| 8-1-3. Measuring Instrument | 8-3 |
| 8-1-4. Materials Required | 8-3 |
| 9. Bolts and Nuts Tightening Torques | 9-2 |
| 9-1. General Instructions..... | 9-2 |
| 9-2. Major Bolts and Nuts | 9-3 |
| 10. Troubleshooting | 10-2 |
| 10-1. Troubleshooting Procedures..... | 10-2 |

**Please Click Here To Download The Complete Manual
Download Other Manuals
If Having Any Questions Feel Free To Contact us**

admin@servicemanualbit.com