

# Troubleshooting

---

## **1104E and 1106E Industrial Engines**

---

RF1 (Engine)  
RH1 (Engine)  
RK1 (Engine)  
VK1 (Engine)

## Important Safety Information

Most accidents that involve product operation, maintenance and repair are caused by failure to observe basic safety rules or precautions. An accident can often be avoided by recognizing potentially hazardous situations before an accident occurs. A person must be alert to potential hazards. This person should also have the necessary training, skills and tools to perform these functions properly.

**Improper operation, lubrication, maintenance or repair of this product can be dangerous and could result in injury or death.**

**Do not operate or perform any lubrication, maintenance or repair on this product, until you have read and understood the operation, lubrication, maintenance and repair information.**

Safety precautions and warnings are provided in this manual and on the product. If these hazard warnings are not heeded, bodily injury or death could occur to you or to other persons.

The hazards are identified by the "Safety Alert Symbol" and followed by a "Signal Word" such as "DANGER", "WARNING" or "CAUTION". The Safety Alert "WARNING" label is shown below.



The meaning of this safety alert symbol is as follows:

**Attention! Become Alert! Your Safety is Involved.**

The message that appears under the warning explains the hazard and can be either written or pictorially presented.

Operations that may cause product damage are identified by "NOTICE" labels on the product and in this publication.

**Perkins cannot anticipate every possible circumstance that might involve a potential hazard. The warnings in this publication and on the product are, therefore, not all inclusive. If a tool, procedure, work method or operating technique that is not specifically recommended by Perkins is used, you must satisfy yourself that it is safe for you and for others. You should also ensure that the product will not be damaged or be made unsafe by the operation, lubrication, maintenance or repair procedures that you choose.**

The information, specifications, and illustrations in this publication are on the basis of information that was available at the time that the publication was written. The specifications, torques, pressures, measurements, adjustments, illustrations, and other items can change at any time. These changes can affect the service that is given to the product. Obtain the complete and most current information before you start any job. Perkins dealers or Perkins distributors have the most current information available.



**When replacement parts are required for this product Perkins recommends using Perkins replacement parts.**

**Failure to heed this warning can lead to premature failures, product damage, personal injury or death.**

# Table of Contents

## Troubleshooting Section

### Electronic Troubleshooting

System Overview .....	5
Glossary .....	9
Electronic Service Tools .....	12
Indicator Lamps .....	14
Replacing the ECM .....	16
Self-Diagnostics .....	17
Sensors and Electrical Connectors .....	18
Engine Wiring Information .....	22

### Programming Parameters

Programming Parameters .....	31
Factory Passwords .....	31
Flash Programming .....	31

### System Configuration Parameters

System Configuration Parameters .....	33
---------------------------------------	----

### Troubleshooting without a Diagnostic Code

Alternator Noise (Noisy Operation) .....	34
Alternator Will Not Charge (Charging Problem) ....	34
Battery .....	35
Can Not Reach Top Engine RPM .....	35
Coolant in Engine Oil .....	36
Coolant Temperature Is Too High .....	37
ECM Will Not Accept Factory Passwords .....	38
ECM Will Not Communicate with Other Systems or Display Modules .....	39
Electronic Service Tool Will Not Communicate with ECM .....	39
Engine Cranks but Will Not Start .....	40
Engine Has Early Wear .....	42
Engine Misfires, Runs Rough or Is Unstable .....	42
Engine Oil in Cooling System .....	44
Engine Stalls at Low RPM .....	45
Engine Vibration .....	46
Engine Will Not Crank .....	47
Excessive Black Smoke .....	48
Excessive Engine Oil Consumption .....	49
Excessive Valve Lash .....	51
Excessive White Smoke .....	51
Intake Air Temperature Is Too High .....	52
Intermittent Engine Shutdown .....	53
Intermittent Low Power or Power Cutout .....	54
Low Engine Oil Pressure .....	56
Low Power/Poor or No Response to Throttle .....	57
Mechanical Noise (Knock) in Engine .....	59
Noise Coming from Cylinder .....	60

### Troubleshooting with a Diagnostic Code

Diagnostic Code Cross Reference .....	61
CID 0041 FMI 03 .....	62
CID 0041 FMI 04 .....	63
CID 0091 FMI 02 .....	63
CID 0091 FMI 03 .....	64
CID 0091 FMI 04 .....	64
CID 0091 FMI 08 .....	65

CID 0091 FMI 12 .....	65
CID 0100 FMI 03 .....	66
CID 0100 FMI 04 .....	66
CID 0100 FMI 10 .....	66
CID 0102 FMI 03 .....	67
CID 0102 FMI 04 .....	67
CID 0102 FMI 10 .....	68
CID 0105 FMI 03 .....	68
CID 0105 FMI 04 .....	68
CID 0110 FMI 03 .....	69
CID 0110 FMI 04 .....	69
CID 0174 FMI 02 .....	69
CID 0247 FMI 09 .....	70
CID 0253 FMI 02 .....	70
CID 0262 FMI 03 .....	70
CID 0262 FMI 04 .....	71
CID 0320 FMI 02 .....	71
CID 0320 FMI 11 .....	71
CID 0342 FMI 02 .....	72
CID 0774 FMI 02 .....	72
CID 0774 FMI 03 .....	73
CID 0774 FMI 04 .....	73
CID 0774 FMI 08 .....	74
CID 0774 FMI 12 .....	74
CID 1627 FMI 03 .....	75
CID 1684 FMI 00 .....	75
CID 1684 FMI 02 .....	76
CID 1684 FMI 03 .....	76
CID 1684 FMI 04 .....	77
CID 1684 FMI 05 .....	77
CID 1684 FMI 07 .....	77
CID 1684 FMI 08 .....	78
CID 1684 FMI 09 .....	78
CID 1684 FMI 10 .....	79
CID 1684 FMI 11 .....	80
CID 1684 FMI 12 .....	80
CID 1684 FMI 14 .....	81
CID 1743 FMI 02 .....	81
CID 1894 FMI 02 .....	82
CID 1895 FMI 02 .....	82

### Troubleshooting with an Event Code

Event Codes .....	83
E015 High Engine Coolant Temperature Derate ..	83
E016 High Engine Coolant Temperature Shutdown .....	83
E017 High Engine Coolant Temperature Warning .....	83
E025 High Inlet Air Temperature Derate .....	84
E027 High Inlet Air Temperature Warning .....	84
E040 Low Engine Oil Pressure Shutdown .....	85
E054 High Fuel Temperature Derate .....	85
E056 High Fuel Temperature Warning .....	86
E100 Low Engine Oil Pressure Warning .....	87
E190 Engine Overspeed Warning .....	88

### Diagnostic Functional Tests

5 Volt Engine Pressure Sensor Supply Circuit - Test .....	89
Air Inlet Heater Circuit - Test .....	93
Analog Throttle Position Sensor Circuit - Test .....	98
CAN Data Link Circuit - Test .....	103
Data Link Circuit - Test .....	111

---

Digital Throttle Position Sensor Circuit - Test .....	119
Electrical Connectors - Inspect .....	125
Electrical Power Supply Circuit - Test .....	134
Engine Pressure Sensor Open or Short Circuit - Test .....	139
Engine Temperature Sensor Open or Short Circuit - Test .....	145
Fuel Injection Pump Circuit - Test .....	149
Indicator Lamp Circuit - Test .....	159
Mode Selection Circuit - Test .....	162
Set Speed Circuit - Test .....	166
Speed/Timing Sensor Circuit - Test .....	171
Throttle Switch Circuit - Test .....	174

**Index Section**

Index .....	180
-------------	-----

**Please Click Here To Download The Complete Manual**  
**Download Other Manuals**  
**If Having Any Questions Feel Free To Contact us**

**[admin@servicemanualbit.com](mailto:admin@servicemanualbit.com)**