

DL450

Shop Manual

K1039661E

Serial Number 5001 and Up

DOOSAN reserves the right to improve our products in a continuing process to provide the best possible product to the market place. These improvements can be implemented at any time with no obligation to change materials on previously sold products. It is recommended that consumers periodically contact their distributors for recent documentation on purchased equipment.

This documentation may include attachments and optional equipment that is not available in your machine's package. Please call your distributor for additional items that you may require.

Illustrations used throughout this manual are used only as a representation of the actual piece of equipment, and may vary from the actual item.

DL450

Serial Number 5001 and Up

Pub. No. K1039661E

Product Label



Instructions

**Trim Out The Label Along
The Lines And Insert Into
Pocket On The Binder Spine**



Table of Contents

Safety

Wheel Loader Safety	SP001667
---------------------------	----------

Specifications

Specification for DL450.....	SP001668
------------------------------	----------

General Maintenance

General Maintenance Procedures	SP000097
Standard Torques	SP000813

Engine

QSM11 Engine	SP001669
--------------------	----------

Drive Train

Transmission and Torque Converter (ZF 4WG-260-4).....	SP001670
Transmission Error Codes (ZF)	SP000100
Axle (ZF-MT-L 3105)	SP001672
Drive Shaft.....	SP001673

Brake

Service Brake	SP001674
Brake Supply Valve	SP000121
Parking Brake	SP000122
Brake Pedal Valve	SP000123
Accumulator	SP001675

Steering

Steering Unit	SP001676
Flow Amplifier	SP000126
Cushion Valve.....	SP000127

Emergency Steering SP001677

Frame

Articulation Center SP001678
Counterweight..... SP000130

Tank

Oil Tank SP001679
Fuel Tank..... SP001680

Hydraulics

Main Control Valve SP001681
Load Isolation System SP001682
Cooling System..... SP000154
Pilot System..... SP001714
Hydraulic Schematic (DL450) SP001683

Electrical System

Air Conditioner SP000172
Electrical System SP001684
Electrical Schematic (DL450) SP001685

Safety

Wheel Loader Safety

Edition 1

Please Click Here To Download The Complete Manual
Download Other Manuals
If Having Any Questions Feel Free To Contact us

admin@servicemanualbit.com