



Workshop literature

STILL
ELECTRONIC
DOCUMENTATION
SYSTEM

ECU25, ECU30



ECU25 ECU30 TN

45628042104 EN - 10/2010

first in intralogistics

Edition 10/2010

- First issue

00 General information

Safety precautions	00- 1
Description of safety symbols	00- 1
Preliminary maintenance operations	00- 1
To avoid accidents	00- 1
Safety Regulations Relative to Operating Materials	00- 1
Product information	00- 3
Frame labelling	00- 3
Stopping the truck in an emergency	00- 3
Forklift Use in Cold-Storage Rooms.	00- 4
Maintenance	00- 5
Supply Table	00- 5
Synoptic Table of Maintenance Operations	00- 6
Fork tolerance table	00- 7
Speed tolerance table	00- 7

02 Diagnostics

Diagnostics connector	02- 1
Positioning the diagnostic connector	02- 1
Electronic system diagnostics	02- 2
Electronic system software	02- 2
Parameters	02-13
Table of parameters: electronic control for version with 2500/3000 kg capacity	02-13
ALARMS list	02-17
WARNING list	02-21

11 Motor

Traction motor	11- 1
Drive unit assembly diagram	11- 1
Drive motor type	11- 2
Drive disabling	11- 2
Removing the drive motor	11- 3
Removing the drive shaft bearing	11- 9

22 Reducer

Reducer	22- 1
Reducer gearbox drawing	22- 1

Description of the reducer	22- 2
Disassembly / Reassembly of the reducer	22- 3
Instructions for assembly/ service on the reducer	22- 3
Disassembly and reassembly of the transmission gear	22- 5
Reducer gearbox group overhaul	22- 7
Reducer maintenance	22-13
Adjustment of the bevel gear system	22-13
31 Lift mast	
Covers	31- 1
Cover topography	31- 1
Removing the covers	31- 2
42 Steering	
Tiller	42- 1
Tiller head views	42- 1
Disassembling tiller head buttons	42- 2
Disassembling the anti-crush button	42- 3
Disassembling tiller head covers	42- 5
Disassembling traction potentiometer	42- 9
Tiller head traction potentiometer	42-11
Operating conditions	42-11
Assembling and disassembling the tiller gas spring	42-13
Disassembling the tiller arm	42-15
Lifting/lowering of fork arms and interlock devices	42-17
Numerical keypad (optional)	42-17
Disassembling the numerical keypad	42-19
Tiller head electronic card	42-20
46 Wheels	
Wheels	46- 1
Disassembly and reassembly of the drive wheel	46- 1
Disassembly and reassembly of the pivoting wheel	46- 2
49 Brake system	
Braking method	49- 1
Braking devices and methods	49- 1

Electromagnetic brake	49- 2
Calibrating the electromagnetic brake	49- 2
60 Electrical and electronic system	
Electrical/electronic system: general information.	60- 1
Electronic control system functional diagram	60- 1
Main features of the electronic system	60- 2
Electronic system inputs and outputs	60- 3
Fuse replacement	60- 4
Batteries	60- 5
Battery dimensions and weights	60- 5
Battery status indicator and hour meter	60- 5
Battery Recharging	60- 6
On-board battery charger	60- 7
Recharging the battery using the on-board battery charger (optional)	60- 8
Description of Pb/lead battery charging phases for on-board battery charger	60- 9
Removing the on-board battery charger	60-11
Removing the battery plug mounting bracket	60-13
71 Hydraulic components	
Hydraulic control unit	71- 1
Hydraulic control unit assembly diagram	71- 1
Hydraulic control unit circuit diagram	71- 3
Hydraulic control unit motor	71- 3
Removing the hydraulic control unit	71- 5
Hydraulic control unit maintenance	71- 8
Fork lifting cylinder	71-14
Removing the fork lift cylinder	71-14
Fork lift cylinder unit	71-18
Overhauling the fork lift cylinder	71-19
Assembling the fork lift cylinder	71-22
84 Load support system	
Forks, rods and levers	84- 1
Forks and levers	84- 1
Removal of the lever system	84- 3
Removal and replacement of the bushings	84- 8

90 Options

Standard and optional features	90- 1
Standard and optional features	90- 1

Annex

A Diagrams

Wiring diagrams	A- 1
Electrical connection diagram - Sheet 1/4	A- 1
Electrical connection diagram - Sheet 2/4	A- 3
Electrical connection diagram - Sheet 3/4	A- 5
Electrical connection diagram - Sheet 4/4	A- 7
Electrical wiring diagram with PIN CODE - sheet 1/4	A- 9
Electrical wiring diagram with PIN CODE - sheet 2/4	A-11
Electrical wiring diagram with PIN CODE - sheet 3/4	A-13
Electrical wiring diagram with PIN CODE - sheet 4/4	A-15
Hydraulic diagrams	A-17
Hydraulic diagram	A-17

Thanks for your reading.

Please click here to download complete manual instantly.

And can also choose other manuals.

Feel free --->write to me with any questions.

Our service email:

manuals007@hotmail.com